



# SAKURA

## HINO FILTERS SUB-CATALOGUE





# Table of Contents

Engine Application .....

**A**

Technical Specification .....

**B**



# Engine Application

A

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
120 (TRUCKS) HINO EB200 , 1970-1977		Fuel Filter.....	FC-1312	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU142M , 4100, 1995-1999	
Fuel Filter.....	F-1302	2218P (TRUCKS) HINO H06C-TN		Air Filter.....	A-1112
121 (TRUCKS) HINO EB400 , 1977-UP		Fuel Filter.....	FC-1312	Oil Filter Combination.....	C-1112
Air Filter.....	AS-5709	2320DH (TRUCKS) HINO J08C-TP		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU147M , 4100, 1996-1999	
Fuel Filter.....	F-1302	Air Filter.....	A-1334	Air Filter.....	A-1112
Oil Filter Full Flow.....	O-1303	Fuel/Water Separator Primary....	SFC-1306-30	Oil Filter Combination.....	C-1112
1415 (TRUCKS) HINO W04C-TH		Oil Filter Full Flow.....	C-1314	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU162M , 4100, 1995-1999	
Air Filter Primary.....	A-5639	238 (TRUCKS) HINO J08E , 2005-UP		Air Filter.....	A-1112
Air Filter Set.....	A-5654-S	Air Filter Primary.....	A-5020	Oil Filter Combination.....	C-1112
Fuel Filter.....	FC-1305	Fuel/Water Separator.....	SF-27010	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU162T , 4100, 1995-1999	
Fuel Filter Primary.....	FC-1310	Fuel/Water Separator Secondary..	SFC-7912-10	Air Filter.....	A-1112
Oil Filter Full Flow.....	C-1301	Fuel/Water Separator Secondary..	SFC-7912-10B	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	C-1309	Oil Filter Transmission.....	TC-7901	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU162X , 4100, 1995-1999	
141P (TRUCKS) HINO EF350 , 1980-UP		238LP (TRUCKS) HINO J08E , 2005-UP		Air Filter.....	A-1112
Fuel Filter.....	F-1304	Air Filter Primary.....	A-5020	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	O-13081	Fuel/Water Separator.....	SF-27010	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU172M , 4100, 1995-1999	
145 (TRUCKS) HINO J05D , 2005-UP		Fuel/Water Separator Secondary..	SFC-7912-10	Air Filter.....	A-1112
Air Filter Primary.....	A-5020	Fuel/Water Separator Secondary..	SFC-7912-10B	Oil Filter Combination.....	C-1112
Fuel/Water Separator.....	SF-27010	Oil Filter Transmission.....	TC-7901	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU182M , 4100, 1996-1999	
Oil Filter Full Flow.....	C-1314	2/3 RANGER (TRUCKS) 4.1L 15B-FP GE-RZU100E , 4100, 1999-2000		Air Filter.....	A-1112
156 (TRUCKS) HINO H06C-T , 1982-1983		Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1112
Oil Filter By Pass.....	O-1318	2/3 RANGER (TRUCKS) 4.1L 15B-FP GE-RZU100X , 4100, 1999-2000		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU202M , 4100, 1996-1999	
165 (TRUCKS) HINO J05D , 2005-UP		Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
Air Filter Primary.....	A-5020	2/3 RANGER (TRUCKS) 3.4L 3B KC-BU100M , 3400, 1995-1999		Oil Filter Combination.....	C-1112
Fuel/Water Separator.....	SF-27010	Air Filter.....	A-1119	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU102M , 4100, 1995-1999	
Oil Filter Full Flow.....	C-1314	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
185 (TRUCKS) HINO J05D , 2005-UP		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU105M , 3400, 1997-1999		Oil Filter Combination.....	C-1112
Air Filter Primary.....	A-5020	Air Filter.....	A-1119	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU107M , 4100, 1996-1999	
Fuel/Water Separator.....	SF-27010	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
Fuel/Water Separator Secondary..	SFC-7912-10	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU107M , 4100, 1996-1999		Oil Filter Combination.....	C-1112
Fuel/Water Separator Secondary..	SFC-7912-10B	Air Filter.....	A-1112	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU112M , 4100, 1995-1999	
Oil Filter Full Flow.....	C-1314	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
2218 (TRUCKS) HINO H06C-TM		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU107M , 4100, 1996-1999		Oil Filter Combination.....	C-1112
Air Filter Primary.....	A-5639	Air Filter.....	A-1112	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU112M , 4100, 1995-1999	
Air Filter Set.....	A-5654-S	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
Fuel Filter.....	FC-1305	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU112M , 4100, 1995-1999		Oil Filter Combination.....	C-1112
Fuel Filter.....	FC-1312	Air Filter.....	A-1112	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU122M , 4100, 1997-1999	
Fuel Filter Primary.....	FC-1310	Oil Filter Combination.....	C-1112	Air Filter.....	A-1158
2218 (TRUCKS) HINO H06C-TN		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU122M , 4100, 1997-1999		Oil Filter Combination.....	C-1112
Air Filter Primary.....	A-5639	Air Filter.....	A-1112	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU137M , 4100, 1997-1999	
Air Filter Set.....	A-5654-S	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
Fuel Filter.....	FC-1305	2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU137M , 4100, 1997-1999		Oil Filter Combination.....	C-1112
Fuel Filter.....	FC-1312	Air Filter.....	A-1112	2/3 RANGER (TRUCKS) 5.3L J05C KC-XZU130X , 5300, 1995-1999	
Fuel Filter Primary.....	FC-1310	Oil Filter Combination.....	C-1112	Air Filter.....	A-1112
2218P (TRUCKS) HINO H06C-TM		2/3 RANGER (TRUCKS) 4.1L 15B-F KC-BU137M , 4100, 1997-1999			

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>2/3 RANGER</b> (TRUCKS) 5.3L J05C KC-XZU130X , 5300, 1995-1999 Fuel Filter..... FC-1302 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>300</b> (TRUCKS) 4.0L N04C XZU710R , 4000, 2011 Air Filter..... A-13570		<b>338</b> (TRUCKS) HINO J08E , 2005-UP Air Filter Primary..... A-5020 Fuel/Water Separator..... SF-27010 Fuel/Water Separator Primary.... SFC-1306-30 Fuel/Water Separator Secondary... SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Full Flow..... C-1314 Oil Filter Transmission..... H-8537-S	
<b>2/3 RANGER</b> (TRUCKS) 5.3L J05C KC-XZU140M , 5300, 1997-1999 Air Filter..... A-1112 Fuel Filter..... FC-1302 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>3018</b> (TRUCKS) HINO H06C-TM Fuel Filter..... FC-1312		<b>360P</b> (TRUCKS) HINO EF500 , 1980-UP Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081	
<b>258LP</b> (TRUCKS) HINO J08E-TA , 2005-UP Air Filter Primary..... A-5020 Fuel/Water Separator..... SF-27010 Fuel/Water Separator Secondary.. SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Transmission..... TC-7901		<b>3018</b> (TRUCKS) HINO H06C-TN Fuel Filter..... FC-1312		<b>390</b> (TRUCKS) HINO EK100 , 1974-UP Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305	
<b>2618</b> (TRUCKS) HINO H06C-TM Fuel Filter..... FC-1312		<b>3020</b> (TRUCKS) HINO H06C-TM Fuel Filter..... FC-1312		<b>540</b> (TRUCKS) HINO EH100 , 1972-1979 Air Filter..... AS-1303 Fuel Filter..... F-1301 Oil Filter Full Flow..... 0-1301	
<b>2618</b> (TRUCKS) HINO H06C-TN Fuel Filter..... FC-1312		<b>306</b> (TRUCKS) HINO EK100 , 1975-UP Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305		<b>541</b> (TRUCKS) HINO EC100 Oil Filter Full Flow..... 0-1301	
<b>268</b> (TRUCKS) HINO J08E , 2005-UP Air Filter Primary..... A-5020 Fuel/Water Separator..... SF-27010 Fuel/Water Separator Secondary... SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Transmission..... TC-7901		<b>308</b> (TRUCKS) HINO J08E Air Filter Primary..... A-5020 Fuel/Water Separator..... SF-27010 Fuel/Water Separator Secondary... SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Transmission..... TC-7901		<b>541</b> (TRUCKS) HINO EH100 Oil Filter Full Flow..... 0-1301	
<b>300</b> (TRUCKS) 4.0L N04C-UV , 4000, 2013 Fuel Filter..... FC-13210		<b>320</b> (TRUCKS) HINO DK20 , 1969-1979 Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303		<b>5523</b> (TRACTORS) HINO H06C-TM Air Filter Primary..... A-5639 Air Filter Set..... A-5654-S Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305 Oil Filter Full Flow..... C-1305	
<b>300</b> (TRUCKS) 4.0L N04C , 4000, 2011 Fuel Filter..... EF-13070		<b>321</b> (TRUCKS) HINO ER200 , 1980 Air Filter..... AS-5709 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305		<b>561</b> (TRUCKS) HINO EF500 , 1979-UP Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081	
<b>300</b> (TRUCKS) 4.0L N04C EURO 3 , 4000 Fuel Filter..... F-1306		<b>321</b> (TRUCKS) HINO ER200 , 1978-UP Air Filter..... AS-5709 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-1301		<b>6797</b> (BUSES) HINO EF300 , 1977 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	
<b>300</b> (TRUCKS) 5.0L J05E , 5000, 2011 Fuel Filter..... EF-13070		<b>3320</b> (TRUCKS) HINO H06C-TM Fuel Filter..... FC-1312		<b>700 SERIES</b> (TRUCKS) 2008-UP Air Filter Secondary..... A-6120M Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-1011 Oil Filter Full Flow..... C-1011XPL	
<b>300</b> (TRUCKS) J05E Fuel Filter..... EF-13020 Fuel Filter..... EF-13021		<b>3320</b> (TRUCKS) HINO H06C-TN Fuel Filter..... FC-1312		<b>700 SERIES</b> (TRUCKS) 2007-UP	
<b>300</b> (TRUCKS) N04CT Fuel Filter..... EF-13020 Fuel Filter..... EF-13021		<b>3323</b> (TRUCKS) HINO H06C-TM Fuel Filter..... FC-1312			
<b>300</b> (TRUCKS) 4.0L N04C-UV XZU7# , 4000, 2013 Air Filter..... A-13570		<b>3323</b> (TRUCKS) HINO H06C-TN Fuel Filter..... FC-1312			

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>700 SERIES</b> (TRUCKS) 2007-UP		<b>BLUE RIBBON</b> (BUSES) EK200 , 1983-1985		Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1011	Air Filter.....	A-1304	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1011XPL	Air Filter.....	AS-1304		
<b>700 SERIES</b> (TRUCKS) HINO E13CTI		<b>BLUE RIBBON</b> (BUSES) J08E-T ACG-HU8J , HU, 2005-2007		<b>BLUE RIBBON</b> (BUSES) J08C KL-HU1J , HU, 2000-2002	
Oil Filter Full Flow.....	0-1322	Air Filter Primary.....	A-1324	Air Filter.....	A-1311
		Air Filter Primary.....	A-1324M	Fuel Filter.....	FC-1301
<b>700 SERIES</b> (TRUCKS) K13C-T		Air Filter Set.....	A-1324-S	Oil Filter Combination.....	C-1315
Oil Filter Full Flow.....	E0-13050	Air Filter Set.....	A-1324M-S		
<b>705</b> (TRUCKS) HINO EF300 , 1975-1979		<b>BLUE RIBBON</b> (BUSES) J08E-T BJG-HU8J , HU, 2007-2010		<b>BLUE RIBBON</b> (BUSES) P11C-T KL-HU2P#E , HU, 2000-2005	
Fuel Filter.....	F-1304	Air Filter Primary.....	A-1324	Air Filter.....	A-1315
Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-1324M	Fuel Filter.....	FC-1305
Oil Filter By Pass.....	0-1305	Air Filter Set.....	A-1324-S	Fuel Filter Primary.....	FC-1310
		Air Filter Set.....	A-1324M-S		
<b>706</b> (TRUCKS) HINO EF300 , 1975-1979		<b>BLUE RIBBON</b> (BUSES) J08C-T HM-HU1J , HU, 2001-2002		<b>BLUE RIBBON</b> (BUSES) 6HK1-T LDG-KV234#3 , KV, 2010-2012	
Fuel Filter.....	F-1304	Air Filter.....	A-1311	Air Filter Primary.....	A-1013
Oil Filter By Pass.....	0-1305			Air Filter Primary.....	A-10134
Oil Filter Full Flow.....	0-1301			Air Filter Set.....	A-1841-S
				Fuel Filter.....	EF-1509
<b>AC140</b> (BUSES) HINO W06D		<b>BLUE RIBBON</b> (BUSES) M10U KC-HT2M#C , HT, 1995-2000		Oil Filter By Pass.....	0-1524
Fuel Filter.....	F-1303	Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	0-1313
		Air Filter Primary.....	A-60400		
<b>AK17</b> (BUSES) HINO EH700		Air Filter Set.....	A-6118-S	<b>BLUE RIBBON</b> (BUSES) J08E-T LJG-HU8J , HU, 2010-2012	
Air Filter.....	AS-1303	Fuel Filter Primary.....	FC-1310	Air Filter Primary.....	A-1324
Fuel Filter.....	F-1301	Fuel Filter.....	FC-1305	Air Filter Primary.....	A-1324M
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-1324-S
				Air Filter Set.....	A-1324M-S
<b>AK176</b> (TRUCKS) NISSAN 6 CYL		<b>BLUE RIBBON</b> (BUSES) K13U KC-HT3K#C , HT, 1995-2000		<b>BLUE RIBBON</b> (BUSES) 6HK1-T LKG-KV234#3 , KV, 2010-2012	
Air Filter.....	A-1305	Air Filter Primary.....	A-6006	Air Filter Primary.....	A-10134
Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400	Air Filter Primary.....	A-1013
Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-6118-S	Air Filter Set.....	A-1841-S
		Fuel Filter Primary.....	FC-1310	Fuel Filter.....	EF-1509
		Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	0-1313
<b>AM100</b> (BUSES) HINO EC100 , 1971-1984		Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1524
Air Filter.....	A-1301				
Fuel Filter.....	F-1301	<b>BLUE RIBBON</b> (BUSES) M10U KC-HU2M#C , HU, 1995-2000		<b>BLUE RIBBON</b> (BUSES) J08E-T LNG-HU8J , HU, 2012	
Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-60400	Air Filter Primary.....	A-1324
		Air Filter Primary.....	A-6006	Air Filter Primary.....	A-1324M
<b>BC144</b> (TRUCKS) HINO W06D		Air Filter Set.....	A-6118-S	Air Filter Set.....	A-1324-S
Air Filter.....	A-1305	Fuel Filter Primary.....	FC-1310	Air Filter Set.....	A-1324M-S
Fuel Filter.....	F-1303	Fuel Filter.....	FC-1305		
Oil Filter Full Flow.....	0-1314	Oil Filter Full Flow.....	0-1301	<b>BLUE RIBBON</b> (BUSES) 6HK1-T PDG-KV234#2 , KV, 2007-2010	
				Air Filter Primary.....	A-10134
<b>BG100</b> (TRUCKS) HINO DK20 , 1981-UP		<b>BLUE RIBBON</b> (BUSES) P11C-T KC-HU2P#C , HU, 1999-2001		Air Filter Primary.....	A-1013
Air Filter.....	A-1305	Air Filter.....	A-1315	Air Filter Set.....	A-1841-S
Fuel Filter.....	F-1303	Fuel Filter.....	FC-1305	Fuel Filter.....	EF-1509
		Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	0-1524
				Oil Filter Full Flow.....	0-1313
<b>BG100</b> (TRUCKS) HINO DK20 , 1972-1980		<b>BLUE RIBBON</b> (BUSES) K13U KC-HU3K#C , HU, 1995-2000		<b>BLUE RIBBON</b> (BUSES) 6HK1-T PJ-KV234#1 , KV, 2005-2007	
Fuel Filter.....	F-1302	Air Filter.....	A-1315	Air Filter Primary.....	A-1013
		Fuel Filter.....	FC-1305	Air Filter Primary.....	A-10134
<b>BG300</b> (TRUCKS) HINO EK100		Fuel Filter Primary.....	FC-1310	Air Filter Set.....	A-1841-S
Air Filter Secondary.....	A-5408	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	FC-1203
Fuel Filter.....	F-1304			Oil Filter Full Flow.....	0-1313
Oil Filter Full Flow.....	0-1301	<b>BLUE RIBBON</b> (BUSES) P11C-T KL-HT2P , HT, 2000-2002		Oil Filter By Pass.....	0-1524
		Air Filter.....	A-1315		



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>BLUE RIBBON</b> (BUSES) 6HK1-T PKG-KV234#2 , KV, 2007-2010		Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	EO-1102
Air Filter Primary.....	A-1013	<b>BU301M</b> (TRUCKS) HINO 4B , 1999		<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRU300M , 2700, 2007-2011	
Air Filter Primary.....	A-10134	Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	EO-1102
Air Filter Set.....	A-1841-S	Oil Filter Combination.....	C-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRU300X , 2700, 2007-2011	
Fuel Filter.....	EF-1509	<b>BU400</b> (TRUCKS) TOYOTA 15BFET , 1999		Oil Filter Full Flow.....	EO-1102
Oil Filter By Pass.....	O-1524	Fuel Filter.....	FC-1707	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRU340M , 2700, 2007-2011	
Oil Filter Full Flow.....	O-1313	Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	EO-1102
<b>BLUE RIBBON</b> (BUSES) 6HK1-T QPG-KV234#3 , KV, 2013		<b>BU400M</b> (TRUCKS) HINO 15BFTE , 1999		<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRU500M , 2700, 2007-2011	
Air Filter Primary.....	A-1013	Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	EO-1102
Air Filter Primary.....	A-10134	Oil Filter Combination.....	C-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRU600M , 2700, 2011	
Air Filter Set.....	A-1841-S	<b>BUS</b> (BUSES) 4.6L 05C-TB RB8 , 4600, 2007		Oil Filter Full Flow.....	EO-1102
Oil Filter Full Flow.....	O-1313	Fuel Filter.....	F-1110	<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU304E , 4000, 2006-2010	
Oil Filter By Pass.....	O-1524	<b>BX320</b> (TRUCKS) HINO EH100 , 1975-UP		Air Filter.....	A-3370
<b>BLUE RIBBON</b> (BUSES) 6HK1-T QPG-KV234#3 , KV, 2012-2013		Fuel Filter.....	F-1301	Fuel Filter.....	EF-1112
Air Filter Primary.....	A-1013	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1318
Air Filter Primary.....	A-10134	<b>BX340</b> (TRUCKS) HINO EH100		<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU304M , 4000, 2006-2009	
Air Filter Set.....	A-1841-S	Air Filter.....	AS-1303	Air Filter.....	A-3370
Fuel Filter.....	EF-1509	Fuel Filter.....	F-1304	Fuel Filter.....	EF-1112
Oil Filter By Pass.....	O-1524	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1318
Oil Filter Full Flow.....	O-1313	<b>BX341</b> (TRUCKS) HINO EH700		<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU304T , 4000, 2006-2009	
<b>BU102</b> (TRUCKS) TOYOTA 15B , 1995		Air Filter.....	AS-1303	Air Filter.....	A-3370
Air Filter.....	A-1112	Fuel Filter.....	F-1303	Fuel Filter.....	EF-1112
Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1318
<b>BU102E</b> (TRUCKS) TOYOTA 15BF , 1996		<b>CG277</b> (TRUCKS) HINO EK200 , 1984-1990		<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU304X , 4000, 2006-2009	
Air Filter.....	A-1112	Air Filter Primary.....	A-6010	Air Filter.....	A-3370
Oil Filter Combination.....	C-1112	Air Filter Secondary.....	A-5408	Fuel Filter.....	EF-1112
<b>BU102M</b> (TRUCKS) HINO 15BF , 1995		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1318
Air Filter.....	A-1112	Oil Filter Full Flow.....	O-1301	<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU308M , 4000, 2006-2009	
Oil Filter Combination.....	C-1112	Oil Filter By Pass.....	O-1310	Air Filter.....	A-3370
<b>BU107M</b> (TRUCKS) HINO 15BF , 1996-1999		<b>CM277</b> (TRUCKS) HINO EK200		Fuel Filter.....	EF-1112
Air Filter.....	A-1112	Air Filter Secondary.....	A-5408	Oil Filter Full Flow.....	C-1318
Oil Filter Combination.....	C-1112	Fuel Filter.....	F-1304	<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU314T , 4000, 2006-2011	
<b>BU137M</b> (TRUCKS) HINO 15BF , 1996		Oil Filter Full Flow.....	O-1301	Air Filter.....	A-3370
Air Filter.....	A-1112	<b>CN275</b> (TRUCKS) HINO EK200 , 1988		Fuel Filter.....	EF-1112
Oil Filter Combination.....	C-1112	Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1318
<b>BU162M</b> (TRUCKS) HINO 15BF , 1995-1999		Fuel Filter.....	F-1304	<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU324T , 4000, 2006-2009	
Air Filter.....	A-1112	Oil Filter By Pass.....	O-1310	Air Filter.....	A-3370
Oil Filter Combination.....	C-1112	<b>DRS121</b> (TRUCKS) HINO EF350 , 1980-1982		Fuel Filter.....	EF-1112
<b>BU212F</b> (TRUCKS) HINO 15BF , 1997		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1318
Air Filter.....	A-1112	Oil Filter Full Flow.....	O-13081	<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU334M , 4000, 2006-2010	
Oil Filter Combination.....	C-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRC600M , 2700, 2011		Air Filter.....	A-3370
<b>BU212M</b> (TRUCKS) HINO 15BF , 1997		Oil Filter Full Flow.....	EO-1102	Fuel Filter.....	EF-1112
Air Filter.....	A-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRC600X , 2700, 2011		<b>DUTRO</b> (TRUCKS) 4.0L N04C-T BDG-XZU334M , 4000, 2006-2010	
Oil Filter Combination.....	C-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRC600X , 2700, 2011		Air Filter.....	A-3370
<b>BU222M</b> (TRUCKS) HINO 15BFT , 1997		<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRC600X , 2700, 2011		Fuel Filter.....	EF-1112
Air Filter.....	A-1112	<b>DUTRO</b> (TRUCKS) 2.7L 2TR-FE ABG-TRC600X , 2700, 2011			





MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
DUTRO (TRUCKS) 4.0L N04C-T BJK-XKU508E , 4000, 2006-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU404M , 4000, 2010-2011		Air Filter.....	A-1143
Air Filter.....	A-3370	Air Filter Primary.....	A-1177	DUTRO (TRUCKS) 2.7L 3RZ-FE GE-RZU340M , 2700, 2000-2003	
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Air Filter.....	A-1143
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Fuel Filter.....	FS-1128
DUTRO (TRUCKS) 4.0L N04C-T BJK-XKU508M , 4000, 2006-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU414M , 4000, 2008-2011		DUTRO (TRUCKS) 3.7L 4B KK-BU301M , 3700, 1999-2004	
Air Filter.....	A-3370	Air Filter Primary.....	A-1177	Air Filter.....	A-1143
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	DUTRO (TRUCKS) 3.7L 4B KK-BU301X , 3700, 1999-2004	
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU304E , 4000, 2010-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU424M , 4000, 2008-2011		Air Filter.....	A-1143
Air Filter.....	A-3370	Air Filter Primary.....	A-1177	Oil Filter Combination.....	C-1112
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 3.7L 4B KK-BU306M , 3700, 1999-2004	
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU304M , 4000, 2009-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU454M , 4000, 2008-2011		Oil Filter Combination.....	C-1112
Air Filter.....	A-3370	Air Filter Primary.....	A-1177	DUTRO (TRUCKS) 3.7L 4B KK-BU306Y , 3700, 1999-2004	
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Air Filter.....	A-1143
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Oil Filter Combination.....	C-1112
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU308M , 4000, 2009-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU504M , 4000, 2008-2011		DUTRO (TRUCKS) 3.7L 4B KK-BU346M , 3700, 1999-2004	
Air Filter.....	A-3370	Air Filter.....	A-3370	Air Filter.....	A-1143
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	DUTRO (TRUCKS) 4.1L 15B-FTE KK-BU400M , 4100, 1999-2004	
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU324T , 4000, 2009-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU508M , 4000, 2008-2011		Air Filter Primary.....	A-1177
Air Filter.....	A-3370	Air Filter.....	A-3370	Oil Filter Combination.....	C-1112
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.1L 15B-FTE KK-BU410M , 4100, 1999-2004	
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Air Filter Primary.....	A-1177
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU334M , 4000, 2010-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU524T , 4000, 2008-2011		Oil Filter Combination.....	C-1112
Air Filter.....	A-3370	Air Filter.....	A-3370	DUTRO (TRUCKS) 4.1L 15B-FTE KK-BU420M , 4100, 1999-2004	
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Air Filter Primary.....	A-1177
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Oil Filter Combination.....	C-1112
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU338M , 4000, 2010-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU538M , 4000, 2008-2011		DUTRO (TRUCKS) 4.1L 15B-FTE KK-BU426M , 4100, 1999-2004	
Air Filter.....	A-3370	Air Filter.....	A-3370	Air Filter Primary.....	A-1177
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	DUTRO (TRUCKS) 4.1L 15B-FTE KK-BU430M , 4100, 1999-2004	
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU344M , 4000, 2010-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU548M , 4000, 2008-2011		Air Filter Primary.....	A-1177
Air Filter.....	A-3370	Air Filter.....	A-3370	Oil Filter Combination.....	C-1112
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 5.3L J05C KK-XZU300E , 5300, 2002-2004	
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU348M , 4000, 2010-2011		DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU554T , 4000, 2008-2011		Fuel Filter.....	FC-1302
Air Filter.....	A-3370	Air Filter.....	A-3370	Oil Filter Combination.....	C-1317
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1320
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1318	DUTRO (TRUCKS) 2.7L 3RZ-FE GE-RZU300M , 2700, 2000-2002	
DUTRO (TRUCKS) 4.0L N04C-T BKG-XZU354T , 4000, 2009-2011		DUTRO (TRUCKS) 2.7L 3RZ-FE GE-RZU300M , 2700, 2000-2002		Air Filter.....	A-1143
Air Filter.....	A-3370	Air Filter.....	A-1143	Fuel Filter.....	FC-1302
Fuel Filter.....	EF-1112	Fuel Filter.....	FS-1128	Oil Filter Combination.....	C-1321
Oil Filter Full Flow.....	C-1318	DUTRO (TRUCKS) 2.7L 3RZ-FPE GE-RZU300M , 2700, 2000-2002			

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
DUTRO (TRUCKS) 4.1L 15B-FP KK-XZU301E , 4100, 2002-2003 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU302E , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		Oil Filter Combination..... C-1320	
DUTRO (TRUCKS) 4.1L 15B-FP KK-XZU301E , 4100, 2000-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU302M , 4100, 2002-2003 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU307M , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301E , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU302M , 4100, 2001-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU307Y , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301E , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.1L 15B-CNG KK-XZU302M , 4100, 2000-2003 Air Filter..... A-1143 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU307Y , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301M , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		DUTRO (TRUCKS) 4.6L S05C KK-XZU302M , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		DUTRO (TRUCKS) 4.9L S05D KK-XZU311T , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301M , 4900, 2000-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.6L S05C KK-XZU302M , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.9L S05D KK-XZU311T , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301T , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		DUTRO (TRUCKS) 4.6L S05C KK-XZU302T , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		DUTRO (TRUCKS) 4.9L S05D KK-XZU311X , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301T , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.6L S05C KK-XZU302T , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.6L S05C KK-XZU312T , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	
DUTRO (TRUCKS) 4.1L 15B-FP KK-XZU301X , 4100, 2002-2003 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU302X , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		DUTRO (TRUCKS) 4.6L S05C KK-XZU312T , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.1L 15B-FP KK-XZU301X , 4100, 2000-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1112		DUTRO (TRUCKS) 4.6L S05C KK-XZU302X , 4600, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 5.3L J05C KK-XZU320X , 5300, 1999-2002 Air Filter..... A-1143 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301X , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		DUTRO (TRUCKS) 4.9L S05D KK-XZU306M , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		DUTRO (TRUCKS) 4.9L S05D KK-XZU321T , 4900, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	
DUTRO (TRUCKS) 4.9L S05D KK-XZU301X , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.9L S05D KK-XZU306M , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321		DUTRO (TRUCKS) 4.9L S05D KK-XZU321T , 4900, 1999-2002 Air Filter..... A-1143 Oil Filter Combination..... C-1321	
DUTRO (TRUCKS) 4.6L S05C KK-XZU302E , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		DUTRO (TRUCKS) 4.6L S05C KK-XZU307M , 4600, 2002-2004 Air Filter..... A-1143 Oil Filter Combination..... C-1317			

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
DUTRO (TRUCKS) 4.9L S05D KK-XZU321X , 4900, 1999-2002		Oil Filter Combination.....	C-1320	DUTRO (TRUCKS) 4.6L S05C KK-XZU347M , 4600, 1999-2002	
Air Filter.....	A-1143	DUTRO (TRUCKS) 5.3L J05C KK-XZU340M , 5300, 1999-2002		Air Filter.....	A-1143
Oil Filter Combination.....	C-1321	Air Filter.....	A-1143	Oil Filter Combination.....	C-1321
DUTRO (TRUCKS) 4.6L S05C KK-XZU322M , 4600, 2002-2004		Fuel Filter.....	FC-1302	DUTRO (TRUCKS) 5.3L J05C KK-XZU350E , 5300, 2002-2004	
Air Filter.....	A-1143	Oil Filter Combination.....	C-1321	Air Filter.....	A-1143
Oil Filter Combination.....	C-1320	DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU341M , 4100, 2002-2003		Fuel Filter.....	FC-1302
Oil Filter Combination.....	C-1317	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1317
DUTRO (TRUCKS) 4.6L S05C KK-XZU322M , 4600, 1999-2002		DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU341M , 4100, 2000-2002		Oil Filter Combination.....	C-1320
Air Filter.....	A-1143	Air Filter.....	A-1143	DUTRO (TRUCKS) 5.3L J05C KK-XZU350E , 5300, 1999-2002	
Oil Filter Combination.....	C-1321	Oil Filter Combination.....	C-1112	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.6L S05C KK-XZU322T , 4600, 2002-2004		DUTRO (TRUCKS) 4.9L S05D KK-XZU341M , 4900, 2002-2004		Fuel Filter.....	FC-1302
Air Filter.....	A-1143	Air Filter.....	A-1143	Oil Filter Combination.....	C-1321
Oil Filter Combination.....	C-1317	Oil Filter Combination.....	C-1320	DUTRO (TRUCKS) 4.9L S05D KK-XZU351T , 4900, 2002-2004	
Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1317	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.6L S05C KK-XZU322T , 4600, 1999-2002		DUTRO (TRUCKS) 4.9L S05D KK-XZU341M , 4900, 1999-2002		Oil Filter Combination.....	C-1320
Air Filter.....	A-1143	Air Filter.....	A-1143	Oil Filter Combination.....	C-1317
Oil Filter Combination.....	C-1321	Oil Filter Combination.....	C-1321	DUTRO (TRUCKS) 4.9L S05D KK-XZU351T , 4900, 1999-2002	
DUTRO (TRUCKS) 5.3L J05C KK-XZU330M , 5300, 2002-2004		DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU342M , 4100, 2002-2003		Air Filter.....	A-1143
Air Filter.....	A-1143	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1321
Fuel Filter.....	FC-1302	DUTRO (TRUCKS) 4.1L 15B-CNG KK-XZU342M , 4100, 2001-2003		DUTRO (TRUCKS) 4.6L S05C KK-XZU352T , 4600, 2002-2004	
Oil Filter Combination.....	C-1317	Air Filter.....	A-1143	Air Filter.....	A-1143
Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1317
DUTRO (TRUCKS) 5.3L J05C KK-XZU330M , 5300, 1999-2002		DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU342M , 4100, 2001-2002		Oil Filter Combination.....	C-1320
Air Filter.....	A-1143	Air Filter.....	A-1143	DUTRO (TRUCKS) 4.6L S05C KK-XZU362M , 4600, 2002-2004	
Fuel Filter.....	FC-1302	Oil Filter Combination.....	C-1112	Air Filter.....	A-1143
Oil Filter Combination.....	C-1321	DUTRO (TRUCKS) 4.6L S05C KK-XZU342M , 4600, 2002-2004		Oil Filter Combination.....	C-1320
DUTRO (TRUCKS) 4.9L S05D KK-XZU331M , 4900, 2002-2004		Air Filter.....	A-1143	Oil Filter Combination.....	C-1317
Air Filter.....	A-1143	Oil Filter Combination.....	C-1317	DUTRO (TRUCKS) 4.6L S05C KK-XZU362M , 4600, 1999-2002	
Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1320	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.9L S05D KK-XZU331M , 4900, 1999-2002		DUTRO (TRUCKS) 4.6L S05C KK-XZU342M , 4600, 2000-2002		Oil Filter Combination.....	C-1321
Air Filter.....	A-1143	Air Filter.....	A-1143	DUTRO (TRUCKS) 4.6L S05C KK-XZU362M , 4600, 2002-2004	
Oil Filter Combination.....	C-1321	Oil Filter Combination.....	C-1321	Air Filter.....	A-1143
DUTRO (TRUCKS) 4.6L S05C KK-XZU337M , 4600, 2002-2004		DUTRO (TRUCKS) 4.9L S05D KK-XZU346M , 4900, 2002-2004		Oil Filter Combination.....	C-1320
Air Filter.....	A-1143	Air Filter.....	A-1143	Oil Filter Combination.....	C-1317
Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1317	Oil Filter Combination.....	C-1320
Oil Filter Combination.....	C-1317	DUTRO (TRUCKS) 4.9L S05D KK-XZU346M , 4900, 1999-2002		DUTRO (TRUCKS) 4.6L S05C KK-XZU362T , 4600, 1999-2002	
DUTRO (TRUCKS) 4.6L S05C KK-XZU337M , 4600, 1999-2002		Air Filter.....	A-1143	Air Filter.....	A-1143
Air Filter.....	A-1143	Oil Filter Combination.....	C-1321	Oil Filter Combination.....	C-1317
Oil Filter Combination.....	C-1321	Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1320
DUTRO (TRUCKS) 5.3L J05C KK-XZU340M , 5300, 2002-2004		DUTRO (TRUCKS) 4.6L S05C KK-XZU347M , 4600, 2002-2004		DUTRO (TRUCKS) 4.6L S05C KK-XZU362X , 4600, 2002-2004	
Air Filter.....	A-1143	Air Filter.....	A-1143	Air Filter.....	A-1143
Fuel Filter.....	FC-1302	Oil Filter Combination.....	C-1320	Oil Filter Combination.....	C-1320
Oil Filter Combination.....	C-1317	Oil Filter Combination.....	C-1317	Oil Filter Combination.....	C-1317

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
DUTRO (TRUCKS) 4.6L S05C KK-XZU362X , 4600, 1999-2002	Air Filter..... A-1143 Oil Filter Combination..... C-1321	Oil Filter Combination..... C-1320		Oil Filter Combination..... C-1320	
DUTRO (TRUCKS) 4.9L S05D KK-XZU371M , 4900, 2002-2004	Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 5.3L J05C KK-XZU400X , 5300, 1999-2002	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.6L S05C KK-XZU412M , 4600, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321
DUTRO (TRUCKS) 4.9L S05D KK-XZU371M , 4900, 1999-2002	Air Filter..... A-1143 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.9L S05D KK-XZU401M , 4900, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317	DUTRO (TRUCKS) 5.3L J05C KK-XZU420M , 5300, 2002-2004	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320
DUTRO (TRUCKS) 4.6L S05C KK-XZU372M , 4600, 2002-2004	Air Filter..... A-1143 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 4.9L S05D KK-XZU401M , 4900, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 5.3L J05C KK-XZU420M , 5300, 1999-2002	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1321
DUTRO (TRUCKS) 4.6L S05C KK-XZU372M , 4600, 1999-2002	Air Filter..... A-1143 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.6L S05C KK-XZU402M , 4600, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317	DUTRO (TRUCKS) 4.9L S05D KK-XZU421M , 4900, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317
DUTRO (TRUCKS) 4.6L S05C KK-XZU382M<TC> , 4600, 2002-2004	Air Filter..... A-1143 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317	DUTRO (TRUCKS) 4.6L S05C KK-XZU402M , 4600, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.9L S05D KK-XZU421M , 4900, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321
DUTRO (TRUCKS) 4.6L S05C KK-XZU382M<TC> , 4600, 1999-2002	Air Filter..... A-1143 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 5.3L J05C KK-XZU410M , 5300, 2002-2004	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 5.3L J05C KK-XZU430M , 5300, 2002-2004	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320
DUTRO (TRUCKS) 4.6L S05C KK-XZU382M<WC> , 4600, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 4.9L S05D KK-XZU411M , 4900, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 4.1L 1BZ-FNE LD-BZU300M , 4100, 2003-2007	Air Filter..... A-1143 Oil Filter Combination..... C-1112
DUTRO (TRUCKS) 4.6L S05C KK-XZU382M<WC> , 4600, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.9L S05D KK-XZU411M , 4900, 1999-2002	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.1L 1BZ-FPE LD-BZU300M , 4100, 2003-2007	Oil Filter Combination..... C-1112
DUTRO (TRUCKS) 5.3L J05C KK-XZU400M , 5300, 2002-2004	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320	DUTRO (TRUCKS) 4.1L 15B-LPG KK-XZU412M , 4100, 2002-2003	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1112	DUTRO (TRUCKS) 4.1L 1BZ-FPE LD-BZU300X , 4100, 2003-2007	Air Filter..... A-1143 Oil Filter Combination..... C-1112
DUTRO (TRUCKS) 5.3L J05C KK-XZU400M , 5300, 1999-2002	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1321	DUTRO (TRUCKS) 4.1L 15B-CNG KK-XZU412M , 4100, 2000-2003	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1112	DUTRO (TRUCKS) 4.1L 1BZ-FPE LD-BZU300X , 4100, 2003-2007	Oil Filter Combination..... C-1112
DUTRO (TRUCKS) 5.3L J05C KK-XZU400X , 5300, 2002-2004	Air Filter Primary..... A-1177 Fuel Filter..... FC-1302 Oil Filter Combination..... C-1317	DUTRO (TRUCKS) 4.6L S05C KK-XZU412M , 4600, 2002-2004	Air Filter Primary..... A-1177 Oil Filter Combination..... C-1317	DUTRO (TRUCKS) 4.1L 1BZ-FPE LD-BZU340M , 4100, 2003-2007	Oil Filter Combination..... C-1112
				DUTRO (TRUCKS) 4.1L 1BZ-FNE LD-BZU340X , 4100, 2003-2007	Air Filter..... A-1143

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
4.1L 1BZ-FNE LD-BZU340X , 4100, 2003-2007		4.9L S05D PB-XZU301X , 4900, 2004-2006		4.9L S05D PB-XZU321T , 4900, 2004-2006	
Oil Filter Combination.....	C-1112	Air Filter.....	A-3370	Air Filter.....	A-3370
<b>DUTRO (TRUCKS)</b>		Fuel Filter.....		Fuel Filter.....	
4.1L 1BZ-FPE LD-BZU340X , 4100, 2003-2007		EF-1112		EF-1112	
Oil Filter Combination.....	C-1112	Oil Filter Combination.....		Oil Filter Combination.....	
<b>DUTRO (TRUCKS)</b>		C-1317		C-1320	
4.1L 1BZ-FNE LD-BZU410M , 4100, 2003-2007		C-1320		C-1317	
Air Filter Primary.....	A-1177	<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Oil Filter Combination.....	C-1112	4.0L N04C-T PB-XZU304E , 4000, 2003-2006		4.9L S05D PB-XZU331M , 4900, 2004-2006	
<b>DUTRO (TRUCKS)</b>		Air Filter.....		Air Filter.....	
4.1L 1BZ-FPE LD-BZU410M , 4100, 2003-2007		A-3370		A-3370	
Air Filter Primary.....	A-1177	Fuel Filter.....		Fuel Filter.....	
Oil Filter Combination.....	C-1112	EF-1112		EF-1112	
<b>DUTRO (TRUCKS)</b>		Oil Filter Combination.....		Oil Filter Combination.....	
4.1L 1BZ-FPE LD-RZU300M , 2700, 2003-2004		C-1317		C-1317	
Air Filter.....	A-1143	C-1320		C-1320	
Fuel Filter.....	FS-1128	Oil Filter Combination.....		Oil Filter Combination.....	
<b>DUTRO (TRUCKS)</b>		C-1317		C-1320	
2.7L 3RZ-FE LD-RZU300M , 2700, 2003-2004		<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Air Filter.....	A-1143	4.0L N04C-T PB-XZU304M , 4000, 2003-2006		4.0L N04C-A PB-XZU334M , 4000, 2004-2006	
Fuel Filter.....	FS-1128	Air Filter.....		Air Filter.....	
<b>DUTRO (TRUCKS)</b>		A-3370		A-3370	
2.7L 3RZ-FE LD-RZU340M , 2700, 2003-2004		Fuel Filter.....		Fuel Filter.....	
Air Filter.....	A-1143	EF-1112		EF-1112	
Fuel Filter.....	FS-1128	Oil Filter Combination.....		Oil Filter Combination.....	
<b>DUTRO (TRUCKS)</b>		C-1320		C-1320	
2.7L 3RZ-FE LD-RZU300M , 2700, 2003-2004		C-1317		C-1317	
Air Filter.....	A-1143	<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Fuel Filter.....	FS-1128	4.0L N04C-T PB-XZU304M , 4000, 2003-2006		4.0L N04C-T PB-XZU334M , 4000, 2004-2006	
<b>DUTRO (TRUCKS)</b>		Air Filter.....		Air Filter.....	
4.1L 1BZ-FPE NBG-BZU300M , 4100, 2007-2011		A-3370		A-3370	
Oil Filter Combination.....	C-1112	Fuel Filter.....		Fuel Filter.....	
<b>DUTRO (TRUCKS)</b>		EF-1112		EF-1112	
4.1L 1BZ-FPE NBG-BZU300X , 4100, 2007-2011		Oil Filter Combination.....		Oil Filter Combination.....	
Oil Filter Combination.....	C-1112	C-1320		C-1320	
<b>DUTRO (TRUCKS)</b>		C-1317		C-1320	
4.1L 1BZ-FPE NBG-BZU340M , 4100, 2007-2011		<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Oil Filter Combination.....	C-1112	4.9L S05D PB-XZU306M , 4900, 2004-2006		4.9L S05D PB-XZU336M , 4900, 2004-2006	
<b>DUTRO (TRUCKS)</b>		Air Filter.....		Air Filter.....	
4.1L 1BZ-FPE NBG-BZU600M , 4100, 2011		A-3370		A-3370	
Oil Filter Combination.....	C-1112	Fuel Filter.....		Fuel Filter.....	
<b>DUTRO (TRUCKS)</b>		EF-1112		EF-1112	
4.1L 1BZ-FPE NBG-BZU600X , 4100, 2011		Oil Filter Combination.....		Oil Filter Combination.....	
Oil Filter Combination.....	C-1112	C-1317		C-1317	
<b>DUTRO (TRUCKS)</b>		C-1320		C-1320	
4.1L 1BZ-FPE NBG-BZU301E , 4900, 2004-2006		<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Air Filter.....	A-3370	4.9L S05D PB-XZU306Y , 4900, 2004-2006		4.0L N04C-A PB-XZU338M , 4000, 2004-2006	
Fuel Filter.....	EF-1112	Air Filter.....		Air Filter.....	
Oil Filter Combination.....	C-1320	A-3370		A-3370	
Oil Filter Combination.....	C-1317	Fuel Filter.....		Fuel Filter.....	
<b>DUTRO (TRUCKS)</b>		EF-1112		EF-1112	
4.9L S05D PB-XZU301M , 4900, 2004-2006		Oil Filter Combination.....		Oil Filter Full Flow.....	
Air Filter.....	A-3370	C-1317		C-1318	
Fuel Filter.....	EF-1112	C-1320		C-1318	
Oil Filter Combination.....	C-1317	<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Oil Filter Combination.....	C-1320	4.0L N04C-A PB-XZU308M , 4000, 2004-2006		4.0L N04C-A PB-XZU338M , 4000, 2004-2006	
<b>DUTRO (TRUCKS)</b>		Air Filter.....		Air Filter.....	
4.9L S05D PB-XZU301T , 4900, 2004-2006		A-3370		A-3370	
Air Filter.....	A-3370	Fuel Filter.....		Fuel Filter.....	
Fuel Filter.....	EF-1112	EF-1112		EF-1112	
Oil Filter Combination.....	C-1317	Oil Filter Combination.....		Oil Filter Full Flow.....	
Oil Filter Combination.....	C-1320	C-1318		C-1318	
<b>DUTRO (TRUCKS)</b>		C-1317		C-1320	
4.9L S05D PB-XZU301M , 4900, 2004-2006		<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Air Filter.....	A-3370	4.0L N04C-A PB-XZU308Y , 4000, 2004-2006		4.0L N04C-T PB-XZU344M , 4000, 2003-2006	
Fuel Filter.....	EF-1112	Air Filter.....		Air Filter.....	
Oil Filter Combination.....	C-1317	A-3370		A-3370	
Oil Filter Combination.....	C-1320	Fuel Filter.....		Fuel Filter.....	
<b>DUTRO (TRUCKS)</b>		EF-1112		EF-1112	
4.9L S05D PB-XZU311T , 4900, 2004-2006		Oil Filter Combination.....		Oil Filter Combination.....	
Air Filter.....	A-3370	C-1317		C-1317	
Fuel Filter.....	EF-1112	C-1320		C-1320	
Oil Filter Combination.....	C-1317	C-1317		C-1320	
Oil Filter Combination.....	C-1320	<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
<b>DUTRO (TRUCKS)</b>		4.0L N04C-T PB-XZU311T , 4900, 2004-2006		4.9L S05D PB-XZU346M , 4900, 2004-2006	
4.9L S05D PB-XZU301T , 4900, 2004-2006		Air Filter.....		Air Filter.....	
Air Filter.....	A-3370	A-3370		A-3370	
Fuel Filter.....	EF-1112	Fuel Filter.....		Fuel Filter.....	
Oil Filter Combination.....	C-1317	EF-1112		EF-1112	
Oil Filter Combination.....	C-1320	Oil Filter Combination.....		Oil Filter Combination.....	
<b>DUTRO (TRUCKS)</b>		C-1317		C-1317	
4.9L S05D PB-XZU301T , 4900, 2004-2006		C-1320		C-1320	
Air Filter.....	A-3370	<b>DUTRO (TRUCKS)</b>		<b>DUTRO (TRUCKS)</b>	
Fuel Filter.....	EF-1112	4.0L N04C-T PB-XZU314T , 4000, 2004-2006		4.0L N04C-A PB-XZU348M , 4000, 2004-2006	
Oil Filter Combination.....	C-1320	Air Filter.....		Air Filter.....	
Oil Filter Combination.....	C-1317	A-3370		A-3370	
<b>DUTRO (TRUCKS)</b>		Fuel Filter.....		Fuel Filter.....	
4.9L S05D PB-XZU301T , 4900, 2004-2006		EF-1112		EF-1112	
Air Filter.....	A-3370	Oil Filter Combination.....		Oil Filter Full Flow.....	
Fuel Filter.....	EF-1112	C-1317		C-1318	
Oil Filter Combination.....	C-1320	C-1320		C-1318	
Oil Filter Combination.....	C-1317	C-1320		C-1318	









MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU600X , 4000, 2012		Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.0L N04C-T XZU605M , 4000, 2012	
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU645M , 4000, 2015		Fuel Filter.....	FC-13190
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T XZU655M , 4000, 2011	
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU605M , 4000, 2012		Oil Filter Full Flow.....	C-1328	Fuel Filter.....	FC-13190
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU650M , 4000, 2015		DUTRO (TRUCKS) 4.0L N04C-T XZU700X , 4000, 2011	
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	Fuel Filter.....	FC-13190
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU640M , 4000, 2012		Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.0L N04C-T XZU710M , 4000, 2011	
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU655M , 4000, 2015		Fuel Filter.....	FC-13190
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T XZU720M , 4000, 2011	
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU645M , 4000, 2012		Oil Filter Full Flow.....	C-1328	Fuel Filter.....	FC-13190
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU700M , 4000, 2015		DUTRO (TRUCKS) 4.0L N04C-T XZU730M , 4000, 2011	
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	Fuel Filter.....	FC-13190
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU650M , 4000, 2012		Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.0L N04C-T XZU700M , 4000, 2011	
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU710M , 4000, 2015		Fuel Filter.....	FC-13190
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T XZU730M , 4000, 2011	
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU655M , 4000, 2012		Oil Filter Full Flow.....	C-1328	Fuel Filter.....	FC-13190
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU720M , 4000, 2015		DUTRO (TRUCKS) 4.0L N04C-T XZU730M , 4000, 2011	
Oil Filter Full Flow.....	C-1318	Fuel Filter.....	EF-1112	Fuel Filter.....	FC-13190
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU710M , 4000, 2012		Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.0L N04C-T XZU730M , 4000, 2011	
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T VF-XKU304E , 4000, 2003-2006		Fuel Filter.....	FC-1301
Oil Filter Full Flow.....	C-1318	Air Filter.....	A-3370	Fuel/Water Separator.....	SF-28010
DUTRO (TRUCKS) 4.0L N04C-T TQG-XKU720M , 4000, 2012		Fuel Filter.....	EF-1112	FA (TRUCKS)	
Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1317	Fuel/Water Separator Primary.....	SFC-1306-30
Oil Filter Full Flow.....	C-1318	Oil Filter Combination.....	C-1320	Oil Filter Full Flow.....	C-1314
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKC605M , 4000, 2015		DUTRO (TRUCKS) 4.0L N04C-T VF-XKU344M , 4000, 2003-2006		FA14 (TRUCKS) HINO W04C , TO-1991	
Fuel Filter.....	EF-1112	Air Filter.....	A-3370	Coolant Filter.....	WC-5707
Oil Filter Full Flow.....	C-1328	Fuel Filter.....	EF-1112	Fuel Filter.....	FC-1305
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKC645M , 4000, 2015		Oil Filter Combination.....	C-1320	Fuel Filter Primary.....	FC-1310
Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1317	Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.0L N04C-T VF-XKU414M , 4000, 2003-2006		Oil Filter Full Flow.....	C-1309
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKC655M , 4000, 2015		Air Filter Primary.....	A-1177	Oil Filter Full Flow.....	C-5519
Fuel Filter.....	EF-1112	Fuel Filter.....	EF-1112	FA14 (TRUCKS) HINO W04CT , TO-1991	
Oil Filter Full Flow.....	C-1328	Oil Filter Combination.....	C-1320	Coolant Filter.....	WC-5707
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU600M , 4000, 2015		Oil Filter Combination.....	C-1317	Fuel Filter.....	FC-1305
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.0L N04C-T VF-XKU424M , 4000, 2003-2006		Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1328	Air Filter Primary.....	A-1177	Oil Filter Full Flow.....	C-1301
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU605M , 4000, 2015		Fuel Filter.....	EF-1112	Oil Filter Full Flow.....	C-1309
Fuel Filter.....	EF-1112	Oil Filter Combination.....	C-1320	Oil Filter Full Flow.....	C-5519
Oil Filter Full Flow.....	C-1328	Oil Filter Combination.....	C-1317	FA1415 (TRUCKS) HINO W04C-TH , TO-1997	
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU640M , 4000, 2015		DUTRO (TRUCKS) 4.6L S05C-TB XZU404 , 4600, 2003-2007		Air Filter Primary.....	A-5639
Fuel Filter.....	EF-1112	Fuel Filter.....	F-1110	Air Filter Set.....	A-5654-S
Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.6L S05C-TB XZU414 , 4600, 2003-2007		Fuel Filter Primary.....	FC-1310
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU640M , 4000, 2015		Fuel Filter.....	F-1110	Fuel Filter.....	FC-1305
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.6L S05C-TB XZU414 , 4600, 2003-2007		Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1328	Fuel Filter.....	F-1110	Oil Filter Full Flow.....	C-1309
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU605M , 4000, 2015		DUTRO (TRUCKS) 4.6L S05C-TB XZU414 , 4600, 2003-2007		Oil Filter Full Flow.....	C-5519
Fuel Filter.....	EF-1112	Fuel Filter.....	F-1110	FA1415 (TRUCKS) HINO W04C , TO-1997	
Oil Filter Full Flow.....	C-1328	DUTRO (TRUCKS) 4.6L S05C-TB XZU414 , 4600, 2003-2007		Air Filter Primary.....	A-5639
DUTRO (TRUCKS) 4.0L N04C-T TSG-XKU640M , 4000, 2015		Fuel Filter.....	F-1110	Air Filter Set.....	A-5654-S
Fuel Filter.....	EF-1112	DUTRO (TRUCKS) 4.6L S05C-TB XZU414 , 4600, 2003-2007			
Oil Filter Full Flow.....	C-1328	Fuel Filter.....	F-1110		

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FA1415 (TRUCKS)</b> HINO W04C , TO-1997	
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-5519
<b>FA15 (TRUCKS)</b> HINO W04C , 1992-1997	
Air Filter Primary.....	A-5639
Air Filter Set.....	A-5654-S
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-5519
<b>FA15 (TRUCKS)</b> HINO W04CT , 1992-1997	
Air Filter Primary.....	A-5639
Air Filter Set.....	A-5654-S
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-5519
<b>FA1517 (TRUCKS)</b> HINO J05C , 2004-UP	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S
Fuel/Water Separator Primary....	SFC-1306-30
Oil Filter Full Flow.....	C-1314
<b>FA1517 (TRUCKS)</b> HINO J05C-TD , 1999-UP	
Fuel/Water Separator Primary....	SFC-1306-30
Oil Filter Full Flow.....	C-1314
<b>FA1517 (TRUCKS)</b> HINO J05C , 1998-2003	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	C-5519
<b>FA1817 (TRUCKS)</b> HINO J08C , 2004-UP	
Air Filter Primary.....	A-1156
Air Filter Primary.....	A-5020
Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	C-1314
<b>FA4J (TRUCKS)</b> HINO J05C , 2004-UP	
Air Filter Primary.....	A-1156
Air Filter Primary.....	A-5020
Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	C-1314
<b>FA4J (TRUCKS)</b> HINO J05C , 1998-2003	

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	C-1314
<b>FB111 (TRUCKS)</b> HINO W04D , 1984	
Air Filter.....	A-1308
Fuel Filter.....	FC-1302
<b>FB1715 (TRUCKS)</b> HINO W04C-TH , 1993-1997	
Air Filter Primary.....	A-5639
Air Filter Set.....	A-5654-S
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-5519
<b>FB1715 (TRUCKS)</b> HINO W04C , 1993-1997	
Air Filter Primary.....	A-5639
Air Filter Set.....	A-5654-S
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-5519
<b>FB1817 (TRUCKS)</b> HINO J05C , 1998-2003	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	C-5519
<b>FB2W (TRUCKS)</b> HINO W04D	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1302
<b>FB2W (TRUCKS)</b> HINO W04D-T S/N: 114HP-UP	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1302
<b>FB4J (TRUCKS)</b> HINO J05C , 1998-2003	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S
Fuel/Water Separator Primary....	SFC-1306-30
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	C-5519
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J05D-T ADG-FC6J , FC, 2005-2006	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
Oil Filter Full Flow.....	C-1325
Oil Filter Combination.....	C-1304

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FC7J , FC, 2005-2006	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
Oil Filter Combination.....	C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C ADG-FC7J , FC, 2005-2006	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FD7J , FD, 2005-2006	
Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
Oil Filter Combination.....	C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FD7J<DC> , FD, 2005-2006	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Oil Filter Combination.....	C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FD7J<SC> , FD, 2005-2006	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S
Oil Filter Combination.....	C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T ADG-FD8J , FD, 2005-2006	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FE7J , FE, 2005-2006	
Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
Oil Filter Combination.....	C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T ADG-FE8J , FE, 2005-2006	
Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T ADG-FG8J , FG, 2005-2006	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T ADG-FG8J , FG, 2005-2006	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FD7J<DC> , FD, 2006-2007	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1319	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Air Filter Set..... A-6118-S Oil Filter Combination..... C-1319	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FJ7J , FJ, 2005-2006	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FD7J<SC> , FD, 2006-2007	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J05D-T BJG-FC6J , FC, 2008-2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1304 Oil Filter Full Flow..... C-1325
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T ADG-FT8J , FT, 2005-2006	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T BDG-FD8J , FD, 2006-2010	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BKG-FC7J , FC, 2007-2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T ADG-FX7J , FX, 2005-2006	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Primary..... A-60400 Air Filter Primary..... A-6006 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Air Filter Set..... A-6118-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FE7J , FE, 2006-2010	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BKG-FD7J , FD, 2007-2011	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J05D-T BDG-FC6J , FC, 2006-2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1304 Oil Filter Full Flow..... C-1325	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T BDG-FE8J , FE, 2006-2010	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Primary..... A-60400 Air Filter Primary..... A-6006 Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Air Filter Set..... A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BKG-FD7J<DC> , FD, 2007-2011	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FC7J , FC, 2006-2007	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T BDG-FG8J , FG, 2006-2010	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BKG-FD7J<SC> , FD, 2007-2011	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C BDG-FC7J , FC, 2006-2007	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FJ7J , FJ, 2006-2010	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> W04C-T HF-FC1JWJCH , FC, 2000-2003	Air Filter..... A-1311 Fuel Filter..... FC-1301 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FD7J , FD, 2006-2007	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T BDG-FT8J , FT, 2006-2010	Air Filter Primary..... A-60400 Air Filter Primary..... A-6006 Air Filter Set..... A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> 15B KC-FB4J , FB, 1997-1999	Air Filter Primary..... A-1327 Air Filter Set..... A-1329-S Oil Filter Combination..... C-1112
		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T BDG-FX7J , FX, 2006-2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J05C KC-FB4J , FB, 1995-1999	Air Filter Primary..... A-1327 Air Filter Set..... A-1329-S Fuel Filter..... FC-1302 Oil Filter Full Flow..... C-1301





# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07C-T KK-FC5J , FC, 2001-2004		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FE1J{10224-} , FE, 2001-2002		Air Filter Primary.....	A-6006
Air Filter Primary.....	A-1324	Air Filter.....	A-1322	Air Filter Set.....	A-6118-S
Air Filter Primary.....	A-1324M	Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1J#E , FE, 2001-2004	
Air Filter Set.....	A-1324-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07C-T KK-FJ5J , FJ, 2002-2004		Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324
Oil Filter Combination.....	C-1319	Air Filter Primary.....	A-1324M	Air Filter Set.....	A-1324M-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FD1J , FD, 2001-2001		Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S
Air Filter.....	A-1311	Air Filter Set.....	A-1324M-S	Fuel Filter.....	FC-1301
Air Filter.....	A-1322	Oil Filter Combination.....	C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FE1J#E , FE, 2001-2004	
Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FT1J , FT, 2001-2001		Air Filter Primary.....	A-1324M
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KK-FD1J , FD, 2001-2001		Air Filter Primary.....	A-6006	Air Filter Primary.....	A-1324
Air Filter.....	A-1322	Air Filter Primary.....	A-60400	Air Filter Set.....	A-1324M-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FD1J , FD, 1999-2001		Air Filter.....	A-1322	Air Filter Set.....	A-1324-S
Air Filter.....	A-1322	Air Filter Set.....	A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1J{-10198} , FE, 1999-2001	
Air Filter.....	A-1311	Fuel Filter.....	FC-1301	Air Filter.....	A-1322
Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FT1J , FT, 1999-2001		Fuel Filter.....	FC-1301
Oil Filter Combination.....	C-1315	Air Filter.....	A-1322	Oil Filter Combination.....	C-1315
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KK-FD1J , FD, 1999-2001		Air Filter Primary.....	A-6006	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FE1J{-10198} , FE, 1999-2001	
Air Filter.....	A-1322	Air Filter Primary.....	A-60400	Air Filter.....	A-1322
Oil Filter Combination.....	C-1315	Air Filter Set.....	A-6118-S	Oil Filter Combination.....	C-1315
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FD1J#E , FD, 2001-2005		Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1J{10199-} , FE, 2001-2001	
Air Filter Primary.....	A-1324	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FX1J#E , FX, 2002-2004		Air Filter.....	A-1322
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-60400	Fuel Filter.....	FC-1301
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-6006	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FE1J{10199-} , FE, 2001-2001	
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-6118-S	Air Filter.....	A-1322
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1315
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KK-FD1J#E , FD, 2001-2005		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FX1J#E , FX, 2001-2004		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1JGDE{10199-} , FE, 2001-2001	
Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324M	Air Filter.....	A-1322
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324	Oil Filter Combination.....	C-1315
Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1JGDE{10199-} , FE, 2001-2001	
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324M-S	Air Filter.....	A-1322
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FG1J#E , FG, 2002-2004	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FD1J#E<DC> , FD, 2002-2005		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FX1J{-10068} , FX, 1999-2001		Air Filter Primary.....	A-6006
Air Filter Primary.....	A-6006	Air Filter.....	A-1322	Air Filter Primary.....	A-60400
Air Filter Primary.....	A-60400	Fuel Filter.....	FC-1301	Air Filter Set.....	A-6118-S
Air Filter Set.....	A-6118-S	Oil Filter Combination.....	C-1315	Air Filter Set.....	A-6118-S
Fuel Filter.....	FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FX1J{10069-} , FX, 2001-2001		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FG1J#E , FG, 2001-2004	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FD1J#E<SC> , FD, 2001-2005		Air Filter.....	A-1322	Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324	Fuel Filter.....	FC-1301	Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324M	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FE1J#E , FE, 2002-2004		Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-6006	Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-60400	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FG1J{-10043} , FG, 1999-2001	
Fuel Filter.....	FC-1301	Air Filter Set.....	A-6118-S	Air Filter.....	A-1322
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KK-FE1J{-10223} , FE, 1999-2001		Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1315
Air Filter.....	A-1311	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FE1J#E , FE, 2002-2004		<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FG1J{10044-} , FG, 2001-2001	
Air Filter.....	A-1322	Air Filter Primary.....	A-60400	Air Filter.....	A-1322
Fuel Filter.....	FC-1301	Air Filter Set.....	A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C-T KL-FG1J{10044-} , FG, 2001-2001	
Oil Filter Combination.....	C-1315	Fuel Filter.....	FC-1301	Air Filter.....	A-1322

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FG1J{-10062} , FG, 1999-2001	Air Filter Primary..... A-60400 Air Filter Primary..... A-6006 Air Filter Set..... A-6118-S Fuel Filter..... FC-1301 Oil Filter Combination..... C-1315	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S		Oil Filter Full Flow..... C-1325	
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FG1J{10063-} , FG, 2001-2001	Air Filter Primary..... A-60400 Air Filter Primary..... A-6006 Air Filter Set..... A-6118-S Fuel Filter..... FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T KS-FJ7J , FJ, 2004-2005	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T PB-FC7J , FC, 2003-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FJ1J#E , FJ, 2001-2004	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Fuel Filter..... FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T LDG-FE7J , FE, 2010	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T PB-FD7J , FD, 2003-2005	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FJ1J{-10027} , FJ, 1999-2001	Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Fuel Filter..... FC-1301 Oil Filter Combination..... C-1315	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T LDG-FG8J , FG, 2010	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T PB-FD8J , FD, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FJ1J{10028-} , FJ, 2001-2001	Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Fuel Filter..... FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T LDG-FJ7J , FJ, 2010	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T PB-FT8J , FT, 2004-2005	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FJ1J{-10127} , FJ, 1999-2001	Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Fuel Filter..... FC-1301 Oil Filter Combination..... C-1315	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T LDG-FT8J , FT, 2010	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T PB-FX7J , FX, 2004-2005	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Air Filter Set..... A-6118-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08C KL-FJ1J{10128-} , FJ, 2001-2001	Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Fuel Filter..... FC-1301	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T LKG-FE7J , FE, 2010-2012	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T PK-FE7J , FE, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T KS-FE7J , FE, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J07E-T LKG-FJ7J , FJ, 2010-2012	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T PK-FE8J , FE, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-6006 Air Filter Primary..... A-1324M Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S
<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T KS-FE8J , FE, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J05D-T PB-FC6J , FC, 2003-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1304	<b>FB-FC-FD-FE-FF-FG-FT-FX-FJ RANGER (TRUCKS)</b> J08E-T PK-FG8J , FG, 2004-2005	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S



# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FC110</b> (TRUCKS) HINO W04D-T		Air Filter Primary.....	A-1324	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1302	Air Filter Primary.....	A-1324M	<b>FD120</b> (TRUCKS) HINO EC100 , 1980-1983	
<b>FC111</b> (TRUCKS) HINO W04D , 1984		Air Filter Set.....	A-1324M-S	Fuel Filter.....	F-1303
Air Filter.....	A-1308	Air Filter Secondary.....	A-1326	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1302	Fuel/Water Separator Primary....	SFC-1306-30	<b>FD150</b> (TRUCKS) HINO EH500 , 1980-1983	
<b>FC14</b> (TRUCKS) HINO W06D , 1984-1990		Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1303
Air Filter.....	A-1305	Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1302	<b>FC4J</b> (TRUCKS) HINO J08C , 1995		<b>FD150T</b> (TRUCKS) HINO H06C-T , 1982-1983	
<b>FC141</b> (TRUCKS) HINO W06D , 1984-1987		Air Filter Primary.....	A-1156	Air Filter Primary.....	A-6006
Air Filter.....	A-1305	Air Filter Set.....	A-1156-S	Air Filter Primary.....	A-60400
Fuel Filter.....	F-1303	Oil Filter Combination.....	C-1303	Air Filter Set.....	A-6118-S
Oil Filter Full Flow.....	O-1314	<b>FC4J</b> (TRUCKS) HINO J05C , 1995		Fuel Filter.....	F-1303
<b>FC142</b> (TRUCKS) HINO W06D , 1985-1995		Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	O-1301
Air Filter.....	A-1305	Oil Filter Full Flow.....	C-1309	<b>FD16</b> (TRUCKS) HINO W06E , 1986-1989	
Fuel Filter.....	F-1303	<b>FC4J</b> (TRUCKS) HINO J05CTI		Air Filter.....	A-1306
Oil Filter Full Flow.....	O-1314	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	C-1301
<b>FC144</b> (TRUCKS) HINO W06D , 1985		<b>FD</b> (TRUCKS) HINO EH700		Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1303	Air Filter.....	AS-1303	<b>FD16</b> (TRUCKS) HINO H06C , 1986-1989	
Oil Filter Full Flow.....	O-1314	<b>FD</b> (TRUCKS)		Air Filter Primary.....	A-6006
<b>FC17</b> (TRUCKS) HINO H07C , 1986-1990		Air Filter.....	A-1334	Air Filter Primary.....	A-60400
Air Filter.....	A-1306	<b>FD17</b> (TRUCKS) HINO H07C , 1989-UP		Air Filter Set.....	A-6118-S
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-1313	Oil Filter Combination.....	C-1303
Oil Filter Full Flow.....	C-1309	Air Filter Secondary.....	A-1307	<b>FD16</b> (TRUCKS) HINO H06C , 1983-1986	
<b>FC17</b> (TRUCKS) HINO H07C , 1984-1986		Air Filter Set.....	A-5662-S	Air Filter Primary.....	A-6006
Air Filter.....	A-1306	Coolant Filter.....	WC-5707	Air Filter Primary.....	A-60400
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	FC-1305	Air Filter.....	A-1306
<b>FC170</b> (TRUCKS) HINO H07C , 1984-1986		Fuel Filter Primary.....	FC-1310	Air Filter Set.....	A-6118-S
Air Filter.....	A-1306	Oil Filter Full Flow.....	C-5519	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301	<b>FD17</b> (TRUCKS) HINO H07C , 1989		Oil Filter By Pass.....	O-1319
<b>FC1JCD</b> (TRUCKS) HINO J08C , 1999-2001		Fuel Filter.....	FC-1312	Oil Filter Full Flow.....	O-1301
Air Filter Primary.....	A-1156	<b>FD17</b> (TRUCKS) HINO H07C , 1986-1989		<b>FD16</b> (TRUCKS) HINO W06E	
Air Filter Set.....	A-1156-S	Air Filter.....	A-1306	Air Filter.....	A-1306
<b>FC1W</b> (TRUCKS) HINO W04D , 2000		Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-60400	<b>FD16</b> (TRUCKS) HINO W06E 6 CYL. DIESEL	
Oil Filter Full Flow.....	C-1309	Air Filter Set.....	A-6118-S	Air Filter Primary.....	A-1313
<b>FC3J</b> (TRUCKS) HINO J07C , 1995-UP		Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-5662-S
Air Filter Primary.....	A-1156	Oil Filter Full Flow.....	C-1309	Air Filter Secondary.....	A-1307
Air Filter Set.....	A-1156-S	<b>FD17</b> (TRUCKS) HINO H07C , 1983-1986		Coolant Filter.....	WC-5707
Fuel/Water Separator Primary....	SFC-1306-30	Air Filter.....	A-1306	Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-6006	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	C-5519
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		Air Filter Set.....	A-6118-S	<b>FD160</b> (TRUCKS) HINO H06C-T , 1983-1986	
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		Fuel Filter.....	F-1303	Fuel Filter.....	F-1303
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		<b>FD17</b> (TRUCKS) HINO EH700		<b>FD160T</b> (TRUCKS) HINO H06C-T , 1986-UP	
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		Air Filter.....	AS-1303	Air Filter Primary.....	A-6006
<b>FC4J</b> (TRUCKS) HINO J05CT , 2003-2008		Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FD160T</b> (TRUCKS) HINO H06C-T , 1986-UP Air Filter Set.....	A-6118-S	<b>FD174</b> (TRUCKS) HINO EH700 , 1983-1986 Air Filter.....	AS-1303	<b>FD20</b> (TRUCKS) HINO H06C-TI , 1992 Fuel Filter.....	FC-1312
<b>FD160T</b> (TRUCKS) HINO H06C-T , 1983-1986 Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303	<b>FD2218</b> (TRUCKS) HINO H06C , 1993-1997 Air Filter.....	A-1334
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	O-1301	Fuel Filter.....	FC-1305
Air Filter Set.....	A-6118-S	<b>FD176</b> (TRUCKS) HINO EH700 , 1983-UP Air Filter.....	AS-1303	Fuel Filter.....	FC-1312
Fuel Filter.....	F-1303	Fuel Filter.....	F-1303	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-5519
<b>FD164</b> (TRUCKS) HINO W06E , 1987-1995 Air Filter.....	A-1306	<b>FD1H</b> (TRUCKS) HINO H06C , 1989-1994 Oil Filter Combination.....	C-1303	<b>FD2218</b> (TRUCKS) HINO H06C-TP Air Filter.....	A-1334
Oil Filter Full Flow.....	C-1301	<b>FD1J</b> (TRUCKS) HINO J08C , 1994-1999 Air Filter.....	A-1310	Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-6006	Fuel Filter.....	FC-1312
<b>FD164</b> (TRUCKS) HINO W06E , 1987 Air Filter.....	A-1306	Air Filter Primary.....	A-60400	Fuel Filter Primary.....	FC-1310
Fuel Filter.....	F-1303	Air Filter Set.....	A-6118-S	<b>FD2218LP</b> (TRUCKS) HINO H06C , 1993-1997 Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-1301	Oil Filter Combination.....	C-1303	<b>FD2220</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter.....	A-1334
Oil Filter Full Flow.....	C-1309	<b>FD1J</b> (TRUCKS) HINO J08CT , 1994-1999 Oil Filter Combination.....	C-1303	Fuel Filter.....	FC-1312
<b>FD164LA</b> (TRUCKS) HINO W06E , 1987-1988 Air Filter.....	A-1306	<b>FD1J</b> (TRUCKS) HINO J08C , 1991-1994 Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	C-1314
Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	C-5519
Oil Filter Full Flow.....	C-1301	Air Filter.....	A-1310	<b>FD2J</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter.....	A-1334
Oil Filter Full Flow.....	C-1309	Air Filter Set.....	A-6118-S	Fuel Filter.....	FC-1312
<b>FD170</b> (TRUCKS) HINO H07C , 1983-1986 Fuel Filter.....	F-1303	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	O-1301	<b>FD1W</b> (TRUCKS) HINO W06E , 1989 Air Filter.....	A-1306	Oil Filter Full Flow.....	C-5519
<b>FD170</b> (TRUCKS) HINO EH700 , 1980-1983 Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-1301	<b>FD2J</b> (TRUCKS) HINO J08C , 1989-1994 Air Filter Primary.....	A-6006
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-60400
<b>FD171</b> (TRUCKS) HINO TSH07C , 1987-1992 Air Filter.....	A-1306	<b>FD1JLUA</b> (TRUCKS) HINO J08C-F (S/N: F26393) Air Filter Primary.....	A-1324	Air Filter Set.....	A-6118-S
Air Filter.....	AS-1303	Air Filter Primary.....	A-1324M	Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-1324M-S	Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	C-1309	Air Filter Secondary.....	A-1326	Oil Filter Combination.....	C-1303
<b>FD171</b> (TRUCKS) HINO TSH07C , 1982-1987 Fuel Filter.....	F-1301	<b>FD20</b> (TRUCKS) HINO H06C , 1992-UP Air Filter.....	A-1334	<b>FD2320DH</b> (TRUCKS) HINO J08C , 2004-UP Air Filter Primary.....	A-1156
Fuel Filter.....	F-1303	Fuel Filter.....	FC-1305	Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	O-1301	Fuel Filter Primary.....	FC-1310	Oil Filter Full Flow.....	C-1314
<b>FD171</b> (TRUCKS) HINO EH700 Air Filter.....	AS-1303	Oil Filter Full Flow.....	C-5519	Oil Filter Transmission.....	TC-7901
Fuel Filter.....	F-1303	<b>FD20</b> (TRUCKS) HINO H06C-TI , 1992-UP Coolant Filter.....	WC-5707	<b>FD2320LP</b> (TRUCKS) HINO J08C , 2004-UP Air Filter.....	A-1334
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	C-1314
<b>FD171</b> (TRUCKS) HINO EH700 Air Filter.....	AS-1303	Fuel Filter Primary.....	FC-1310	Oil Filter Transmission.....	TC-7901
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-5519	<b>FD2H</b> (TRUCKS) HINO H07C , 1989-1994 Oil Filter Combination.....	C-1303
Oil Filter Full Flow.....	O-1301	<b>FD20</b> (TRUCKS) HINO H06C , 1992 Fuel Filter.....	FC-1312	<b>FD2JE</b> (TRUCKS) HINO J08CA , 1989-1994 Oil Filter Combination.....	C-1303

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FD3H (TRUCKS)</b> HINO H07D , 1989-1994	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Oil Filter Combination.....	C-1303
<b>FD3W (TRUCKS)</b> HINO W06E , 1989-1994	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>FD5H (TRUCKS)</b> HINO H06C , 1993-1997	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FE (TRUCKS)</b> HINO H07C	
Air Filter Primary.....	A-1313
Air Filter Set.....	A-5662-S
Air Filter Secondary.....	A-1307
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
<b>FE17 (TRUCKS)</b> HINO H07C , 1984-1991	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-5519
<b>FE19 (TRUCKS)</b> HINO H07C , 1984-1991	
Air Filter Primary.....	A-1313
Air Filter Set.....	A-5662-S
Air Filter Secondary.....	A-1307
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-5519
<b>FE16 (TRUCKS)</b> HINO W06E , 1986-1987	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-5519
<b>FE1J (TRUCKS)</b> HINO J08C , 1996-1999	
Air Filter Primary.....	A-6006

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Oil Filter Combination.....	C-1303
<b>FE20 (TRUCKS)</b> HINO H06C , 1992-UP	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FE20 (TRUCKS)</b> HINO H06C , 1992	
Fuel Filter.....	FC-1312
<b>FE20 (TRUCKS)</b> HINO H06C-TI	
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FE2618 (TRUCKS)</b> HINO H06C , 1993-1997	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FE2620 (TRUCKS)</b> HINO J08C-TP , 1999-UP	
Oil Filter Full Flow.....	C-1314
<b>FE2620 (TRUCKS)</b> HINO J08C , 1998-2004	
Air Filter.....	A-1334
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	C-5519
<b>FE2J (TRUCKS)</b> HINO J08C , 1998-2004	
Air Filter.....	A-1334
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-1314
Oil Filter Full Flow.....	C-5519
<b>FE5H (TRUCKS)</b> HINO H06C , 1993-1997	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FF (TRUCKS)</b> HINO H07C	
Fuel Filter.....	FC-1312
<b>FF17 (TRUCKS)</b> HINO H07C , 1989	
Fuel Filter.....	FC-1312
<b>FF17 (TRUCKS)</b> HINO H07C , 1986-1989	
Fuel Filter.....	FC-1312

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter.....	A-1306
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>FF17 (TRUCKS)</b> HINO H07C , 1983-1986	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FF19 (TRUCKS)</b> HINO H07C , 1984-1991	
Air Filter Primary.....	A-1313
Air Filter Set.....	A-5662-S
Air Filter Secondary.....	A-1307
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FF19 (TRUCKS)</b> HINO H06C-T	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>FF172 (TRUCKS)</b> HINO H07C , 1987	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FF172 (TRUCKS)</b> HINO EH700 , 1983-1986	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FF177 (TRUCKS)</b> HINO H07C	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FF192 (TRUCKS)</b> HINO H06C-T , 1986-UP	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303
Oil Filter By Pass.....	O-1319
<b>FF192 (TRUCKS)</b> HINO H06C-T	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303
Oil Filter By Pass.....	O-1319
Oil Filter Combination.....	C-1303



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FF192</b> (TRUCKS) HINO H06C-TB		<b>FF2618</b> (TRUCKS) HINO H06C-TP		Air Filter.....	A-1310
Air Filter Primary.....	A-6006	Air Filter Primary.....	A-5639	Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400	Air Filter.....	A-1334	Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S	Air Filter Set.....	A-5654-S	Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303	Fuel Filter.....	FC-1305	Oil Filter Combination.....	C-1303
Oil Filter Combination.....	C-1303	Fuel Filter.....	FC-1312		
Oil Filter By Pass.....	O-1319	Fuel Filter Primary.....	FC-1310		
				<b>FF4H</b> (TRUCKS) HINO H06C	
<b>FF192LD</b> (TRUCKS) HINO H06C-T , 1987-UP		<b>FF2J</b> (TRUCKS) HINO J08C , 1998-2003		Air Filter.....	A-1334
Air Filter Primary.....	A-6006	Air Filter.....	A-1334	Fuel Filter.....	FC-1305
Air Filter Primary.....	A-60400	Fuel Filter.....	FC-1312	Fuel Filter.....	FC-1312
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	C-1314	Fuel Filter Primary.....	FC-1310
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-5519	Oil Filter Full Flow.....	C-5519
Oil Filter Combination.....	C-1303				
		<b>FF2H</b> (TRUCKS) HINO H07CT , 1989-1994		<b>FFC1</b> (TRUCKS) CUMMINS 6BT5.9 , 1989-1999	
<b>FF1J</b> (TRUCKS) HINO J08C , 1994-1999		Air Filter.....	A-1310	Air Filter Primary.....	A-1313
Oil Filter Combination.....	C-1303	Oil Filter Combination.....	C-1303	Air Filter Set.....	A-5662-S
				Air Filter Secondary.....	A-1307
<b>FF1J</b> (TRUCKS) HINO J08CT		<b>FF3018</b> (TRUCKS) HINO H06C , 1993-1997		Fuel/Water Separator.....	SFC-5708
Air Filter Primary.....	A-6006	Air Filter.....	A-1334	Oil Filter Full Flow.....	C-5704
Air Filter Primary.....	A-60400	Fuel Filter.....	FC-1305		
Air Filter Set.....	A-6118-S	Fuel Filter.....	FC-1312	<b>FFC1</b> (TRUCKS) CUMMINS 6BT5.9 , 1987-1988	
Air Filter Secondary.....	A-6007	Fuel Filter Primary.....	FC-1310	Air Filter Primary.....	A-1313
Fuel/Water Separator Primary.....	SFC-1306-30	Oil Filter Full Flow.....	C-5519	Air Filter Secondary.....	A-1307
Oil Filter Combination.....	C-1303			Air Filter Set.....	A-5662-S
		<b>FF3018</b> (TRUCKS) HINO H06C-TP		Coolant Filter.....	WC-5708
<b>FF20</b> (TRUCKS) HINO H06C , 1992-UP		Fuel Filter.....	FC-1312	Fuel/Water Separator.....	SFC-5708
Air Filter.....	A-1334			Oil Filter Full Flow.....	C-5704
Fuel Filter.....	FC-1305	<b>FF3018</b> (TRUCKS) HINO J08C-TP			
Fuel Filter Primary.....	FC-1310	Air Filter.....	A-1334	<b>FFD17</b> (TRUCKS) HINO H07C , 1983-1986	
Oil Filter Full Flow.....	C-5519	Fuel Filter.....	FC-1305	Air Filter.....	A-1306
		Fuel Filter.....	FC-1312	Air Filter Primary.....	A-6006
<b>FF20</b> (TRUCKS) HINO H06C , 1992		Fuel Filter Primary.....	FC-1310	Air Filter Primary.....	A-60400
Fuel Filter.....	FC-1312			Air Filter Set.....	A-6118-S
		<b>FF3020</b> (TRUCKS) HINO J08C , 1998-2003		Fuel Filter.....	F-1303
<b>FF20</b> (TRUCKS) HINO H06C-TI		Air Filter.....	A-1334	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1312	Fuel Filter.....	FC-1312		
		Oil Filter Full Flow.....	C-1314	<b>FFS1F</b> (TRUCKS) HINO F17D , 1989-1992	
<b>FF23</b> (TRUCKS) HINO H06C , 1992-UP		Oil Filter Full Flow.....	C-5519	Fuel Filter.....	F-1304
Air Filter.....	A-1334			Oil Filter Full Flow.....	O-13081
Fuel Filter.....	FC-1305	<b>FF3020</b> (TRUCKS) HINO H06C-TN , 1993-1997		Oil Filter By Pass.....	O-1310
Fuel Filter Primary.....	FC-1310	Air Filter.....	A-1334		
Oil Filter Full Flow.....	C-5519	Air Filter Primary.....	A-5639	<b>FFS1F</b> (TRUCKS) HINO F17D	
		Air Filter Set.....	A-5654-S	Fuel Filter.....	F-1304
<b>FF23</b> (TRUCKS) HINO H06C , 1992		Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	O-1310
Fuel Filter.....	FC-1312	Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	O-13081
		Fuel Filter.....	FC-1312		
<b>FF23</b> (TRUCKS) HINO H06C-TH , 1992				<b>FG19</b> (TRUCKS) HINO H06C-T , 1986-1989	
Air Filter.....	A-1334	<b>FF3020</b> (TRUCKS) HINO J08C-TP		Air Filter Primary.....	A-6006
Coolant Filter.....	WC-5707	Fuel Filter.....	FC-1312	Air Filter Primary.....	A-60400
Fuel Filter.....	FC-1305			Air Filter Set.....	A-6118-S
Fuel Filter.....	FC-1312	<b>FF3H</b> (TRUCKS) HINO H07D , 1989-1994		Oil Filter Combination.....	C-1303
Fuel Filter Primary.....	FC-1310				
Oil Filter Full Flow.....	C-5519			<b>FG19</b> (TRUCKS) HINO H06C , 1984-1985	
				Air Filter Primary.....	A-1313
				Air Filter Set.....	A-5662-S
				Air Filter Secondary.....	A-1307
				Fuel Filter Primary.....	FC-1310
				Fuel Filter.....	FC-1305

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FG19</b> (TRUCKS) HINO H06C , 1984-1985	
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-5519
<b>FG19</b> (TRUCKS) HINO H06C-T , 1983-1986	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303
Oil Filter By Pass.....	O-1319
<b>FG19</b> (TRUCKS) HINO H06C-T	
Fuel Filter.....	FC-1312
<b>FG172LD</b> (TRUCKS) HINO H07C , 1988	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>FG175</b> (TRUCKS) HINO H07C	
Air Filter.....	A-1306
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>FG180</b> (TRUCKS) HINO EL100 , 1980-1983	
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FG1H</b> (TRUCKS) HINO H06C-TI , 1989-1994	
Oil Filter Combination.....	C-1303
<b>FG1H</b> (TRUCKS) HINO H06C-T , 1989	
Air Filter.....	A-1310
Oil Filter Combination.....	C-1303
<b>FG1J</b> (TRUCKS) HINO J08CT , 1994-1999	
Oil Filter Combination.....	C-1303
<b>FG1J</b> (TRUCKS) HINO J08C	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Air Filter Secondary.....	A-6007
Fuel/Water Separator Primary.....	SFC-1306-30
Oil Filter Combination.....	C-1303
<b>FG1J</b> (TRUCKS) HINO J08C-TI	
Oil Filter Combination.....	C-1303
<b>FG1JDD</b> (TRUCKS) HINO J08C , 1999-2001	
Air Filter Primary.....	A-1156
Air Filter Set.....	A-1156-S

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FG22</b> (TRUCKS) HINO EM100E , 1984-1986	
Air Filter Primary.....	A-1313
Air Filter Set.....	A-5662-S
Air Filter Secondary.....	A-1307
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter By Pass.....	C-1306
Oil Filter By Pass.....	C-1327
Oil Filter Full Flow.....	C-5519
<b>FG22</b> (TRUCKS) HINO EM100 , 1984-1985	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Fuel Filter Primary.....	FC-1310
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Oil Filter Full Flow.....	C-5519
Oil Filter By Pass.....	C-1306
Oil Filter By Pass.....	C-1327
<b>FG22</b> (TRUCKS) EM100E	
Oil Filter By Pass.....	C-1306
<b>FG235JJ / JK / TI</b> (TRUCKS)	
Air Filter Primary.....	A-1325
Air Filter Set.....	A-1331-S
Air Filter Secondary.....	A-1330
Fuel Filter.....	FC-1301
Fuel/Water Separator Primary.....	SFC-1306-30B
Oil Filter Combination.....	C-1316
<b>FH220</b> (TRUCKS) HINO EM100 , 1981-1983	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FH22</b> (TRUCKS) HINO EM100 , 1983-1990	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
<b>FH221</b> (TRUCKS) HINO EM100 , 1981-1983	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1305
Oil Filter Full Flow.....	O-1301

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>FH224</b> (TRUCKS) HINO EM100 , 1987-UP	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>FH27</b> (TRUCKS) HINO EK100 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
<b>FH270</b> (TRUCKS) HINO EM100 , 1985-UP	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1303
<b>FH2K</b> (TRUCKS) HINO K13D , 1995	
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>FH2K</b> (TRUCKS) HINO K13D , 1992	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>FH2KB</b> (TRUCKS) HINO K13D , 1990-1995	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
<b>FM1J</b> (TRUCKS) HINO J08C-TI	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Air Filter Secondary.....	A-6007
Fuel/Water Separator Primary.....	SFC-1306-30
Oil Filter Combination.....	C-1303
<b>FM1JNLA</b> (TRUCKS) HINO J08C	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Fuel/Water Separator Primary.....	SFC-1306-30
Oil Filter Combination.....	C-1303
<b>FM2K</b> (TRUCKS) HINO K13D	
Air Filter Primary.....	A-6010
Fuel Filter.....	FC-1312
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081
<b>FM235</b> (TRUCKS) FM8JN1D-CGJ , 7700	
Air Filter Primary.....	A-1325

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FM235</b> (TRUCKS) FM8JN1D-CGJ		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Air Filter Set.....	A-1331-S	<b>FN1KB</b> (TRUCKS) HINO K13CT , 1992-1995		Oil Filter Full Flow.....	O-13081
Air Filter Secondary.....	A-1330	Fuel Filter.....	F-1304	<b>FN28</b> (TRUCKS) HINO EP100T , 1983-1989	
Fuel Filter.....	FC-1301	Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-5425
Oil Filter Full Flow.....	C-1011	<b>FN1P</b> (TRUCKS) HINO P09CT , 1989-1992		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1011XPL	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1311
Oil Filter Combination.....	C-1316	Oil Filter Full Flow.....	O-13081	<b>FN2F</b> (TRUCKS) HINO F17E , 1992	
<b>FM260</b> (TRUCKS) FM8JN1D-EGJ , 7700		<b>FN1V</b> (TRUCKS) HINO V22D , 1992-1995		Fuel Filter.....	F-1304
Air Filter Primary.....	A-1325	Oil Filter Full Flow.....	C-1301	Oil Filter By Pass.....	O-1310
<b>FM260</b> (TRUCKS) FM8JN1D-EGJ		Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-13081
Air Filter Secondary.....	A-1330	Oil Filter By Pass.....	O-1310	<b>FN2FA</b> (TRUCKS) HINO F17E , 1989-1992	
Air Filter Set.....	A-1331-S	<b>FN2K</b> (TRUCKS) HINO K13D , 1995-1995		Fuel Filter.....	F-1304
Cabin Air Filter.....	CA-11340	Fuel Filter.....	FC-1312	Oil Filter Full Flow.....	O-13081
Cabin Air Filter.....	CAC-11340	<b>FN2K</b> (TRUCKS) HINO K13D , 1995		<b>FN2FB</b> (TRUCKS) HINO F17E , 1992-1995	
Cabin Air Filter.....	CAV-11340	Fuel Filter.....	FC-1305	Fuel Filter.....	F-1304
Fuel Filter.....	FC-1301	Fuel Filter Primary.....	FC-1310	Oil Filter Full Flow.....	O-13081
Oil Filter Combination.....	C-1316	Oil Filter By Pass.....	O-1310	<b>FN2KA</b> (TRUCKS) HINO K13D , 1989-1992	
Oil Filter Full Flow.....	C-1011	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1011XPL	Oil Filter By Pass.....	O-13081	Oil Filter Full Flow.....	O-13081
<b>FM260JD / 260TI</b> (TRUCKS)		<b>FN2K</b> (TRUCKS) HINO K13D , 1989-UP		<b>FN2KB</b> (TRUCKS) HINO K13D , 1992-1995	
Air Filter Primary.....	A-1325	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Air Filter Set.....	A-1331-S	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Air Filter Secondary.....	A-1330	Oil Filter By Pass.....	O-1311	<b>FN3F</b> (TRUCKS) HINO F20C , 1992-1995	
Fuel Filter.....	FC-1301	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
Fuel/Water Separator Primary....	SFC-1306-30B	<b>FN2K</b> (TRUCKS) HINO K13C , 1989-UP		Fuel Filter.....	FC-1305
Oil Filter Combination.....	C-1316	Fuel Filter.....	F-1304	Fuel Filter.....	FC-1312
<b>FN1F</b> (TRUCKS) HINO F17D , 1994		Oil Filter By Pass.....	O-1311	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
<b>FN1F</b> (TRUCKS) HINO F17DT , 1992		<b>FN2P</b> (TRUCKS) HINO P11CT , 1992-1995		Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	<b>FN388</b> (TRUCKS) HINO K13CT , 1986-1990	
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305	Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1312	Oil Filter By Pass.....	O-1311
<b>FN1FA</b> (TRUCKS) HINO F17DT , 1989-1992		Fuel Filter Primary.....	FC-1310	<b>FN4F</b> (TRUCKS) HINO F21C , 1995	
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310	<b>FN60</b> (TRUCKS) HINO EP550 , 1983-1990	
<b>FN1K</b> (TRUCKS) HINO K13CT , 1994		<b>FN2P</b> (TRUCKS) HINO P11CT , 1989		Air Filter Primary.....	A-5425
Fuel Filter.....	FC-1305	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	O-1311	Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	<b>FN63</b> (TRUCKS) HINO EF750 , 1983-1990	
Oil Filter By Pass.....	O-1310	<b>FN27</b> (TRUCKS) HINO EK100 , 1983-1989		Air Filter Primary.....	A-5425
<b>FN1K</b> (TRUCKS) HINO T17D , 1994		Air Filter Primary.....	A-5425	Fuel Filter.....	F-1304
Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310
Fuel Filter.....	FC-1305	Oil Filter By Pass.....	O-1311	<b>FN TRUCK</b> (TRUCKS) E13C-T KS-FN1E , 2003	
Oil Filter By Pass.....	O-1310	<b>FN272</b> (TRUCKS) HINO EK100 , 1981-1983		Oil Filter Full Flow.....	O-1325
Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-5425		
<b>FN1KA</b> (TRUCKS) HINO K13CT , 1989-1992		Fuel Filter.....	F-1304		
Fuel Filter.....	F-1304				

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FP1F</b> (TRUCKS) HINO F17D , 1995		Fuel Filter.....	F-1304	<b>FR1KA</b> (TRUCKS) HINO F13CT , 1990-1992	
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310	<b>FQ1K</b> (TRUCKS) HINO K13C , 1998		Oil Filter Full Flow.....	O-13081
<b>FP1FA</b> (TRUCKS) HINO F17D , 1989-1992		Oil Filter Full Flow.....	O-13081	<b>FR1KB</b> (TRUCKS) HINO F13CT , 1992-1995	
Fuel Filter.....	F-1304	<b>FQ2FA</b> (TRUCKS) HINO F17E , 1990-1992		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081
<b>FP1FB</b> (TRUCKS) HINO F17D , 1992-1995		Oil Filter Full Flow.....	O-13081	<b>FR1P</b> (TRUCKS) HINO P09CT , 1989-1992	
Fuel Filter.....	F-1304	<b>FQ2P</b> (TRUCKS) HINO F11C , 1996		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
<b>FP1K</b> (TRUCKS) HINO K13CT , 1992-1995		<b>FQ3F</b> (TRUCKS) HINO F20C , 1995		<b>FR27</b> (TRUCKS) HINO EK100 , 1983-1991	
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-5425
Oil Filter Full Flow.....	O-13081	<b>FQ TRUCK</b> (TRUCKS) E13C-T KS-FQ1E , 2003		Fuel Filter.....	F-1304
<b>FP1P</b> (TRUCKS) HINO P09CT , 1989-1992		Oil Filter Full Flow.....	O-1325	Oil Filter By Pass.....	O-1311
Fuel Filter.....	F-1304	<b>FR1F</b> (TRUCKS) HINO F17D , 1995		<b>FR272</b> (TRUCKS) HINO EK100 , 1980-1983	
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305	Air Filter Primary.....	A-5425
<b>FP27</b> (TRUCKS) HINO EK100 , 1983-1989		Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311	<b>FR1F</b> (TRUCKS) HINO F17DT , 1992		<b>FR28</b> (TRUCKS) HINO EP100T , 1983-1989	
<b>FP28</b> (TRUCKS) HINO EP100T , 1983-1989		Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Oil Filter By Pass.....	O-1311	<b>FR1FA</b> (TRUCKS) HINO F17D , 1989-1992		<b>FR2FA</b> (TRUCKS) HINO F17E , 1989-1992	
<b>FP2F</b> (TRUCKS) HINO F17E , 1992-1995		Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	<b>FR1FB</b> (TRUCKS) HINO F17D , 1992-1995		<b>FR2K</b> (TRUCKS) HINO K13D , 1995	
<b>FP2KA</b> (TRUCKS) HINO K13D , 1989-1992		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	<b>FR2P</b> (TRUCKS) HINO P11CT , 1992-1995	
Oil Filter Full Flow.....	O-13081	<b>FR1FB</b> (TRUCKS) HINO F17DT , 1989-1995		Fuel Filter.....	F-1304
<b>FP2W</b> (TRUCKS) HINO P11CT , 1994		Fuel Filter.....	F-1304	Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310
Fuel Filter Primary.....	FC-1310	<b>FR1K</b> (TRUCKS) HINO K13CT , 1994		Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	<b>FR33</b> (TRUCKS) HINO K13CT , 1986-1990	
Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
<b>FP60</b> (TRUCKS) HINO EF550 , 1983-1989		Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1311
Air Filter Primary.....	A-5425	<b>FR1K</b> (TRUCKS) HINO F13CT , 1994		<b>FR3F</b> (TRUCKS) HINO F20C , 1994	
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305
Oil Filter By Pass.....	O-1310	<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		Fuel Filter Primary.....	FC-1310
<b>FQ1FA</b> (TRUCKS) HINO F17D , 1990-1992		Fuel Filter.....	FC-1305	Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1304	Fuel Filter Primary.....	FC-1310	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	
<b>FQ1FB</b> (TRUCKS) HINO F17D , 1992-1995		Oil Filter By Pass.....	O-1311	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305	<b>FR3K</b> (TRUCKS) HINO K13CT , 1986-1990	
<b>FP60</b> (TRUCKS) HINO EF550 , 1983-1989		Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	<b>FR3P</b> (TRUCKS) HINO P11CT , 1992-1995	
Oil Filter By Pass.....	O-1310	<b>FR1K</b> (TRUCKS) HINO F13CT , 1994		Fuel Filter.....	FC-1305
<b>FQ1FA</b> (TRUCKS) HINO F17D , 1990-1992		Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310
Fuel Filter.....	F-1304	<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305	<b>FR33</b> (TRUCKS) HINO K13CT , 1986-1990	
<b>FQ1FB</b> (TRUCKS) HINO F17D , 1992-1995		Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	
<b>FP60</b> (TRUCKS) HINO EF550 , 1983-1989		<b>FR1K</b> (TRUCKS) HINO F13CT , 1994		Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1304	<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		<b>FR3K</b> (TRUCKS) HINO K13CT , 1986-1990	
Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1305	Fuel Filter.....	F-1304
<b>FQ1FA</b> (TRUCKS) HINO F17D , 1990-1992		Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	O-1311
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	
Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
<b>FQ1FB</b> (TRUCKS) HINO F17D , 1992-1995		<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1304	Fuel Filter.....	FC-1305	<b>FR3K</b> (TRUCKS) HINO K13CT , 1986-1990	
Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
<b>FP60</b> (TRUCKS) HINO EF550 , 1983-1989		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	O-1310	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	
Fuel Filter.....	F-1304	<b>FR1K</b> (TRUCKS) HINO F13CT , 1994		Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
<b>FQ1FA</b> (TRUCKS) HINO F17D , 1990-1992		<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		<b>FR3K</b> (TRUCKS) HINO K13CT , 1986-1990	
Fuel Filter.....	F-1304	Fuel Filter.....	FC-1305	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	O-1311
<b>FQ1FB</b> (TRUCKS) HINO F17D , 1992-1995		Oil Filter Full Flow.....	O-13081	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	<b>FR1K</b> (TRUCKS) HINO K13CT , 1989-1992		Oil Filter Full Flow.....	O-13081
<b>FP60</b> (TRUCKS) HINO EF550 , 1983-1989		Fuel Filter.....	FC-1305	<b>FR3K</b> (TRUCKS) HINO K13CT , 1986-1990	
Air Filter Primary.....	A-5425	Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1311
Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310	<b>FR3FA</b> (TRUCKS) HINO F20C , 1989-1992	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FR3FB</b> (TRUCKS) HINO F20C , 1992-1995		Fuel Filter.....	FC-1305	Air Filter.....	A-1323
Fuel Filter.....	F-1304	Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Fuel Filter.....	FC-1312
		Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
				Oil Filter By Pass.....	0-1310
<b>FR4F</b> (TRUCKS) HINO F21C , 1994-1994		<b>FS1K</b> (TRUCKS) HINO K13CT		Oil Filter By Pass.....	0-1311
Fuel Filter.....	FC-1312	Fuel Filter.....	FC-1312		
		Oil Filter By Pass.....	0-1310	<b>FS27</b> (TRUCKS) HINO EK100 , 1983-1989	
		Oil Filter Full Flow.....	0-13081	Air Filter Primary.....	A-5425
<b>FR4F</b> (TRUCKS) HINO F21C , 1994				Fuel Filter.....	F-1304
Fuel Filter.....	FC-1305	<b>FS1FB</b> (TRUCKS) HINO F17D , 1992-1995		Oil Filter By Pass.....	0-1311
Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304		
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	<b>FS270</b> (TRUCKS) HINO EK100 , 1984	
Oil Filter By Pass.....	0-1310			Air Filter Primary.....	A-5425
		<b>FS1KA</b> (TRUCKS) HINO K13CT , 1990-1992		Fuel Filter.....	F-1304
<b>FR608</b> (TRUCKS) HINO EF550 , 1981-1984		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304				
Oil Filter Full Flow.....	0-13081	<b>FS1KB</b> (TRUCKS) HINO K13CT , 1992-1995		<b>FS270</b> (TRUCKS) HINO EK100 , 1981-1983	
		Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425
<b>FR63</b> (TRUCKS) HINO EF550 , 1983-1989		Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1303
Air Filter Primary.....	A-5425				
Fuel Filter.....	F-1304	<b>FS1V</b> (TRUCKS) HINO V22D , 1992		<b>FS270 SUPER DOLPHIN</b> (TRUCKS) HINO EK100	
Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
		Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	0-13081
<b>FR630</b> (TRUCKS) HINO EF750 , 1981-1983		Oil Filter Full Flow.....	C-1309		
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1310	<b>FS270KD</b> (TRUCKS) HINO EK100 , 1984	
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-6010
Oil Filter By Pass.....	0-1305			Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	<b>FS1V</b> (TRUCKS) HINO V22D		Oil Filter Full Flow.....	0-13081
		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
<b>FR66</b> (TRUCKS) HINO F17C , 1985-1989		Oil Filter By Pass.....	0-1310		
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1301	<b>FS271</b> (TRUCKS) HINO EK100 , 1989-UP	
Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-5425
				Fuel Filter.....	F-1303
<b>FR TRUCK</b> (TRUCKS) E13C-T KS-FR1E , 2003		<b>FS1VA</b> (TRUCKS) HINO V22D , 1991-1992		Oil Filter By Pass.....	0-1311
Oil Filter Full Flow.....	0-1325	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
		Oil Filter Full Flow.....	C-1301		
<b>FS1F</b> (TRUCKS) HINO F17D , 1995-1995		Oil Filter Full Flow.....	C-1309	<b>FS2F</b> (TRUCKS) HINO F17E , 1992	
Fuel Filter.....	FC-1312			Fuel Filter.....	F-1304
		<b>FS1VB</b> (TRUCKS) HINO V22D , 1992-1995		Oil Filter Full Flow.....	0-13081
<b>FS1F</b> (TRUCKS) HINO F17D , 1995		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	C-1301		
Fuel Filter Primary.....	FC-1310	Oil Filter Full Flow.....	C-1309	<b>FS2F</b> (TRUCKS) HINO F17E	
Oil Filter Full Flow.....	0-13081			Fuel Filter.....	F-1304
Oil Filter By Pass.....	0-1310	<b>FS2K</b> (TRUCKS) HINO K13D , 1995		Oil Filter By Pass.....	0-1310
		Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	0-13081
<b>FS1F</b> (TRUCKS) HINO F17D		Fuel Filter Primary.....	FC-1310		
Fuel Filter.....	FC-1312	Oil Filter Full Flow.....	0-13081	<b>FS2FA</b> (TRUCKS) HINO F17E , 1989-1992	
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081			Oil Filter Full Flow.....	0-13081
		<b>FS2K</b> (TRUCKS) HINO K13D , 1992-1995			
<b>FS1K</b> (TRUCKS) HINO K13CT , 1994-1994		Fuel Filter.....	F-1304	<b>FS2KA</b> (TRUCKS) HINO K13D , 1989-1992	
Fuel Filter.....	FC-1312	Oil Filter By Pass.....	0-1311	Fuel Filter.....	F-1304
		Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
<b>FS1K</b> (TRUCKS) HINO K13CT , 1994					
		<b>FS2K</b> (TRUCKS) HINO K13D			
		Fuel Filter.....	F-1304		
		Oil Filter By Pass.....	0-1311		
		Oil Filter Full Flow.....	0-13081		

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FS3F</b> (TRUCKS) HINO F20C , 1994-1994		Air Filter Primary.....	A-5425	Air Filter Primary.....	A-5425
Fuel Filter.....	FC-1312	Fuel Filter.....	F-1303	Fuel Filter.....	F-1304
<b>FS3F</b> (TRUCKS) HINO F20C , 1994		<b>FS633</b> (TRUCKS) HINO EF750T , 1985-1989		Oil Filter By Pass.....	O-1310
Fuel Filter.....	FC-1305	Air Filter Primary.....	A-5425	<b>FV313</b> (TRUCKS)	
Fuel Filter Primary.....	FC-1310	Fuel Filter.....	F-1304	Fuel Filter.....	F-1008
Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310	<b>FW1F</b> (TRUCKS) HINO F17D , 1995	
Oil Filter By Pass.....	O-1310	<b>FS66</b> (TRUCKS) HINO F17T , 1987-1989		Oil Filter Full Flow.....	O-13081
<b>FS3F</b> (TRUCKS) HINO F20C		Fuel Filter.....	F-1304	<b>FW1F</b> (TRUCKS) HINO F17D , 1992	
Fuel Filter.....	FC-1312	Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1305
Oil Filter By Pass.....	O-1310	<b>FS TRUCK</b> (TRUCKS) E13C-T KS-FS1E , 2003		Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-1325	Oil Filter Full Flow.....	O-13081
<b>FS33</b> (TRUCKS) HINO K13CT , 1986-1989		<b>FT17</b> (TRUCKS) HINO H07C , 1986-1989		Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1304	Air Filter.....	A-1306	<b>FW1FA</b> (TRUCKS) HINO F17D , 1989-1992	
Oil Filter By Pass.....	O-1311	Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1304
<b>FS330T</b> (TRUCKS) HINO K13CT , 1986-UP		Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1303	<b>FT17</b> (TRUCKS) HINO H07C , 1983-1986		<b>FW1FB</b> (TRUCKS) HINO F17D , 1992-1995	
<b>FS3FA</b> (TRUCKS) HINO F20C , 1989-1992		Air Filter.....	A-1306	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Fuel Filter.....	F-1303	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-1301	<b>FW1K</b> (TRUCKS) HINO K13CT , 1994	
<b>FS3FB</b> (TRUCKS) HINO F20C , 1992-1995		<b>FT1J</b> (TRUCKS) HINO J08C , 1995-1999		Fuel Filter.....	FC-1305
Fuel Filter.....	F-1304	Air Filter Primary.....	A-6006	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	O-13081
<b>FS4F</b> (TRUCKS) HINO F21C , 1994		Air Filter Set.....	A-6118-S	Oil Filter By Pass.....	O-1310
Fuel Filter.....	FC-1305	Oil Filter Combination.....	C-1303	<b>FW1KA</b> (TRUCKS) HINO K13CT , 1990-1992	
Fuel Filter Primary.....	FC-1310	<b>FT3H</b> (TRUCKS) HINO H07D , 1989-1994		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310	Air Filter Primary.....	A-60400	<b>FW1KB</b> (TRUCKS) HINO K13CT , 1992-1995	
<b>FS4F</b> (TRUCKS) HINO F21C		Air Filter Set.....	A-6118-S	Fuel Filter.....	F-1304
Fuel Filter.....	FC-1312	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310	<b>FU2F</b> (TRUCKS) HINO F17E , 1990-1992		<b>FW28</b> (TRUCKS) HINO EP100T , 1985-1990	
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425
<b>FS600</b> (TRUCKS) HINO EF550 , 1981-UP		Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1303	<b>FU3F</b> (TRUCKS) HINO F20C , 1993		<b>FW2P</b> (TRUCKS) HINO P11C , 1996	
<b>FS63</b> (TRUCKS) HINO EF750 , 1983-1989		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	O-13081	<b>FW3F</b> (TRUCKS) HINO F20C , 1994	
Fuel Filter.....	F-1304	<b>FU4F</b> (TRUCKS) HINO F21C , 1995-1995		Fuel Filter.....	FC-1305
Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1312	Fuel Filter Primary.....	FC-1310
<b>FS630</b> (TRUCKS) HINO EF750 , 1983-UP		<b>FU4F</b> (TRUCKS) HINO F21C , 1995		Oil Filter Full Flow.....	O-13081
Air Filter Primary.....	A-5425	Fuel Filter.....	FC-1305	Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1303	Fuel Filter Primary.....	FC-1310	<b>FW3F</b> (TRUCKS) HINO F20C , 1992-1995	
<b>FS630T</b> (TRUCKS) HINO EF750 , TO-1984		Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
Fuel Filter.....	F-1303	<b>FU63</b> (TRUCKS) HINO EF750 , 1983-1990		Fuel Filter.....	FC-1305



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>FW3F</b> (TRUCKS) HINO F20C , 1992-1995		Oil Filter Full Flow.....	O-13081	Air Filter Set.....	A-6118-S
Fuel Filter.....	FC-1312	<b>FZ1FB</b> (TRUCKS) HINO F17D , 1993		Oil Filter Combination.....	C-1303
Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304	<b>GD164</b> (TRUCKS) HINO W06E , 1987	
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Air Filter.....	A-1306
<b>FW60</b> (TRUCKS) HINO EF550 , 1984-1989		<b>FZ273</b> (TRUCKS) HINO EK100 , 1983-1987		Fuel Filter.....	F-1303
Air Filter Primary.....	A-5425	Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081	<b>GD17</b> (TRUCKS) HINO H07C , 1986-1989	
<b>FW TRUCK</b> (TRUCKS) E13C-T KS-FW1E , 2003		Oil Filter By Pass.....	O-1311	Air Filter.....	A-1306
Oil Filter Full Flow.....	O-1325	<b>FZ273AA</b> (TRUCKS) HINO EK100 , 1983-UP		Oil Filter Full Flow.....	C-1301
<b>FX1J</b> (TRUCKS) HINO J08C , 1997-1999		Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1309
Oil Filter Combination.....	C-1303	Fuel Filter.....	F-1303	<b>GD17</b> (TRUCKS) HINO H07C , 1983-1986	
<b>FX1J</b> (TRUCKS) HINO J08C , 1994-1997		<b>FZ633</b> (TRUCKS) HINO EF750 , 1983-1990		Air Filter.....	A-1306
Air Filter Primary.....	A-6006	Air Filter Primary.....	A-5425	Fuel Filter.....	F-1303
Air Filter Primary.....	A-60400	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
Air Filter Set.....	A-6118-S	Oil Filter By Pass.....	O-1310	<b>GD170</b> (TRUCKS) HINO H07C , 1986-UP	
Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1301
<b>FX3H</b> (TRUCKS) HINO H07D , 1992-1994		<b>GC17</b> (TRUCKS) HINO H07C , 1984-1991		Oil Filter Full Flow.....	C-1309
Air Filter.....	A-1310	Air Filter Primary.....	A-1313	<b>GD170T</b> (TRUCKS) HINO EH700 , 1980-1983	
Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-5662-S	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1309	Air Filter Secondary.....	A-1307	Oil Filter Full Flow.....	O-1301
<b>FY270</b> (TRUCKS) HINO EK100E , 1983-UP		Coolant Filter.....	WC-5707	<b>GD174</b> (TRUCKS) HINO H07C , 1987-1993	
Air Filter Primary.....	A-5425	Fuel Filter.....	FC-1305	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1303	Fuel Filter.....	FC-1312	Oil Filter Full Flow.....	C-1309
<b>FY275KA</b> (TRUCKS) HINO EK100E , 1987-UP		Fuel Filter Primary.....	FC-1310	<b>GD174</b> (TRUCKS) HINO H07C , 1983-1987	
Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-5519	Fuel Filter.....	F-1301
Fuel Filter.....	F-1303	<b>GC20</b> (TRUCKS) HINO H06C-TI , 1992-UP		Fuel Filter.....	F-1303
<b>FY3F</b> (TRUCKS) HINO F20C , 1998		Air Filter.....	A-1334	Oil Filter Full Flow.....	O-1301
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1305	<b>GD174</b> (TRUCKS) HINO EH700 , 1983-1986	
<b>FZ1F</b> (TRUCKS) HINO F17D , 1995		Fuel Filter Primary.....	FC-1310	Air Filter.....	AS-1303
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-5519	Fuel Filter.....	F-1303
<b>FZ1F</b> (TRUCKS) HINO F17D , 1994		<b>GC20</b> (TRUCKS) HINO H06C-TI , 1992-UP		Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1305	Coolant Filter.....	WC-5707	<b>GD1J</b> (TRUCKS) HINO J08C , 1994-1999	
Fuel Filter Primary.....	FC-1310	Fuel Filter.....	FC-1305	Air Filter.....	A-1310
Oil Filter Full Flow.....	O-13081	Fuel Filter Primary.....	FC-1310	Air Filter Primary.....	A-6006
Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	C-5519	Air Filter Primary.....	A-60400
<b>FZ1F</b> (TRUCKS) HINO F17D , 1990		<b>GC20</b> (TRUCKS) HINO H06C-TI , 1992		Air Filter Set.....	A-6118-S
Fuel Filter Primary.....	FC-1310	Fuel Filter.....	FC-1312	Oil Filter Combination.....	C-1303
Fuel Filter.....	FC-1305	<b>GC20</b> (TRUCKS) HINO H06C-TI , 1992		<b>GD1J</b> (TRUCKS) HINO J08CT , 1994-1999	
Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1312	Oil Filter Combination.....	C-1303
Oil Filter Full Flow.....	O-13081	<b>GD</b> (TRUCKS) HINO EH700		<b>GD1J</b> (TRUCKS) HINO J08C-TI	
<b>FZ1FA</b> (TRUCKS) HINO F17D , 1990-1992		Air Filter.....	AS-1303	Fuel/Water Separator Primary....	SFC-1306-30
Fuel Filter.....	F-1304	<b>GD16</b> (TRUCKS) HINO H06C-T , 1986-1989		Oil Filter Combination.....	C-1303
		Air Filter Primary.....	A-6006	<b>GD2H</b> (TRUCKS) HINO H07CT , 1989-1994	
		Air Filter Primary.....	A-60400		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>GD2H</b> (TRUCKS) HINO H07CT , 1989-1994 Oil Filter Combination.....	C-1303	Oil Filter By Pass.....	0-1311	Oil Filter By Pass.....	0-1319
<b>GD3H</b> (TRUCKS) HINO H07D , 1989-1994 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Oil Filter Combination.....	A-6006 A-60400 A-6118-S C-1303	<b>GN28</b> (TRUCKS) HINO EP100T , 1983-1989 Air Filter Primary..... Fuel Filter..... Oil Filter By Pass.....	A-5425 F-1304 0-1311	<b>GT173 4X4 MA</b> (TRUCKS) HINO H07C , 1987 Air Filter..... Fuel Filter..... Oil Filter Full Flow..... Oil Filter Full Flow.....	A-1306 F-1303 C-1301 C-1309
<b>GH1J</b> (TRUCKS) HINO J08C-TI Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Air Filter Secondary..... Fuel/Water Separator Primary.... Oil Filter Combination.....	A-6006 A-60400 A-6118-S A-6007 SFC-1306-30 C-1303	<b>GN2K</b> (TRUCKS) HINO K13D , 1995 Fuel Filter..... Fuel Filter Primary..... Oil Filter By Pass..... Oil Filter Full Flow.....	FC-1305 FC-1310 0-1310 0-13081	<b>GT1J</b> (TRUCKS) HINO J08C-TI Air Filter Set..... Air Filter Primary..... Air Filter Primary..... Fuel/Water Separator Primary.... Oil Filter Combination.....	A-6118-S A-6006 A-60400 SFC-1306-30 C-1303
<b>GK1H</b> (TRUCKS) HINO H06C-TI , 1989-1994 Oil Filter Combination.....	C-1303	<b>GRIFFON 850</b> (TRUCKS) HINO H07CT Air Filter..... Fuel Filter..... Oil Filter Full Flow.....	A-1306 F-1304 C-1314	<b>GU275 S</b> (TRUCKS) Oil Filter Full Flow..... Oil Filter Full Flow.....	C-1032 C-1032XPL
<b>GK1J</b> (TRUCKS) HINO J08CT , 1995-1999 Oil Filter Combination.....	C-1303	<b>GS221</b> (TRUCKS) HINO EM100 , 1986 Air Filter Primary..... Air Filter Secondary..... Air Filter Set..... Fuel Filter..... Oil Filter Full Flow..... Oil Filter By Pass.....	A-1313 A-1307 A-5662-S F-1304 0-1301 0-1305	<b>GX1J</b> (TRUCKS) HINO J08C , 1997-1999 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Oil Filter Combination.....	A-6006 A-60400 A-6118-S C-1303
<b>GK1J</b> (TRUCKS) HINO J08CT , 1994 Oil Filter Combination.....	C-1303	<b>GS221</b> (TRUCKS) HINO EM100 , 1984-1992 Fuel Filter..... Oil Filter Full Flow.....	F-1304 0-1301	<b>HARRIER 700</b> (TRUCKS) HINO H07D Air Filter Set..... Air Filter Primary..... Air Filter Primary..... Fuel Filter..... Oil Filter Full Flow.....	A-6118-S A-6006 A-60400 F-1304 C-1314
<b>GN1F</b> (TRUCKS) HINO F17D , 1994 Fuel Filter Primary..... Fuel Filter..... Oil Filter By Pass..... Oil Filter Full Flow.....	FC-1310 FC-1305 0-1310 0-13081	<b>GS221KD</b> (TRUCKS) HINO EM100 , 1986-UP Air Filter Set..... Air Filter Secondary..... Air Filter Primary..... Fuel Filter..... Oil Filter Full Flow.....	A-5662-S A-1307 A-1313 F-1303 0-1301	<b>HAWK 550</b> (TRUCKS) HINO H07D , 1991-1997 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Fuel Filter..... Oil Filter Combination.....	A-6006 A-60400 A-6118-S F-1304 C-1303
<b>GN1F SERIES</b> (TRUCKS) HINO F17D , 1989-UP Fuel Filter..... Oil Filter Full Flow.....	F-1304 0-13081	<b>GS224</b> (TRUCKS) HINO EM100 , 1987 Air Filter Primary..... Air Filter Secondary..... Air Filter Set..... Fuel Filter..... Oil Filter Full Flow..... Oil Filter By Pass.....	A-1313 A-1307 A-5662-S F-1304 0-1301 0-1305	<b>HAWK 550</b> (TRUCKS) HINO W06E Air Filter Set..... Air Filter Primary..... Air Filter Primary..... Fuel Filter..... Oil Filter Full Flow..... Oil Filter Full Flow..... Oil Filter Full Flow.....	A-6118-S A-6006 A-60400 F-1304 C-1301 C-1309 C-1314
<b>GN1FB</b> (TRUCKS) HINO F17D , 1992-1995 Fuel Filter..... Oil Filter Full Flow.....	F-1304 0-13081	<b>GT173 4X4</b> (TRUCKS) HINO H07C , 1987 Air Filter..... Fuel Filter.....	A-1306 F-1303	<b>HE320</b> (TRACTORS) HINO EB300 , 1973-1977 Fuel Filter..... Oil Filter Full Flow.....	F-1302 0-1303
<b>GN1P</b> (TRUCKS) HINO P09CT , 1989-1992 Fuel Filter..... Oil Filter Full Flow.....	F-1304 0-13081	<b>GT173 4X4</b> (TRUCKS) HINO EH700 , 1984-1986 Air Filter..... Fuel Filter..... Oil Filter By Pass.....	AS-1303 F-1303 0-1319	<b>HE335</b> (TRACTORS) HINO ED100 , 1973-1976 Fuel Filter..... Oil Filter Full Flow.....	F-1302 0-1303
<b>GN2P</b> (TRUCKS) HINO P11CT , 1992-1995 Fuel Filter..... Fuel Filter..... Fuel Filter..... Fuel Filter Primary..... Oil Filter Full Flow..... Oil Filter By Pass.....	F-1304 FC-1305 FC-1312 FC-1310 0-13081 0-1310	<b>GT173 4X4 KA</b> (TRUCKS) HINO EH700 , 1984-1986 Air Filter..... Fuel Filter.....	A-1306 F-1303	<b>HE336</b> (TRACTORS) HINO EK100 , 1987-UP	
<b>GN27</b> (TRUCKS) HINO EK100 , 1983-1989 Air Filter Primary..... Fuel Filter.....	A-5425 F-1304				

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
HE336 (TRACTORS) HINO EK100 , 1987-UP	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	HE526 (TRACTORS) HINO EV700 , 1978-1979	Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309	Fuel Filter..... FC-1302 Oil Filter Full Flow..... C-1302	
HE336 (TRACTORS) HINO EK100 , 1976-1979	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305	HF340 (TRACTORS) HINO FF100	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	KAB115 (BUSES) HINO W04D , 1985	Air Filter..... A-1308 Fuel Filter..... FC-1302 Oil Filter Full Flow..... C-1302
HE336 (TRACTORS) HINO EF500 , 1976-1979	Fuel Filter..... F-1303 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-1301	HH130 (TRACTORS) HINO ED100 , 1972-1976	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303	KAM101 (TRUCKS) HINO EH100 , 1980-1983	Fuel Filter..... F-1301 Oil Filter Full Flow..... 0-1301
HE346 (TRUCKS) HINO EF100T , 1976-1979	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	HH131 (TRACTORS) HINO EF700 , 1977-1979	Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305	KAM101 (BUSES) HINO EH100 , 1976-1983	Fuel Filter..... F-1301 Oil Filter Full Flow..... 0-1301
HE350 (TRACTORS) HINO EG100 , 1971-1976	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	HH340 (TRACTORS) HINO EF100 , 1971-1977	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	KB113 (TRUCKS) HINO EB300 , 1971-1979	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303
HE356 (TRACTORS) HINO EF500 , 1987-UP	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	HINO W04C-TH (MARINE) HINO W04C-TH	Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309	KB301D (TRUCKS) HINO EB100	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1301
HE356 (TRACTORS) HINO EF500 , 1979-1981	Fuel Filter..... F-1303	HINO W06E (MARINE) HINO W06E	Oil Filter Full Flow..... C-1305	KB303 (TRUCKS) HINO EB300 , 1973-UP	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303
HE356 (TRACTORS) HINO EF500 , 1976-1979	Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305	HL500 (TRUCKS) HINO EH100 , 1973-1980	Air Filter..... AS-1303 Fuel Filter..... F-1301 Oil Filter Full Flow..... 0-1301	KB304 (TRUCKS) HINO EK300 , 1979-1983	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305
HE366 (TRACTORS) HINO EF700 , 1987-UP	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	HV10 (TRUCKS) HINO B , 1978-1979	Air Filter..... A-1119 Fuel Filter..... FC-1501 Fuel Filter..... FC-1801	KB304 (TRUCKS) HINO EB300	Fuel Filter..... F-1302 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1303
HE366 (TRACTORS) HINO EF700T , 1980-1983	Fuel Filter..... F-1304	HV11 (TRUCKS) TOYOTA 14B , 1988-1999	Oil Filter Combination..... C-1112	KB314 (TRUCKS) HINO EB300 , 1976-1979	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303
HE366 (TRACTORS) HINO EF700 , 1979-1983	Fuel Filter..... F-1303 Fuel Filter..... F-1304	HV20 (TRUCKS) HINO DG , 1978-1989	Air Filter..... A-1119 Fuel Filter..... F-1803 Oil Filter Full Flow..... C-1005	KB344 (TRUCKS) HINO EB300 , 1976-1979	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303
HE366 (TRACTORS) HINO EF700 , 1976-1979	Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1305	KA340 (TRUCKS) HINO EF100	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303	KB4501 (TRUCKS) HINO EK300 , 1979-1982	Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301
HE366T (TRACTORS) HINO EF700T , 1981-UP	Fuel Filter..... F-1303	KAB115 (TRUCKS) HINO W04D , 1985-UP	Air Filter..... A-1308	KB500 (TRUCKS) HINO ED100 , 1974-1976	Fuel Filter..... F-1302 Oil Filter Full Flow..... 0-1303
HE526 (TRACTORS) HINO EV700 , 1979-1981				KB501 (TRUCKS) HINO EK100 , 1979-1983	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KB501</b> (TRUCKS) HINO EK100 , 1979-1983		Oil Filter Combination .....	C-1112	Oil Filter Combination .....	C-1303
Fuel Filter.....	F-1303	<b>KCBU212F</b> (TRUCKS) HINO 15BF , 1997		<b>KCFD2J</b> (TRUCKS) HINO J08C , 1994-1999	
Oil Filter Full Flow.....	O-1301	Air Filter.....	A-1112	Air Filter Primary.....	A-6006
Oil Filter By Pass.....	O-1305	Oil Filter Combination .....	C-1112	Air Filter Primary.....	A-60400
<b>KB501D</b> (TRUCKS) HINO EK100 , 1979-1983		<b>KCBU212M</b> (TRUCKS) HINO 15BFT , 1997		Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1303	Air Filter.....	A-1112	Oil Filter Combination .....	C-1303
Oil Filter Full Flow.....	O-1301	Oil Filter Combination .....	C-1112	<b>KCFD2JE</b> (TRUCKS) HINO J08CA , 1994-1999	
<b>KB721</b> (TRUCKS) HINO EF350 , 1975-1980		<b>KCBU222M</b> (TRUCKS) HINO 15BFT , 1997		Oil Filter Combination .....	C-1303
Fuel Filter.....	F-1302	Oil Filter Combination .....	C-1112	<b>KCFE1J</b> (TRUCKS) HINO J08CT , 1997-1999	
<b>KB721</b> (TRUCKS) HINO EB300 , 1975-1979		<b>KCBU222M</b> (TRUCKS) HINO 15BF , 1996		Oil Filter Combination .....	C-1303
Fuel Filter.....	F-1302	Air Filter.....	A-1112	<b>KCFE1J</b> (TRUCKS) HINO J08C , 1996-1999	
Oil Filter Full Flow.....	O-1303	Oil Filter Combination .....	C-1112	Air Filter Set.....	A-6118-S
<b>KC320</b> (TRUCKS) HINO D570 , 1965-1976		<b>KCCH1J</b> (TRUCKS) HINO J08C , 1995		Air Filter Primary.....	A-6006
Fuel Filter.....	F-1302	Oil Filter Combination .....	C-1303	Air Filter Primary.....	A-60400
<b>KCB840M</b> (TRUCKS) HINO 3B , 1997-1999		<b>KCCH4J</b> (TRUCKS) HINO J0DCT , 1995		Oil Filter Combination .....	C-1303
Air Filter.....	A-1119	Air Filter Primary.....	A-1156	<b>KCFF1J</b> (TRUCKS) HINO J08C , 1994-1999	
<b>KCB855M</b> (BUSES) TOYOTA 15BF , 1997-1999		Air Filter Set.....	A-1156-S	Air Filter Primary.....	A-6006
Air Filter.....	A-1112	Oil Filter Combination .....	C-1303	Air Filter Primary.....	A-60400
Oil Filter Combination.....	C-1112	<b>KCFB4J</b> (TRUCKS) TOYOTA 15B , 1997-1999		Air Filter Set.....	A-6118-S
<b>KCBU100M</b> (TRUCKS) TOYOTA 3B , 1995		Oil Filter Combination .....	C-1112	Oil Filter Combination .....	C-1303
Air Filter.....	A-1119	<b>KCFB4J</b> (TRUCKS) HINO J05C , 1995-1999		<b>KCFG1J</b> (TRUCKS) HINO J08CT , 1994-1999	
<b>KCBU102E</b> (TRUCKS) TOYOTA 15BF , 1996		Fuel Filter.....	FC-1302	Oil Filter Combination .....	C-1303
Air Filter.....	A-1112	Oil Filter Full Flow.....	C-1301	<b>KCFH2K</b> (TRUCKS) HINO K13D , 1995	
Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	C-1309	Oil Filter By Pass.....	O-1310
<b>KCBU102M</b> (TRUCKS) HINO 15BF , 1995		<b>KCFC2J</b> (TRUCKS) HINO J08C , 1995-1999		Oil Filter Full Flow.....	O-13081
Air Filter.....	A-1112	Air Filter Set.....	A-1156-S	Oil Filter By Pass.....	O-1310
Oil Filter Combination.....	C-1112	Air Filter Primary.....	A-1156	<b>KCFN1F</b> (TRUCKS) HINO F17D , 1994	
<b>KCBU105M</b> (TRUCKS) HINO 3B , 1997		Oil Filter Combination .....	C-1303	Oil Filter Full Flow.....	O-13081
Air Filter.....	A-1119	<b>KCFC3J</b> (TRUCKS) HINO J07C , 1995-1999		Oil Filter By Pass.....	O-1310
<b>KCBU107M</b> (TRUCKS) HINO 15BF , 1995-1999		Air Filter Primary.....	A-1156	Oil Filter Full Flow.....	O-13081
Air Filter.....	A-1112	Air Filter Set.....	A-1156-S	Oil Filter By Pass.....	O-1310
Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	C-1301	<b>KCFN2K</b> (TRUCKS) HINO K13D , 1995	
<b>KCBU112M</b> (BUSES) HINO 15BF , 1995		Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-13081
Air Filter.....	A-1112	<b>KCFC4J</b> (TRUCKS) HINO J05C , 1995-1999		Oil Filter By Pass.....	O-1310
Oil Filter Combination.....	C-1112	Fuel Filter.....	FC-1302	<b>KCFN2P</b> (TRUCKS) HINO P11CT , 1994	
<b>KCBU112X</b> (TRUCKS) TOYOTA 15BF , 1996		Oil Filter Full Flow.....	C-1301	Oil Filter By Pass.....	O-1310
Air Filter.....	A-1112	Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-13081
Oil Filter Combination.....	C-1112	<b>KCFD1J</b> (TRUCKS) HINO J08C , 1994-1999		Oil Filter By Pass.....	O-1310
<b>KCBU132M</b> (BUSES) HINO 15BF , 1996-1997		Oil Filter Combination .....	C-1303	<b>KCFN3F</b> (TRUCKS) HINO F20C , 1995	
Air Filter.....	A-1112	<b>KCFD1J</b> (TRUCKS) HINO J08CT , 1994-1999		Oil Filter Full Flow.....	O-13081
		Air Filter Set.....	A-6118-S	Oil Filter By Pass.....	O-1310
		Air Filter Primary.....	A-6006	<b>KCFN4F</b> (TRUCKS) HINO F21C , 1995	
		Air Filter Primary.....	A-60400	Oil Filter By Pass.....	O-1310

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
KCFN4F (TRUCKS) HINO F21C , 1995 Oil Filter Full Flow.....	0-13081	KCF53F (TRUCKS) HINO F20C , 1994 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCGK1J (TRUCKS) HINO J08CT , 1995-1999 Oil Filter Combination.....	C-1303
KCFP2P (TRUCKS) HINO P11CT , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCF54F (TRUCKS) HINO F21C , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCGN2K (TRUCKS) HINO K13D , 1995 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081
KCFQ1K (TRUCKS) HINO K13C , 1998 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCFT1J (TRUCKS) HINO J08C , 1995-1999 Oil Filter Combination.....	C-1303	KCGN2P (TRUCKS) HINO P11CT , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310
KCFQ2F (TRUCKS) HINO P11CT , 1996 Fuel Filter..... Fuel Filter Primary..... Oil Filter Full Flow..... Oil Filter By Pass.....	FC-1305 FC-1310 0-13081 0-1310	KCFT1L (TRUCKS) HINO J08C , 1995-1999 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Oil Filter Combination.....	A-6006 A-60400 A-6118-S C-1303	KCGX1J (TRUCKS) HINO J08C , 1997-1999 Air Filter Set..... Air Filter Primary..... Air Filter Primary..... Oil Filter Combination.....	A-6118-S A-6006 A-60400 C-1303
KCFQ2P (TRUCKS) HINO F11CT , 1996 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCFU4F (TRUCKS) HINO F21C , 1995 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCHD50M (BUSES) HINO 1HDFT , 1996-1999 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFQ3F (TRUCKS) HINO F20C , 1996 Fuel Filter..... Fuel Filter Primary..... Oil Filter Full Flow..... Oil Filter By Pass.....	FC-1305 FC-1310 0-13081 0-1310	KCFW1K (TRUCKS) HINO K13CT , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCHD850M (TRUCKS) HINO 1HDFT , 1997 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFQ3F (TRUCKS) HINO F20C , 1995 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCFW2P (TRUCKS) HINO P11C , 1996 Fuel Filter..... Fuel Filter Primary..... Oil Filter By Pass..... Oil Filter Full Flow.....	FC-1305 FC-1310 0-1310 0-13081	KCHD851M (TRUCKS) HINO 1HDT , 1997 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFR1K (TRUCKS) HINO K13CT , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCFW3F (TRUCKS) HINO F20C , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCHDB50M (TRUCKS) HINO 1HDFT , 1996-1999 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFR2K (TRUCKS) HINO K13D , 1995 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCFW4F (TRUCKS) HINO F21C , 1994 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCHDB51M (BUSES) HINO 1HDFT , 1997-1999 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFR3F (TRUCKS) HINO F20C , 1994 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCFX1J (TRUCKS) HINO J08C , 1997-1999 Oil Filter Combination.....	C-1303	KCHDB51M (BUSES) HINO 1HDT , 1997 Air Filter..... Oil Filter Combination.....	A-1112 C-1112
KCFR4F (TRUCKS) HINO F21C , 1994 Oil Filter By Pass.....	0-1310	KCFX1J (TRUCKS) HINO J08C , 1994-1997 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Oil Filter Combination.....	A-6006 A-60400 A-6118-S C-1303	KCHT2M (TRUCKS) HINO M10U , 1995 Air Filter Primary..... Air Filter Primary..... Air Filter Set..... Fuel Filter..... Fuel Filter Primary..... Oil Filter By Pass..... Oil Filter Full Flow.....	A-6006 A-60400 A-6118-S FC-1305 FC-1310 0-1310 0-1301
KCF51F (TRUCKS) HINO K13CT , 1994 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCFY3F (TRUCKS) HINO F20C , 1998 Oil Filter By Pass..... Oil Filter Full Flow.....	0-1310 0-13081	KCHT3K (TRUCKS) HINO K13U , 1995 Oil Filter Full Flow..... Oil Filter By Pass.....	0-1301 0-1310
KCF52K (TRUCKS) HINO K13D , 1995 Oil Filter Full Flow..... Oil Filter By Pass.....	0-13081 0-1310	KCGD1J (TRUCKS) HINO J08C , 1994-1999 Oil Filter Combination.....	C-1303		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KCHU2M</b> (TRUCKS) HINO M10U , 1995		<b>KCRJ170</b> (TRUCKS) HINO EH700 , 1980-1983		Oil Filter Full Flow.....	C-1309
Air Filter Primary.....	A-6006	Air Filter.....	AS-1303	<b>KCSH1F</b> (TRUCKS) HINO F17D , 1995-1995	
Air Filter Primary.....	A-60400	Fuel Filter.....	F-1303	Fuel Filter.....	FC-1312
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	O-1301	<b>KCSH1F</b> (TRUCKS) HINO F17DT , 1995-1995	
Fuel Filter.....	FC-1305	<b>KCRJ1J</b> (TRUCKS) HINO J08C , 1995		Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310	Oil Filter Combination.....	C-1303	<b>KCSH1F</b> (TRUCKS) HINO F17D , 1995	
Oil Filter By Pass.....	O-1310	<b>KCRM2K</b> (TRUCKS) HINO K13D , 1997		Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	O-1301	Oil Filter By Pass.....	O-1311	Fuel Filter Primary.....	FC-1310
<b>KCHU2P</b> (TRUCKS) HINO P11C , 1997		Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	<b>KCRR1J</b> (TRUCKS) HINO J08C , 1995		Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1310	Oil Filter Combination.....	C-1303	<b>KCSH1F</b> (TRUCKS) HINO F17DT , 1995	
<b>KCHU3K</b> (TRUCKS) HINO K13U , 1995		<b>KCRR1J</b> (TRUCKS) HINO J08CT , 1995		Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1305	Oil Filter Combination.....	C-1303	Fuel Filter Primary.....	FC-1310
Fuel Filter Primary.....	FC-1310	<b>KCRU1H</b> (TRUCKS) HINO F08CTI , 1995		Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1310	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-1301	<b>KCRU1J</b> (TRUCKS) HINO J08C , 1995		Oil Filter By Pass.....	O-1310
<b>KCHZ841M</b> (TRUCKS) HINO 1HZ , 1997		Oil Filter Combination.....	C-1303	<b>KCSH3F</b> (TRUCKS) HINO F20C , 1995	
Air Filter.....	A-1112	<b>KCRU1J</b> (TRUCKS) HINO J08CT , 1995		Fuel Filter.....	FC-1305
Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1303	Fuel Filter Primary.....	FC-1310
<b>KCHZB40M</b> (BUSES) HINO 1HZ , 1997-1999		<b>KCRU2P</b> (TRUCKS) HINO P11C , 1997		Oil Filter By Pass.....	O-1310
Air Filter.....	A-1112	Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081
Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	O-13081	<b>KCSH3V</b> (TRUCKS) HINO V26C , 1995	
<b>KCHZB50M</b> (BUSES) HINO 1HZ , 1996-1999		<b>KCRU3F</b> (TRUCKS) HINO F20C , 1995		Fuel Filter.....	FC-1305
Air Filter.....	A-1112	Fuel Filter.....	FC-1305	Fuel Filter Primary.....	FC-1310
Oil Filter Combination.....	C-1112	Fuel Filter.....	FC-1810	Oil Filter Full Flow.....	C-1301
<b>KCPX3JCA</b> (BUSES) HINO J07C , 1997		Fuel Filter Primary.....	FC-1310	Oil Filter Full Flow.....	C-1309
Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
Air Filter Primary.....	A-60400	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310
Air Filter Set.....	A-6118-S	<b>KCRU4F</b> (TRUCKS) HINO F21C , 1995		<b>KCSH4F</b> (TRUCKS) HINO F21C , 1995	
Oil Filter Full Flow.....	C-1301	Fuel Filter.....	FC-1305	Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1309	Fuel Filter Primary.....	FC-1310	Fuel Filter Primary.....	FC-1310
<b>KCRH4J</b> (TRUCKS) HINO J05C , 1995		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
Air Filter Set.....	A-1156-S	Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081
Air Filter Primary.....	A-1156	<b>KCRU4J</b> (BUSES) HINO J05CT , 1995-1999		<b>KCSS1F</b> (TRUCKS) HINO F17DT , 1995	
Oil Filter Combination.....	C-1303	Air Filter Primary.....	A-1156	Fuel Filter.....	FC-1305
<b>KCRH4J</b> (TRUCKS) HINO J05CT , 1995		Air Filter Set.....	A-1156-S	Fuel Filter Primary.....	FC-1310
Air Filter Primary.....	A-1156	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	O-13081
Air Filter Set.....	A-1156-S	<b>KCRX4J</b> (TRUCKS) HINO J05C , 1995-1999		Oil Filter By Pass.....	O-1310
Oil Filter Combination.....	C-1303	Air Filter Set.....	A-1156-S	<b>KCWP4F</b> (BUSES) HINO F21C , 1998	
<b>KCRJ170</b> (TRUCKS) HINO H07C , 1983-1988		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
Air Filter.....	AS-1303	<b>KCRX4J</b> (TRUCKS) HINO J05C , 1995-1999		Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1303	Air Filter Set.....	A-1156-S	<b>KCXZU130X</b> (BUSES) HINO J05C , 1995	
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-1156	Air Filter.....	A-1112
Oil Filter Full Flow.....	C-1309	Fuel Filter.....	FC-1302		
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1301		



# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KCXZU130X</b> (BUSES) HINO J05C , 1995		Fuel Filter.....	F-1304	<b>KFD175</b> (TRUCKS) HINO EH70 , 1980-1983	
Fuel Filter.....	FC-1302	Oil Filter By Pass.....	0-1305	Air Filter.....	AS-1303
Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1309			Oil Filter Full Flow.....	0-1301
<b>KCXZU140M</b> (BUSES) HINO J05C , 1997		<b>KF702</b> (TRUCKS) HINO EF100 , 1972-1976		<b>K-FF170</b> (TRUCKS) HINO EL100 , 1980-UP	
Air Filter.....	A-1112	Fuel Filter.....	F-1303	Air Filter.....	AS-5709
Fuel Filter.....	FC-1302	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1301			Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	C-1309	<b>KF706</b> (TRUCKS) HINO EF300		<b>K-FF505</b> (TRUCKS) HINO EF550	
<b>KD164</b> (TRUCKS) HINO W06E , 1986-1989		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
Air Filter.....	A-1306	Oil Filter Full Flow.....	0-1301		
Oil Filter Full Flow.....	C-1301	Oil Filter By Pass.....	0-1305	<b>KFG182</b> (TRUCKS) HINO EL100 , 1980-1983	
Oil Filter Full Flow.....	C-1309			Air Filter.....	AS-5709
<b>KDGD1J</b> (TRUCKS) HINO J08C , 1994-1999		<b>KF724</b> (TRUCKS) HINO EF350 , 1979-1983		Fuel Filter.....	F-1303
Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-1301
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-13081		
Air Filter Set.....	A-6118-S	<b>KF783</b> (TRUCKS) HINO EF300 , 1977-1979		<b>KFH221</b> (TRUCKS) HINO EM100 , 1981-1983	
Oil Filter Combination.....	C-1303	Fuel Filter.....	F-1303	Air Filter Primary.....	A-6006
<b>KDGD1J</b> (TRUCKS) HINO J08CT , 1994-1999		Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-60400
Oil Filter Combination.....	C-1303	<b>K-FD120</b> (TRUCKS) HINO EC100 , 1980-UP		Air Filter Set.....	A-6118-S
<b>KF300</b> (TRUCKS) HINO EK100 , 1979-1981		Air Filter.....	A-1301	Fuel Filter.....	F-1304
Fuel Filter.....	F-1303	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301
Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1305
Oil Filter Full Flow.....	0-1301	<b>KFD121</b> (TRUCKS) HINO EC100 , 1980-1983		<b>KFH270</b> (TRUCKS) HINO EK100 , 1981-1983	
<b>KF300</b> (TRUCKS) HINO ED100 , 1971-1975		Fuel Filter.....	F-1303	Air Filter Primary.....	A-5425
Fuel Filter.....	F-1302	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1303	<b>KFD151</b> (TRUCKS) HINO EH500 , 1980-1983		Oil Filter By Pass.....	0-1311
<b>KF301</b> (TRUCKS) HINO EK100 , 1975-1979		Air Filter.....	AS-1303	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1303	Fuel Filter.....	F-1303	<b>KFN270</b> (TRUCKS) HINO EK100 , 1981-UP	
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-5425
Oil Filter By Pass.....	0-1305	<b>KFD152</b> (TRUCKS) HINO H06C-T , 1982-1983		Fuel Filter.....	F-1304
<b>KF501</b> (TRUCKS) HINO EH100		Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	0-13081
Air Filter.....	AS-1303	Air Filter Primary.....	A-6006	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1301	Air Filter Primary.....	A-60400	<b>KFN270</b> (TRUCKS) HINO EK100 , 1981-1983	
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303	Air Filter Primary.....	A-5425
<b>KF501</b> (TRUCKS) HINO EH300		Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
Air Filter.....	AS-1303	<b>KFD170</b> (TRUCKS) HINO EH500 , 1980-UP		Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1301	Air Filter.....	AS-1303	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303	<b>K-FN280</b> (TRUCKS) HINO EP100 , 1981-UP	
<b>KF545</b> (TRUCKS) HINO EF500 , 1976-1979		Oil Filter Full Flow.....	0-1301	Air Filter.....	AS-5709
Fuel Filter.....	F-1304	<b>KFD170</b> (TRUCKS) HINO EH700 , 1980-UP		Fuel Filter.....	F-1303
Oil Filter Full Flow.....	0-1301	Air Filter.....	AS-1303	Oil Filter Full Flow.....	0-1301
Oil Filter By Pass.....	0-1305	Fuel Filter.....	F-1303	<b>KFN282</b> (TRUCKS) HINO EP100	
<b>KF585</b> (TRUCKS) HINO EF500 , 1976-1979		Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304	<b>KFD171</b> (TRUCKS) HINO EH700 , 1980-1983		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1301	Air Filter.....	AS-1303	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1305	Fuel Filter.....	F-1303	Oil Filter By Pass.....	0-1311
		Oil Filter Full Flow.....	0-1301		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KFN282</b> <i>(TRUCKS)</i> HINO EP100T Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081		<b>KFP286</b> <i>(TRUCKS)</i> HINO EP100T , 1982-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311		<b>KFS630</b> <i>(TRUCKS)</i> HINO EF750 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305	
<b>KFN286</b> <i>(TRUCKS)</i> HINO EP100 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311		<b>KFP286</b> <i>(TRUCKS)</i> HINO EP100 Air Filter Primary..... A-5425 Oil Filter Full Flow..... 0-13081		<b>KFS633</b> <i>(TRUCKS)</i> HINO EF750 , 1981-1984 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081	
<b>KFN286</b> <i>(TRUCKS)</i> HINO EP100T Air Filter Primary..... A-5425 Oil Filter Full Flow..... 0-13081		<b>KFR272</b> <i>(TRUCKS)</i> HINO EK100 , 1980-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311		<b>KFS633</b> <i>(TRUCKS)</i> HINO EF7850T , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305	
<b>K-FN600</b> <i>(TRUCKS)</i> HINO EF550 , 1981-UP Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305		<b>KFR286</b> <i>(TRUCKS)</i> HINO EP100T , 1982-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081		<b>KFT173</b> <i>(TRUCKS)</i> HINO EH700 , 1981-1983 Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	
<b>KFN602</b> <i>(TRUCKS)</i> HINO EF550 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-13081		<b>KFR602</b> <i>(TRUCKS)</i> HINO EF550 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305		<b>KFW270</b> <i>(TRUCKS)</i> HINO EK100 , 1981-UP Air Filter Primary..... A-5425 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311	
<b>KFN630</b> <i>(TRUCKS)</i> HINO EF750 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081		<b>KFR634</b> <i>(TRUCKS)</i> HINO EF750 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-13081		<b>KFW274</b> <i>(TRUCKS)</i> HINO EK100 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081	
<b>KFN634</b> <i>(TRUCKS)</i> HINO EF750 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305		<b>KFS270</b> <i>(TRUCKS)</i> HINO EK100 , 1982-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311		<b>KG175</b> <i>(TRUCKS)</i> HINO H07C , 1986-1990 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309	
<b>KFP274</b> <i>(TRUCKS)</i> HINO EK100 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081		<b>KFS600</b> <i>(TRUCKS)</i> HINO EF550 , 1981-UP Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-13081		<b>KG175</b> <i>(TRUCKS)</i> HINO H07C , 1983-1986 Air Filter..... A-1306 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	
<b>KFP284</b> <i>(TRUCKS)</i> HINO EP100 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1311		<b>KFS600</b> <i>(TRUCKS)</i> HINO EF750 , 1981-UP Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1305		<b>KG300</b> <i>(TRACTORS)</i> 1971-UP Oil Filter Full Flow..... 0-1301	
<b>KFP284</b> <i>(TRUCKS)</i> HINO EP100T Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081		<b>KFS600</b> <i>(TRUCKS)</i> HINO EF550 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-13081		<b>KGD170</b> <i>(TRUCKS)</i> HINO EH700 , 1980-UP Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	
<b>KFP284</b> <i>(TRUCKS)</i> HINO EP100T Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1311 Oil Filter Full Flow..... 0-13081		<b>KFS600</b> <i>(TRUCKS)</i> HINO EF550 , 1981-1983 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1305 Oil Filter Full Flow..... 0-13081		<b>KGD171</b> <i>(TRACTORS)</i> HINO EH70 , 1980-1983 Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KG174</b> (TRACTORS) HINO EH700 , 1980-1983		Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	O-1301
Air Filter.....	AS-1303	Air Filter Primary.....	A-60400	Oil Filter By Pass.....	O-1310
Fuel Filter.....	F-1303	Air Filter Set.....	A-6118-S	<b>KHU235</b> (TRUCKS) HINO M10U , 1985	
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	F-1304	Air Filter Primary.....	A-6006
<b>KG272</b> (TRUCKS) HINO EK100 , 1981-1983		Oil Filter Full Flow.....	O-1301	Air Filter Primary.....	A-60400
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	O-1310	Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1304	<b>KHT223</b> (TRUCKS) HINO ER200 , 1983-1985		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Air Filter.....	AS-5709	Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1311	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
<b>KG282</b> (TRUCKS) HINO EP100T , 1981-1983		Oil Filter Full Flow.....	O-1301	<b>KHT275</b> (TRUCKS) HINO EK200 , 1985	
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	O-1310	Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304	<b>K-HT223.225.226</b> (TRUCKS) HINO ER200 , 1984-1985		Air Filter.....	A-1119
Oil Filter By Pass.....	O-1311	Air Filter.....	AS-5709	Fuel Filter.....	FC-1801
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	FC-1501
<b>KH120</b> (CRANES) HINO EB300 , 1972-1977		Oil Filter Full Flow.....	O-1301	<b>KHV10</b> (TRUCKS) HINO B , 1979-UP	
Fuel Filter.....	F-1302	Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1501
Oil Filter Full Flow.....	O-1303	<b>K-HT223.225.236</b> (TRUCKS) HINO M10U , 1985-UP		<b>KHV10</b> (TRUCKS) HINO B , 1979-1983	
<b>KHE356</b> (TRUCKS) HINO EF500 , 1979-1983		Air Filter Set.....	A-6118-S	Air Filter.....	A-1119
Fuel Filter.....	F-1304	Air Filter Primary.....	A-6006	Fuel Filter.....	FC-1801
Oil Filter Full Flow.....	O-13081	Air Filter Primary.....	A-60400	<b>KHV17</b> (TRUCKS) HINO 3B , 1980-UP	
<b>K-HE366</b> (TRACTORS) HINO EF700 , 1979-UP		Fuel Filter.....	F-1304	Fuel Filter.....	FC-1501
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301	<b>KHV17</b> (TRUCKS) HINO B , 1980-UP	
<b>KHE526</b> (TRUCKS) HINO EV700 , 1979-1983		Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1501
Fuel Filter.....	F-1304	<b>KHT225</b> (TRUCKS) HINO M10U , 1985-UP		<b>KHV20</b> (TRUCKS) HINO DG , 1979-1983	
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-6006	Air Filter.....	A-1119
Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-60400	Fuel Filter.....	F-1803
Oil Filter By Pass.....	O-1305	Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	C-1005
<b>KHE526</b> (TRUCKS) HINO EV700 , 1978-UP		Fuel Filter.....	F-1304	<b>KHV48</b> (TRUCKS) HINO 3B , 1983	
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301	Air Filter.....	A-1119
Oil Filter By Pass.....	O-1305	Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1801
Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	O-1301	<b>KJ500</b> (TRUCKS) HINO EH100 , 1973-1980	
Oil Filter Full Flow.....	C-1309	<b>KHT275</b> (TRUCKS) HINO EK200 , 1983-1985		Air Filter.....	AS-1303
<b>KHH341</b> (TRACTORS) HINO EF700 , 1979-1981		Fuel Filter.....	F-1304	Fuel Filter.....	F-1301
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-1301
<b>KHH341</b> (TRACTORS) HINO EF700		Oil Filter Full Flow.....	O-1301	<b>KJ500</b> (TRUCKS) HINO EH300	
Fuel Filter.....	F-1304	<b>K-HT275.276</b> (TRUCKS) HINO EK200 , 1985-UP		Air Filter.....	AS-1303
<b>KHH541</b> (TRACTORS) HINO EV700 , 1979-UP		Air Filter Primary.....	A-5425	Fuel Filter.....	F-1301
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
<b>KHH541</b> (TRUCKS) HINO EV700 , 1979-1991		Oil Filter Full Flow.....	O-1301	<b>KJ501</b> (TRUCKS) HINO EH100	
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Air Filter.....	AS-1303
Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	O-1301	<b>KHU223</b> (TRUCKS) HINO ER200 , 1983-1985	
<b>KHT223</b> (TRUCKS) HINO M10U , 1985-UP		<b>KHT275</b> (TRUCKS) HINO EK200 , 1983-1985		Air Filter.....	AS-5709
Air Filter.....	AS-5709	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1303	Oil Filter By Pass.....	O-1310		

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KJ501</b> (TRUCKS) HINO EH100		Fuel Filter.....	FC-1707	<b>KKFJ1J</b> (TRUCKS) HINO J08C , 1999	
Fuel Filter.....	F-1301	Oil Filter Combination.....	C-1112	Air Filter Primary.....	A-1156
Oil Filter Full Flow.....	O-1301	<b>KKBU400M</b> (TRUCKS) HINO 15BFTE , 1999		Air Filter Set.....	A-1156-S
<b>KJ501</b> (TRUCKS) HINO EH300		Fuel Filter.....	FC-1707	<b>KKG175</b> (TRUCKS) HINO H07C , 1983-1986	
Air Filter.....	AS-1303	Oil Filter Combination.....	C-1112	Air Filter.....	A-1306
Fuel Filter.....	F-1301	<b>K-KC562</b> (TRACTORS) HINO EF700 , 1979-UP		Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
<b>KK188</b> (TRUCKS) HINO EL100 , 1981-1984		<b>KKF301</b> (TRUCKS) HINO EK100 , 1979-1981		<b>KKG175</b> (TRUCKS) HINO EH700 , 1981-1983	
Fuel Filter.....	F-1303	Fuel Filter.....	F-1303	Air Filter.....	AS-1303
Oil Filter Full Flow.....	O-1301	Oil Filter By Pass.....	O-1305	Fuel Filter.....	F-1303
<b>KK19</b> (TRUCKS) HINO H06C-T , 1986-1989		Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301
Air Filter Primary.....	A-6006	<b>KKF505</b> (TRUCKS) HINO EF500 , 1979-UP		<b>KKHD850M</b> (TRUCKS) HINO 1HDFTE , 1999	
Air Filter Primary.....	A-60400	Fuel Filter.....	F-1304	Fuel Filter.....	FC-1707
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	O-13081	Oil Filter Combination.....	C-1112
Oil Filter Combination.....	C-1303	<b>KKF545</b> (TRUCKS) HINO EF500 , 1979-1981		<b>KKHDB50M</b> (TRUCKS) HINO 1HDFTE , 1999	
<b>KK19</b> (TRUCKS) HINO H06C-T , 1983-1986		Fuel Filter.....	F-1304	Fuel Filter.....	FC-1707
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	O-13081	Oil Filter Combination.....	C-1112
Air Filter Primary.....	A-6006	<b>KKF700</b> (TRUCKS) HINO EF350 , 1979-UP		<b>KKHZ841M</b> (TRUCKS) HINO 1HZ , 1999	
Air Filter Primary.....	A-60400	Fuel Filter.....	F-1304	Air Filter.....	A-1112
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1707
<b>KK196T</b> (TRUCKS) HINO H06C-T , 1984-1986		<b>KKF704</b> (TRUCKS) HINO EF350 , 1979-1983		Oil Filter Combination.....	C-1112
Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303	<b>KKHZB40M</b> (TRUCKS) HINO 1HZ , 1999	
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	O-13081	Air Filter.....	A-1112
Air Filter Set.....	A-6118-S	<b>KKFC1J</b> (TRUCKS) HINO J08C , 1999		Fuel Filter.....	FC-1707
Fuel Filter.....	F-1303	Air Filter.....	A-1308	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	O-1301	Air Filter Set.....	A-1156-S	<b>KKK180</b> (TRUCKS) HINO EL100	
<b>KKB314</b> (TRUCKS) HINO EB300 , 1979-1981		Air Filter Primary.....	A-1156	Air Filter.....	AS-5709
Fuel Filter.....	F-1302	Fuel Filter.....	FC-1302	Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1303	<b>KKFC1JCDD</b> (TRUCKS) HINO J08C , 2001		Oil Filter Full Flow.....	O-1301
<b>KKB364</b> (TRUCKS) HINO EB300 , 1979-1981		Air Filter Primary.....	A-1156	<b>KKK188</b> (TRUCKS) HINO EL100 , 1981-1984	
Fuel Filter.....	F-1302	Air Filter Set.....	A-1156-S	Air Filter.....	AS-5709
Oil Filter Full Flow.....	O-1303	<b>KKFC1JCDD</b> (TRUCKS) HINO J08C , 1999-2001		Fuel Filter.....	F-1303
<b>KKB501</b> (TRUCKS) HINO EK100 , 1979-UP		Air Filter Set.....	A-1156-S	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	F-1303	Air Filter Primary.....	A-1156	<b>K-KL300</b> (TRUCKS) HINO EC100 , 1969-UP	
Oil Filter Full Flow.....	O-1301	<b>KKFC1W</b> (TRUCKS) HINO W04D , 2000		Air Filter.....	A-1301
Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1301
<b>KKB721</b> (TRUCKS) HINO EB300 , 1980-UP		Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	O-1301
Fuel Filter.....	F-1302	<b>KKFC3J</b> (TRUCKS) HINO J07C , 1999		<b>KKL500</b> (TRUCKS) HINO EH100 , 1972-1979	
Oil Filter Full Flow.....	O-1303	Air Filter Primary.....	A-1156	Air Filter.....	AS-1303
<b>KKBB58M</b> (TRUCKS) HINO 15BFTE , 1999		Air Filter Set.....	A-1156-S	Fuel Filter.....	F-1301
Air Filter.....	A-1112	<b>KKFJ1</b> (TRUCKS) HINO J08C , 1999		Oil Filter Full Flow.....	O-1301
Fuel Filter.....	FC-1707	Air Filter Set.....	A-1156-S	<b>KKL501</b> (TRUCKS) HINO EH300 , 1974-1979	
Oil Filter Combination.....	C-1112	Air Filter Primary.....	A-1156	Air Filter.....	AS-1303
<b>KKBU301X</b> (TRUCKS) CUMMINS 4B , 1999		<b>KKFJ1</b> (TRUCKS) HINO J08C , 1999		Fuel Filter.....	F-1301
		Air Filter Set.....	A-1156-S		
		Air Filter Primary.....	A-1156		

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
KKL501 (TRUCKS) HINO EH300 , 1974-1979 Oil Filter Full Flow.....	0-1301	KKS341 (TRUCKS) HINO EK100 , 1979-1981 Fuel Filter.....	F-1303	KKXZU341M (TRUCKS) HINO 15BLPG , 2000 Oil Filter Combination.....	C-1112
KKL505 (TRUCKS) HINO EH700 , 1977-1979 Air Filter.....	AS-1303	Oil Filter By Pass.....	0-1305	KKXZU350E (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206
Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301	KKXZU351T (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
Oil Filter Full Flow.....	0-1301	KKXZ302E (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	KKXZU371M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
KKL545 (TRUCKS) HINO EH700 , 1979-1980 Air Filter.....	AS-1303	KKXZU300 (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1707	KKXZU371M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
Fuel Filter.....	F-1303	KKXZU300E (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206	KKXZU382M (TRUCKS) HINO S05C , 1999-2002 Fuel Filter.....	FC-1707
Oil Filter Full Flow.....	0-1301	KKXZU301 (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	KKXZU400M (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206
KKL561 (TRUCKS) HINO EH100 , 1974-1979 Air Filter.....	AS-1303	KKXZU301E (TRUCKS) HINO 15BLPG , 2000 Oil Filter Combination.....	C-1112	KKXZU401M (TRUCKS) HINO S05D , 2002 Fuel Filter.....	FC-1707
Fuel Filter.....	F-1301	KKXZU301E (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707	KKXZU401M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
Oil Filter Full Flow.....	0-1301	KKXZU301T (TRUCKS) HINO S05D , 2002 Fuel Filter.....	FC-1707	KKXZU401M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
KKRH4J (TRUCKS) HINO J05CT , 1995 Air Filter Set.....	A-1156-S	KKXZU301X (TRUCKS) HINO 15BLPG , 2000 Oil Filter Combination.....	C-1112	KKXZU402M (TRUCKS) HINO S05C , 1999-2002 Fuel Filter.....	FC-1707
Air Filter Primary.....	A-1156	KKXZU302E (TRUCKS) HINO S05C , 1999-2002 Fuel Filter.....	FC-1707	KKXZU410M (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206
KKRH4JEEA (TRUCKS) HINO J05CT , 2001 Air Filter Primary.....	A-1156	KKXZU310X (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206	KKXZU412 (TRUCKS) HINO 15BCNG , 2000-2002 Fuel Filter.....	FC-1707
Air Filter Set.....	A-1156-S	KKXZU311X (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707	Oil Filter Combination.....	C-1112
KKRH4JEEA (TRUCKS) HINO J05CT , 1999-2001 Air Filter Set.....	A-1156-S	KKXZU312 (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	KKXZU420M (TRUCKS) HINO S05C , 2002 Fuel Filter.....	FC-1206
Air Filter Primary.....	A-1156	KKXZU321X (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707	KKXZU420M (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1206
KKRR1J (TRUCKS) HINO J08CT , 1999 Oil Filter Combination.....	C-1303	KKXZU32M (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	KKXZU421M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707
KKRX4J (TRUCKS) HINO J05C , 1999 Air Filter Primary.....	A-1156	KKXZU330M (TRUCKS) HINO J05C , 1999-2002 Fuel Filter.....	FC-1206	KKXZU430M (TRUCKS) HINO J05C , 2002 Fuel Filter.....	FC-1206
Air Filter Set.....	A-1156-S	KKXZU331M (TRUCKS) HINO S05D , 1999-2002 Fuel Filter.....	FC-1707	KKXZU430M (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1206
Fuel Filter.....	FC-1302				
KKRX4J (TRUCKS) HINO J05CT , 1999 Air Filter Set.....	A-1156-S				
Air Filter Primary.....	A-1156				
KKRX4JFEA (TRUCKS) HINO J05CT , 2001 Air Filter Primary.....	A-1156				
Air Filter Set.....	A-1156-S				
KKRX4JFEA (TRUCKS) HINO J05CT , 1999-2001 Air Filter Set.....	A-1156-S				
Air Filter Primary.....	A-1156				
KKRX4JFEA (TRUCKS) HINO J05C , 1999 Air Filter Primary.....	A-1156				
Air Filter Set.....	A-1156-S				
Fuel Filter.....	FC-1302				

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KL300</b> (TRUCKS) HINO EC100 , 1971-1984		Oil Filter Full Flow.....	0-1301	<b>KR305</b> (TRUCKS) HINO EH700 , 1977-1980	
Air Filter.....	A-1301	<b>KL580</b> (TRUCKS) HINO EC100		Air Filter.....	AS-1303
Fuel Filter.....	F-1301	Air Filter.....	A-1301	Fuel Filter.....	F-1301
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301
<b>KL300</b> (TRUCKS) HINO EH100 , 1971-1984		Oil Filter Full Flow.....	0-1301	<b>KR321</b> (TRUCKS) HINO EH300 , 1971-1977	
Air Filter.....	A-1301	<b>KLFJ1JDD</b> (TRUCKS) HINO J08C , 1999-2001		Air Filter.....	AS-1303
Fuel Filter.....	F-1301	Air Filter Set.....	A-1156-S	Fuel Filter.....	F-1301
Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-1156	Oil Filter Full Flow.....	0-1301
<b>KL340</b> (TRUCKS) HINO EC100 , 1981		<b>KM300</b> (TRUCKS) HINO DM100 , 1971-UP		<b>KR325</b> (TRUCKS) HINO EH700 , 1977-1980	
Air Filter.....	A-1301	Fuel Filter.....	F-1301	Air Filter.....	AS-1303
Fuel Filter.....	F-1301	<b>KM300</b> (TRUCKS) HINO DQ100 , 1971-UP		Fuel Filter.....	F-1301
Fuel Filter.....	F-1303	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	<b>KM5</b> (TRUCKS) HINO W04D , 1983-1986		<b>KR3320</b> (TRUCKS) HINO EF500 , 1980-1982	
<b>KL350</b> (TRUCKS) HINO EC100 , 1979-1980		Fuel Filter.....	FC-1302	Fuel Filter.....	F-1304
Air Filter.....	A-1301	Oil Filter Full Flow.....	C-1302	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1301	<b>KM500</b> (TRUCKS) HINO W04D , 1983		<b>KR360</b> (TRUCKS) HINO EH100	
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	FC-1302	Oil Filter Full Flow.....	0-1301
<b>KL360</b> (TRUCKS) HINO EC100		<b>KM500</b> (TRUCKS) HINO DQ100 , 1979-1983		<b>KR360E</b> (TRUCKS) HINO EC300 , 1979	
Oil Filter Full Flow.....	0-1301	Air Filter.....	A-1301	Air Filter.....	AS-1303
<b>KL500</b> (TRUCKS) HINO EC100 , 1981-UP		Fuel Filter.....	F-1301	Fuel Filter.....	F-1301
Oil Filter Full Flow.....	0-1301	<b>KM500</b> (TRUCKS) HINO DM100 , 1971-UP		Oil Filter Full Flow.....	0-1301
<b>KL500</b> (TRUCKS) HINO EC100 , 1973-1980		Fuel Filter.....	F-1301	<b>KR360E</b> (TRUCKS) HINO EC100	
Air Filter.....	AS-1303	<b>KM500</b> (TRUCKS) HINO DQ100 , 1971-UP		Air Filter.....	AS-1303
Fuel Filter.....	F-1301	Fuel Filter.....	F-1301	Fuel Filter.....	F-1301
Oil Filter Full Flow.....	0-1301	<b>KM505</b> (TRUCKS) HINO W04D , 1983-1986		<b>KRC301</b> (TRUCKS) HINO ER200 , 1978-1984	
<b>KL501</b> (TRUCKS) HINO EH100		Fuel Filter.....	FC-1302	Air Filter.....	AS-5709
Air Filter.....	AS-1303	<b>KQ500</b> (TRUCKS) HINO DQ100 , 1971-1979		Fuel Filter.....	F-1304
Fuel Filter.....	F-1301	Air Filter.....	A-1301	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1301	Oil Filter By Pass.....	0-1305
<b>KL501</b> (TRUCKS) HINO EH300		<b>KR300</b> (TRUCKS) HINO EC700 , 1972-1977		<b>KRC381</b> (TRUCKS) HINO ER200 , 1980-1984	
Air Filter.....	AS-1303	Air Filter.....	AS-1303	Air Filter.....	AS-5709
Fuel Filter.....	F-1301	Fuel Filter.....	F-1301	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1305
<b>KL505</b> (TRUCKS) HINO EH700 , 1977-1980		<b>KR300</b> (TRUCKS) HINO EH300 , 1972-1977		Oil Filter Full Flow.....	0-1301
Air Filter.....	AS-1303	Air Filter.....	AS-1303	<b>KRC701</b> (TRUCKS) HINO ER200 , 1980-1983	
Fuel Filter.....	F-1301	Fuel Filter.....	F-1301	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301
<b>KL540</b> (BUSES) HINO EH100 , 1979-1980		<b>KR301</b> (TRUCKS) HINO EH300 , 1972-1977		<b>K-RC701.721</b> (TRUCKS) HINO EK200 , 1980-1984	
Air Filter.....	AS-1303	Air Filter.....	AS-1303	Fuel Filter.....	F-1304
Fuel Filter.....	F-1301	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1310
<b>KL580</b> (TRUCKS) HINO EH100 , 1975-1979		<b>KR301</b> (TRUCKS) HINO EH300 , 1972-1977		Oil Filter Full Flow.....	0-1301
Air Filter.....	A-1301	Air Filter.....	AS-1303	<b>KRD301</b> (TRUCKS) HINO EH700 , 1980-UP	
Fuel Filter.....	F-1301	Fuel Filter.....	F-1301	Air Filter.....	AS-1303
		Oil Filter Full Flow.....	0-1301		



# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>					
<b>KRD301</b> (TRUCKS) HINO EH700 , 1980-UP		<b>KRT223</b> (TRUCKS) HINO EM100 , 1982-1983		<b>KRV731</b> (TRUCKS) HINO EF350 , 1980-1982	
Fuel Filter.....	F-1301	Air Filter Primary.....	A-6006	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-13081
<b>KRD301</b> (TRUCKS) HINO EH700 , 1980-1984		Air Filter Set.....	A-6118-S	<b>KRV732</b> (TRUCKS) HINO EF350 , 1979-UP	
Air Filter.....	AS-1303	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1305		
<b>KRD301</b> (TRUCKS) HINO EH700 , 1980-1983		Oil Filter By Pass.....	0-1310	<b>KS341</b> (TRUCKS) HINO EK100 , 1981-UP	
Air Filter.....	AS-1303	<b>K-RT223.225.226</b> (TRUCKS) HINO EM100 , 1983-UP		Fuel Filter.....	F-1303
Fuel Filter.....	F-1303	Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	Air Filter Primary.....	A-6006	<b>KS341</b> (TRUCKS) HINO EK100 , 1974-1980	
<b>KRJ170</b> (TRUCKS) HINO EH700 , 1980-UP		Air Filter Primary.....	A-60400	Fuel Filter.....	F-1303
Air Filter.....	AS-1303	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1303	Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1305
Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301	<b>KS390</b> (TRUCKS) HINO EK100	
<b>KRJ170</b> (BUSES) HINO EH700 , 1980-1983		<b>KRU223</b> (TRUCKS) HINO EM100 , 1982-1983		Fuel Filter.....	F-1303
Air Filter.....	AS-1303	Air Filter Primary.....	A-6006	Oil Filter By Pass.....	0-1305
Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304	<b>KS391</b> (TRUCKS) HINO EK100 , 1975-1979	
<b>KRL301</b> (BUSES) HINO EH700 , 1980		Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303
Air Filter.....	AS-1303	Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1303	Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1305
Oil Filter Full Flow.....	0-1301	<b>KRU226</b> (TRUCKS) HINO EM100 , 1983		<b>KSD171</b> (TRUCKS) HINO EH700 , 1980-1984	
<b>KRR170</b> (TRUCKS) HINO EH700 , 1982-1986		Air Filter Set.....	A-6118-S	Air Filter.....	AS-1303
Air Filter.....	AS-1303	Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303
Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304	<b>KSH275</b> (TRUCKS) HINO EK100 , 1982-1983	
<b>KRS120</b> (TRUCKS) HINO EF300 , 1979-1980		Oil Filter By Pass.....	0-1310	Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-1301	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1305	<b>KRU606</b> (TRUCKS) HINO EF550 , 1982-1984		Oil Filter By Pass.....	0-1311
<b>KRS121</b> (TRUCKS) HINO EF350 , 1980-UP		Air Filter Primary.....	A-5425	<b>KSH331</b> (TRUCKS) HINO K13CT , 1986-1991	
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311
<b>KRS141P</b> (TRUCKS) HINO EF350		Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	<b>K-SH600</b> (TRUCKS) HINO EF550	
Oil Filter Full Flow.....	0-13081	<b>KRU636</b> (TRUCKS) HINO EF550 , 1982-1984		Air Filter Primary.....	A-5425
<b>KRS320</b> (TRUCKS) HINO EF500 , 1980-1982		Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	<b>K-SH600</b> (TRUCKS) HINO EF700	
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Air Filter Primary.....	A-5425
<b>KRS360P</b> (TRUCKS) HINO EF500		Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	<b>KRV561</b> (TRUCKS) HINO EF500 , 1979-UP		<b>KSH601</b> (TRUCKS) HINO EF550 , 1981-1983	
Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425
		Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304
				Oil Filter Full Flow.....	0-13081

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KSH601</b> (TRUCKS) HINO EF550 , 1981-1983 Oil Filter By Pass.....	0-1305	<b>K-TC303</b> (TRUCKS) HINO EK100 Oil Filter By Pass.....	0-1305	Fuel Filter.....	F-1301
<b>KSH631</b> (TRUCKS) HINO EF750 , 1981-1983 Air Filter Primary.....	A-5425	<b>KTC323</b> (TRUCKS) HINO EK100 , 1979-1981 Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1305	<b>KWD300</b> (TRACTORS) HINO EK100 , 1980-1989 Fuel Filter.....	F-1303
Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-13081	<b>KTC562</b> (TRACTORS) HINO EF700 , 1979-UP Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1305
<b>KSH631</b> (TRUCKS) HINO EF750T , 1981-1983 Air Filter Primary.....	A-5425	<b>KTC582</b> (TRUCKS) HINO EF500 , 1980-UP Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1305
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	<b>KZC101</b> (TRUCKS) HINO EK100 , 1979-1981 Fuel Filter.....	F-1303
Oil Filter Full Flow.....	0-13081	<b>KTC585</b> (TRUCKS) HINO EF100 , 1980-1981 Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1305
Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-1301
<b>K-SH710</b> (TRACTORS) HINO EV700 , 1981-UP Fuel Filter.....	F-1304	<b>K-TC585.723.743.763.783</b> (TRUCKS) HINO EF700 , 1977-1981 Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1305
Oil Filter By Pass.....	0-1305	<b>K-TC703</b> (TRUCKS) HINO EF350 , 1979-UP Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	0-13081	<b>KZC121</b> (TRUCKS) HINO EK100 , 1979-1981 Fuel Filter.....	F-1303
Oil Filter Full Flow.....	C-1309	<b>KTC723</b> (TRUCKS) HINO EF350 , 1979-1981 Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1305
Oil Filter By Pass.....	0-1305	<b>KTC922</b> (TRUCKS) HINO EK100 , 1975-UP Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-1301
<b>K-S5630</b> (TRUCKS) HINO EF550 , 1981-UP Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-13081	<b>KU581</b> (TRUCKS) HINO EH300 , 1975-1980 Air Filter.....	AS-1303	<b>KZM103</b> (TRUCKS) HINO EK100 , 1976-1984 Fuel Filter.....	F-1303
<b>K-S5630</b> (TRUCKS) HINO EF700 , 1981-UP Air Filter Primary.....	A-5425	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-1301
Oil Filter Full Flow.....	0-13081	<b>KVSS3V</b> (TRUCKS) HINO V26C , 1995 Fuel Filter.....	FC-1305	<b>KZM302</b> (TRUCKS) HINO EK100 , 1975-1981 Fuel Filter.....	F-1303
Oil Filter By Pass.....	0-1305	Fuel Filter Primary.....	FC-1310	Oil Filter By Pass.....	0-1305
<b>KSS631</b> (TRUCKS) HINO EF750 , 1981-1983 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1309	<b>KZM500</b> (TRUCKS) HINO EF500 , 1979-UP Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1305	<b>KWB311</b> (BUSES) HINO EH100 , 1980-1981 Air Filter.....	AS-1303	<b>KZM500</b> (TRUCKS) HINO EF500 , 1979-1981 Fuel Filter.....	F-1304
<b>KSS691</b> (TRUCKS) HINO V21C , 1987-1991 Fuel Filter.....	F-1304	Fuel Filter.....	F-1301	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-1301	<b>KZM704</b> (TRUCKS) HINO EF300 , 1977-1979 Fuel Filter.....	F-1304
<b>K-SS710</b> (TRACTORS) HINO EV700 , 1981-UP Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	0-1301
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1305
<b>KSS711</b> (TRUCKS) HINO EV700 , 1981-1983 Fuel Filter.....	F-1304	<b>KWB311</b> (TRUCKS) HINO EH100 , 1978 Air Filter.....	AS-1303	<b>KZM705</b> (TRUCKS) HINO EF350 , 1979-UP Fuel Filter.....	F-1304
Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	0-13081
				<b>KZM705</b> (TRUCKS) HINO EF350 , 1979-1981	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>KZM705</b> (TRUCKS) HINO EF350 , 1979-1981		<b>LIESSE</b> (BUSES) 4.0L N04C-T BDG-XZB50M , 4000, 2007-2011		Air Filter.....	A-1112
Fuel Filter.....	F-1304	Air Filter.....	A-1158	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1318		
<b>KZM940</b> (TRUCKS) HINO EF700T , 1980-1981		<b>LIESSE</b> (BUSES) 4.0L N04C-T BDG-XZB51M , 4000, 2007-2011		<b>LIESSE</b> (BUSES) 4.2L 1HD-FTE KK-HDB50M , 4200, 1999-2004	
Fuel Filter.....	F-1304	Air Filter.....	A-1158	Air Filter.....	A-1158
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1318	Oil Filter Combination.....	C-1112
<b>K-ZT320</b> (CRANES) HINO EB300 , 1979-UP		<b>LIESSE</b> (BUSES) 3.4L 3B KC-BB40M , 3400, 1997-1999		<b>LIESSE</b> (BUSES) 4.2L 1HD-FTE KK-HDB51M , 4200, 1999-2004	
Fuel Filter.....	F-1302	Air Filter.....	A-1119	Air Filter.....	A-1158
Oil Filter Full Flow.....	O-1303			Oil Filter Combination.....	C-1112
<b>LA540</b> (TRUCKS) HINO EH100		<b>LIESSE</b> (BUSES) 4.1L 15B-F KC-BB55M , 4100, 1997-1999		<b>LIESSE</b> (BUSES) 4.2L 1HZ KK-HZB40M , 4200, 1999-2004	
Air Filter.....	AS-1303	Air Filter.....	A-1112	Air Filter.....	A-1112
Fuel Filter.....	F-1303	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	C-1005				
Oil Filter Full Flow.....	O-1301	<b>LIESSE</b> (BUSES) 4.1L 15B-F KC-BB58M , 4100, 1997-1999		<b>LIESSE</b> (BUSES) 4.2L 1HZ KK-HZB41M , 4200, 1999-2004	
<b>LB500</b> (TRUCKS) HINO EH100		Air Filter.....	A-1112	Air Filter.....	A-1112
Air Filter.....	AS-1303	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1112
Fuel Filter.....	F-1301	<b>LIESSE</b> (BUSES) 4.2L 1HD-FT KC-HDB50M , 4200, 1996-1999		<b>LIESSE</b> (BUSES) 4.2L 1HZ KK-HZB50M , 4200, 1999-2004	
Oil Filter Full Flow.....	O-1301	Air Filter.....	A-1112	Air Filter.....	A-1112
<b>LB500</b> (TRUCKS) HINO EH300		Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1112
Air Filter.....	AS-1303	<b>LIESSE</b> (BUSES) 4.2L 1HD-FT KC-HDB51M , 4200, 1997-1999		<b>LIESSE</b> (BUSES) 5.3L J05C KK-RX4JFE , 5300, 1999-2004	
Fuel Filter.....	F-1301	Air Filter.....	A-1112	Air Filter Primary.....	A-1156
Oil Filter Full Flow.....	O-1301	Oil Filter Combination.....	C-1112	Air Filter Set.....	A-1156-S
<b>LB595</b> (TRUCKS) HINO EH100 , 1976-1978		<b>LIESSE</b> (BUSES) 4.2L 1HZ KC-HZB40M , 4200, 1996-1999		Fuel Filter.....	FC-1301
Fuel Filter.....	F-1301	Air Filter.....	A-1112	Oil Filter Combination.....	C-1321
Oil Filter Full Flow.....	O-1301	Oil Filter Combination.....	C-1112	<b>LIESSE</b> (BUSES) 5.3L J05C-T KK-RX4JFE{-40822} , 5300, 1999-2001	
<b>LB700</b> (TRUCKS) HINO EL100 , 1978-1980		<b>LIESSE</b> (BUSES) 4.2L 1HZ KC-HZB41M , 4200, 1996-1999		Air Filter Primary.....	A-1156
Air Filter.....	AS-5709	Air Filter.....	A-1112	Air Filter Set.....	A-1156-S
Fuel Filter.....	F-1303	Oil Filter Combination.....	C-1112	Oil Filter Combination.....	C-1315
Oil Filter Full Flow.....	O-1301	<b>LIESSE</b> (BUSES) 4.2L 1HZ KC-HZB50M , 4200, 1996-1999		<b>LIESSE</b> (BUSES) 5.3L J05C-T KK-RX4JFE{40823-} , 5300, 2001-2004	
<b>LB720</b> (TRUCKS) HINO EL100 , 1978-1980		Air Filter.....	A-1112	Air Filter Primary.....	A-1156
Air Filter.....	AS-5709	Oil Filter Combination.....	C-1112	Air Filter Set.....	A-1156-S
Fuel Filter.....	F-1303	<b>LIESSE</b> (BUSES) 5.3L J05C KC-RX4JFA , 5300, 1995-1999		<b>LIESSE</b> (BUSES) 4.1L 1BZ-FPE LD-BZB40M , 4100, 2004-2007	
Oil Filter Full Flow.....	O-1301	Air Filter Primary.....	A-1156	Oil Filter Combination.....	C-1112
<b>LIESSE</b> (BUSES) 4.7L J05D-T , 4700		Air Filter Set.....	A-1156-S	<b>LIESSE</b> (BUSES) 4.1L 1BZ-FPE LD-BZB50M , 4100, 2004-2007	
Oil Filter Full Flow.....	C-1325	Fuel Filter.....	FC-1302	Oil Filter Combination.....	C-1112
<b>LIESSE</b> (BUSES) 4.8L J05D-T BDG-RX6JFB , 4800, 2007-2011		Oil Filter Full Flow.....	C-1301	<b>LIESSE</b> (BUSES) 4.1L 1BZ-FPE NBG-BZB40M , 4100, 2007	
Air Filter Primary.....	A-1156	Oil Filter Full Flow.....	C-1309	Oil Filter Combination.....	C-1112
Air Filter Set.....	A-1156-S	<b>LIESSE</b> (BUSES) 5.3L J05C-T KK-RX4JFA , 5300, 1995-1999		<b>LIESSE</b> (BUSES) 4.7L J05D-T PB-RX6JFA , 4700, 2004-2007	
Oil Filter Full Flow.....	C-1325	Air Filter Primary.....	A-1156	Air Filter Primary.....	A-1324
Oil Filter Combination.....	C-1304	Air Filter Set.....	A-1156-S	Air Filter Primary.....	A-1324M
<b>LIESSE</b> (BUSES) 4.0L N04C-T BDG-XZB40M , 4000, 2007-2011		Fuel Filter.....	FC-1301	Air Filter Set.....	A-1324-S
Air Filter.....	A-1158	Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-1324M-S
Oil Filter Full Flow.....	C-1318	Oil Filter Full Flow.....	C-1309	Oil Filter Combination.....	C-1304
<b>LIESSE</b> (BUSES) 4.0L N04C-T BDG-XZB50M , 4000, 2007-2011		<b>LIESSE</b> (BUSES) 4.1L 15B-FTE KK-BB58M , 4100, 1999-2004			
Air Filter.....	A-1158	Air Filter Primary.....	A-1156		
Oil Filter Full Flow.....	C-1318	Air Filter Set.....	A-1156-S		
		Fuel Filter.....	FC-1302		
		Oil Filter Full Flow.....	C-1301		
		Oil Filter Full Flow.....	C-1309		
		<b>LIESSE</b> (BUSES) 5.3L J05C-T KK-RX4JFA , 5300, 1995-1999			
		Air Filter Primary.....	A-1156		
		Air Filter Set.....	A-1156-S		
		Fuel Filter.....	FC-1301		
		Oil Filter Full Flow.....	C-1325		
		Oil Filter Combination.....	C-1304		
		<b>LIESSE</b> (BUSES) 4.1L 15B-FTE KK-BB58M , 4100, 1999-2004			
		Air Filter.....	A-1158		
		Oil Filter Full Flow.....	C-1318		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>LIESSE (BUSES)</b> 4.7L J05D-T PB-RX6JFA , 4700, 2004-2007 Oil Filter Full Flow..... C-1325		Oil Filter Full Flow..... C-1318  <b>LIESSE (BUSES)</b> 4.0L N04C-T SDG-XZB50M , 4000, 2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Fuel Filter..... FC-1301 Oil Filter Full Flow..... C-1325 Oil Filter Combination..... C-1304	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PB-XZB40M , 4000, 2004-2007 Air Filter..... A-1158 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		<b>LIESSE (BUSES)</b> 4.0L N04C-T SDG-XZB51M , 4000, 2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>MELPHA (BUSES)</b> J08C KK-CH1JFE(-40139) , CH, 1999-2001 Air Filter..... A-1311 Fuel Filter..... FC-1301 Oil Filter Combination..... C-1315	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PB-XZB46Y , 4000, 2004-2007 Air Filter..... A-1158 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		<b>LIESSE (BUSES)</b> 4.0L N04C-T SDG-XZB56Y , 4000, 2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>MELPHA (BUSES)</b> J08C KK-CH1JFE(40140-) , CH, 2001-2004 Air Filter..... A-1311 Fuel Filter..... FC-1301	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PB-XZB50M , 4000, 2004-2007 Air Filter..... A-1158 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		<b>LIESSE (BUSES)</b> 4.0L N04C-T SKG-XZB40M , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J05C-T KK-RH4JEE(-40055) , RH, 1999-2001 Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S Oil Filter Combination..... C-1315	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PB-XZB51M , 4000, 2004-2007 Air Filter..... A-1158 Oil Filter Combination..... C-1320 Oil Filter Combination..... C-1317		<b>LIESSE (BUSES)</b> 4.0L N04C-T SKG-XZB46Y , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J05C-T KK-RH4JEE(40056-) , RH, 2001-2004 Air Filter Primary..... A-1156 Air Filter Set..... A-1156-S	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PB-XZB56Y , 4000, 2004-2007 Air Filter..... A-1158 Oil Filter Combination..... C-1317 Oil Filter Combination..... C-1320		<b>LIESSE (BUSES)</b> 4.0L N04C-T SPG-XZB40M , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J08C KK-RR1J , RR, 2001-2004 Air Filter..... A-1311 Fuel Filter..... FC-1301	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PDG-XZB40M , 4000, 2007-2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>LIESSE (BUSES)</b> 4.0L N04C-T SPG-XZB50M , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J08C KK-RR1J , RR, 2001-2004 Air Filter..... A-1311	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PDG-XZB46Y , 4000, 2007-2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>LIESSE (BUSES)</b> 4.0L N04C-T SPG-XZB51M , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J08C KK-RR1J , RR, 1999-2001 Air Filter..... A-1311 Fuel Filter..... FC-1301 Oil Filter Combination..... C-1315	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PDG-XZB50M , 4000, 2007-2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>LIESSE (BUSES)</b> 4.0L N04C-T SPG-XZB56Y , 4000, 2015 Air Filter..... A-1158 Oil Filter Full Flow..... C-1328		<b>MELPHA (BUSES)</b> J08C-T KK-RR1J , RR, 1999-2001 Air Filter..... A-1311 Oil Filter Combination..... C-1315	
<b>LIESSE (BUSES)</b> 4.0L N04C-T PDG-XZB51M , 4000, 2007-2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>MELPHA (BUSES)</b> J07E-T BDG-RR7JJB , RR, 2007-2011 Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319		<b>MELPHA (BUSES)</b> J07E-T PB-RR7JJA , RR, 2004-2007 Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	
<b>LIESSE (BUSES)</b> 4.0L N04C-T SDG-XZB40M , 4000, 2011 Air Filter..... A-1158 Oil Filter Full Flow..... C-1318		<b>MELPHA (BUSES)</b> J08C KC-CH1J , CH, 1995-1999 Air Filter..... A-1311 Fuel Filter..... FC-1301 Oil Filter Combination..... C-1304 Oil Filter Full Flow..... C-1325		<b>MELPHA (BUSES)</b> J07E-T SDG-RR7J , RR, 2011 Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	
<b>LIESSE (BUSES)</b> 4.0L N04C-T SDG-XZB46Y , 4000, 2011 Air Filter..... A-1158		<b>MELPHA (BUSES)</b> J05C-T KC-RH4J , RH, 1995-1999		<b>MERLIN 500 (TRUCKS)</b> HINO N06E Air Filter Set..... A-6118-S	



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>PCG277</b> (TRUCKS) HINO EK200 , 1983-1985		Fuel Filter.....	F-1303	Air Filter Primary.....	A-60400
Oil Filter By Pass.....	0-1305	Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-6118-S
Oil Filter Full Flow.....	0-1301			Fuel Filter.....	F-1304
		<b>PFD161</b> (TRUCKS) HINO W06E , 1986		Oil Filter Full Flow.....	0-1301
<b>PCG277</b> (TRUCKS) HINO EK200 , 1983		Air Filter.....	A-1306	Oil Filter By Pass.....	0-1310
Air Filter Primary.....	A-6010	Oil Filter Full Flow.....	C-1301		
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1309	<b>PFH27</b> (TRUCKS) HINO EK100 , 1983-1990	
Oil Filter Full Flow.....	0-1301			Air Filter Primary.....	A-5425
Oil Filter By Pass.....	0-1305	<b>PFD163</b> (TRUCKS) HINO H06C-T , 1986		Fuel Filter.....	F-1304
		Air Filter Primary.....	A-6006	Oil Filter By Pass.....	0-1311
<b>PCH160</b> (TRUCKS) HINO W06E , 1987-1990		Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-13081
Air Filter.....	A-1306	Air Filter Set.....	A-6118-S		
Oil Filter Full Flow.....	C-1301	Oil Filter Combination.....	C-1303	<b>PFH270</b> (TRUCKS) HINO EK100 , 1983-1989	
Oil Filter Full Flow.....	C-1309			Air Filter Primary.....	A-5425
		<b>PFD164</b> (TRUCKS) HINO H06C-T , 1983-1986		Fuel Filter.....	F-1304
<b>PCN275</b> (TRUCKS) HINO EK200 , 1988		Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	0-13081
Air Filter Primary.....	A-5425	Air Filter Primary.....	A-60400	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1304	Air Filter Set.....	A-6118-S		
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303	<b>PFN27</b> (TRUCKS) HINO EK100 , 1983-1989	
Oil Filter By Pass.....	0-1310	Oil Filter Combination.....	C-1303	Air Filter Primary.....	A-5425
		Oil Filter By Pass.....	0-1319	Fuel Filter.....	F-1304
<b>PEP28</b> (TRUCKS) HINO EP100T , 1983-1989		<b>PFD171</b> (TRUCKS) HINO H07C , 1983-1986		Oil Filter By Pass.....	0-1311
Air Filter Primary.....	A-5425	Air Filter.....	A-1306	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Fuel Filter.....	F-1303		
Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	C-1301	<b>PFN270</b> (TRUCKS) HINO EK100 , 1983-1990	
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-5425
		Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
<b>PFC14</b> (TRUCKS) HINO W06D , 1984-1990		<b>PFF17</b> (TRUCKS) HINO H07C , 1983-1989		Oil Filter Full Flow.....	0-13081
Air Filter.....	A-1305	Air Filter.....	A-1306	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1303	Fuel Filter.....	F-1303		
Oil Filter Full Flow.....	0-1314	Oil Filter Full Flow.....	C-1301	<b>PFN272</b> (TRUCKS) HINO EK100 , 1983-1989	
		Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-5425
<b>PFC17</b> (BUSES) HINO H07C , 1984-1990		Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
Air Filter.....	A-1306	<b>PFG192</b> (TRUCKS) HINO H06C-T , 1983-1990		Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1303	Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	C-1301	Air Filter Primary.....	A-60400		
Oil Filter Full Flow.....	C-1309	Air Filter Set.....	A-6118-S	<b>PFN28</b> (TRUCKS) HINO EK100 , 1983-1989	
Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1303	Air Filter Primary.....	A-5425
		Oil Filter By Pass.....	0-1319	Fuel Filter.....	F-1304
<b>PFC172</b> (TRUCKS) HINO H07C , 1984-1986		Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	0-13081
Air Filter.....	A-1306			Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1303	<b>PFG199</b> (TRUCKS) HINO H06C-T , 1986-1990			
Oil Filter Full Flow.....	C-1301	Oil Filter Combination.....	C-1303	<b>PFN28</b> (TRUCKS) HINO EP100T , 1983-1989	
Oil Filter Full Flow.....	C-1309			Air Filter Primary.....	A-5425
Oil Filter Full Flow.....	0-1301	<b>PFH22</b> (TRUCKS) HINO EM100 , 1983-1990		Fuel Filter.....	F-1304
		Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	0-13081
<b>PFD16</b> (TRUCKS) HINO H06C-T , 1983-1989		Air Filter Primary.....	A-60400	Oil Filter By Pass.....	0-1311
Air Filter Primary.....	A-6006	Air Filter Set.....	A-6118-S		
Air Filter Primary.....	A-60400	Fuel Filter.....	F-1304	<b>PFN282</b> (TRUCKS) HINO EP100 , 1983-1990	
Air Filter Set.....	A-6118-S	Oil Filter By Pass.....	0-1319	Air Filter Primary.....	A-5425
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	F-1304
Oil Filter By Pass.....	0-1319			Oil Filter Full Flow.....	0-13081
Oil Filter Combination.....	C-1303	<b>PFH221</b> (TRUCKS) HINO EM100 , 1983-1989		Oil Filter By Pass.....	0-1311
		Air Filter Primary.....	A-6006		
<b>PFD16</b> (TRUCKS) HINO H06C , 1983-1986				<b>PFN334</b> (TRUCKS) HINO K13CT	
Air Filter.....	A-1306			Oil Filter Full Flow.....	0-13081



MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PFN338</b> (TRUCKS) HINO K13CT , 1986-1990	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PFN60</b> (TRUCKS) HINO EP550 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFN635</b> (TRUCKS) HINO EF750 , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFP274</b> (TRUCKS) HINO EK100 , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081
<b>PFP284</b> (TRUCKS) HINO EP100T , 1983	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PFP604</b> (TRUCKS) HINO EF550 , 1984-1992	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFR28</b> (TRUCKS) HINO EP100T , 1983-1989	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
<b>PFR286</b> (TRUCKS) HINO EP100T , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081
<b>PFR33</b> (TRUCKS) HINO K13CT , 1986-1990	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PFR336</b> (TRUCKS) HINO K13CT , 1986-1992	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PFR602</b> (TRUCKS) HINO EF550 , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFR63</b> (TRUCKS) HINO EF550 , 1983-1989	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
<b>PFR632</b> (TRUCKS) HINO EF750 , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFR66</b> (TRUCKS) HINO F17C , 1985-1989	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFR668</b> (TRUCKS) HINO F17C , 1987-1992	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFS270</b> (TRUCKS) HINO EK100 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PFS33</b> (TRUCKS) HINO K13CT , 1986-1989	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081
<b>PFS334</b> (TRUCKS) HINO K13CT , 1986-1990	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PFS60</b> (TRUCKS) HINO EF550 , 1983-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFS600</b> (TRUCKS) HINO EF550 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFS63</b> (TRUCKS) HINO EF750T , 1983-1989	

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFS630</b> (TRUCKS) HINO EF750 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFS633</b> (TRUCKS) HINO EF750 , 1983-UP	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
<b>PFS633</b> (TRUCKS) HINO EP550 , 1983-UP	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
<b>PFS633</b> (TRUCKS) HINO EP750T , 1983-UP	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
<b>PFS633</b> (TRUCKS) HINO EF750T , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFS66</b> (TRUCKS) HINO F17T , 1987-1989	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFS664</b> (TRUCKS) HINO F17C , 1987-UP	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
<b>PFS666</b> (TRUCKS) HINO F17C , 1987-1990	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PFU63</b> (TRUCKS) HINO EF750 , 1983-1990	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PFU633</b> (TRUCKS) HINO EF750 , 1981-1989	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1305

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>PFU633</b> (TRUCKS) HINO EF750 , 1981-1989 Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
<b>PFW28</b> (TRUCKS) HINO EP100T , 1985-1990 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	0-13081	<b>PONCHO</b> (BUSES) J05D-T ADG-HX6J , HX, 2006-2007 Air Filter Primary.....	A-1156
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Air Filter Set.....	A-1156-S
Oil Filter By Pass.....	0-1311	<b>PGN274</b> (TRUCKS) HINO EK100 , 1983-1989 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1325
Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304	Oil Filter Combination.....	C-1304
<b>PFW286</b> (TRUCKS) HINO EP100T , 1985-1989 Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1311	<b>PONCHO</b> (BUSES) J05D-T BDG-HX6J , HX, 2007-2011 Air Filter Primary.....	A-1156
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	Air Filter Set.....	A-1156-S
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311	Oil Filter Combination.....	C-1304
Oil Filter By Pass.....	0-1311	<b>PHT23</b> (TRUCKS) HINO M10U , 1985-1990 Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	C-1325
<b>PFW60</b> (TRACTORS) HINO EF550 , 1984-1989 Air Filter Primary.....	A-5425	Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	C-1325
Fuel Filter.....	F-1304	Air Filter Set.....	A-6118-S	<b>PONCHO</b> (BUSES) J05E SDG-HX9J , HX, 2011 Air Filter Primary.....	A-1324
Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304	Air Filter Primary.....	A-1324M
<b>PFW604</b> (TRUCKS) HINO EF550 , 1984-1985 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-1324M-S
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Air Filter Set.....	A-1324-S
Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-1301	Oil Filter Full Flow.....	C-1325
Oil Filter Full Flow.....	0-13081	<b>PHT27</b> (TRUCKS) HINO EK200 , 1983-1990 Air Filter Primary.....	A-5425	Oil Filter Combination.....	C-1304
<b>PFZ270</b> (TRUCKS) HINO EK100 , 1983-1986 Air Filter Primary.....	A-5425	Fuel Filter.....	F-1304	<b>PONCHO</b> (BUSES) J05E SKG-HX9J , HX, 2011 Air Filter Primary.....	A-1324M
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Air Filter Primary.....	A-1324
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-1324-S
<b>PFZ270</b> (TRUCKS) HINO EF750 , 1983-1986 Air Filter Primary.....	A-5425	<b>PHV75</b> (TRUCKS) HINO 13B , 1984 Fuel Filter.....	FC-1801	Air Filter Set.....	A-1324M-S
Fuel Filter.....	F-1304	<b>P-KD164</b> (TRUCKS) HINO W06E (S/N: 163HP-UP) , 1984-1989 Air Filter.....	A-1306	Oil Filter Full Flow.....	C-1304
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	C-1325
<b>PFZ270</b> (TRUCKS) HINO EP750T , 1983-1986 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1309	<b>PRB115</b> (TRUCKS) HINO W04D , 1985-UP Air Filter.....	A-1308
Fuel Filter.....	F-1304	<b>PKG175</b> (BUSES) HINO H07C , 1983-1990 Air Filter.....	A-1306	Fuel Filter.....	FC-1302
Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-1302
<b>PFZ270</b> (TRUCKS) HINO EK100 , 1983-1985 Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1301	<b>PRB115</b> (TRUCKS) HINO W04D , 1985-1990 Air Filter.....	A-1308
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-1301	Fuel Filter.....	FC-1302
Oil Filter Full Flow.....	0-13081	<b>PKK196</b> (TRUCKS) HINO H06C-T , 1984-1986 Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	C-1302
Oil Filter By Pass.....	0-1310	Air Filter Primary.....	A-60400	<b>PRB145</b> (TRUCKS) HINO W04CT , 1985-UP Air Filter.....	A-1305
<b>PFZ273</b> (TRUCKS) HINO EK100 , 1983-1987 Air Filter Primary.....	A-5425	Air Filter Set.....	A-6118-S	Fuel Filter.....	FC-1302
Fuel Filter.....	F-1304	Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-1302
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1319	<b>PRB145</b> (TRUCKS) HINO W04CT , 1985-1990 Air Filter.....	A-1305
Oil Filter By Pass.....	0-1310	Oil Filter Combination.....	C-1303	Fuel Filter.....	FC-1302
<b>PFZ273</b> (TRUCKS) HINO EK100 , 1983-1987 Air Filter Primary.....	A-5425	<b>P-KK196.198.199</b> (TRUCKS) HINO H06C-T , 1986-UP Air Filter Primary.....	A-6006	Oil Filter Full Flow.....	C-1302
Fuel Filter.....	F-1304	Air Filter Primary.....	A-60400	<b>PRB145</b> (BUSES) HINO W04CT , 1985 Air Filter.....	A-1305
Oil Filter By Pass.....	0-1311	Air Filter Set.....	A-6118-S	Fuel Filter.....	FC-1302
Oil Filter Full Flow.....	0-13081	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	C-1302
<b>PFZ633</b> (TRUCKS) HINO EF750 , 1987-1990 Air Filter Primary.....	A-5425	<b>PNS270</b> (TRUCKS) HINO EK100 , 1984-1991 Air Filter Primary.....	A-5425	<b>PRH160</b> (TRUCKS) HINO W04CT , 1985-UP Air Filter.....	A-1305
		Fuel Filter.....	F-1304		
		Oil Filter By Pass.....	0-1310		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>PRH160</b> (TRUCKS) HINO W04CT , 1985-UP		<b>PROFIA FH</b> (TRUCKS) A09C-T LDG-FH1A , FH, 2010		<b>PROFIA FN</b> (TRUCKS) K13C-T KL-FN1K , FN, 2000-2003	
Fuel Filter.....	FC-1302	Air Filter Primary.....	A-1335M	Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305
Oil Filter Full Flow.....	C-1309				
<b>PRH160</b> (TRUCKS) HINO W04CT , 1985-1990		<b>PROFIA FH</b> (TRUCKS) A09C-T LKG-FH1A , FH, 2010		<b>PROFIA FN</b> (TRUCKS) P11C-T KL-FN2P , FN, 2000-2003	
Air Filter.....	A-1305	Air Filter Primary.....	A-1335M	Fuel Filter.....	FC-1305
Air Filter Primary.....	A-6006	Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
Air Filter Primary.....	A-60400				
Air Filter Set.....	A-6118-S	<b>PROFIA FH</b> (TRUCKS) P11C-T PK-FH2P , FH, 2003-2007		<b>PROFIA FN</b> (TRUCKS) E13C-T KS-FN1E , FN, 2003-2006	
Fuel Filter.....	FC-1302	Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
Oil Filter Full Flow.....	C-1301	Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
Oil Filter Full Flow.....	C-1309				
<b>PRH160</b> (BUSES) HINO W04CT , 1985		<b>PROFIA FH</b> (TRUCKS) A09C-T QKG-FH1A , FH, 2012		<b>PROFIA FN</b> (TRUCKS) P11C-T KS-FN2P , FN, 2003-2007	
Air Filter.....	A-1305	Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
Fuel Filter.....	FC-1302	Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
Oil Filter Full Flow.....	C-1301				
Oil Filter Full Flow.....	C-1309	<b>PROFIA FN</b> (TRUCKS) P11C-T , 11000, 2003-2007		<b>PROFIA FN</b> (TRUCKS) A09C-T LDG-FN1A , FN, 2010	
		Oil Filter By Pass.....	0-1323	Air Filter Primary.....	A-1335M
				Air Filter Set.....	A-1335M-S
<b>PRJ17</b> (BUSES) HINO H07C , 1983-1990		<b>PROFIA FN</b> (TRUCKS) P11C-T , 11000, 2003-2007		<b>PROFIA FN</b> (TRUCKS) E13C-T LDG-FN1E , FN, 2010	
Air Filter.....	AS-1303	Oil Filter By Pass.....	0-1323	Air Filter Primary.....	A-1335M
Fuel Filter.....	F-1303			Air Filter Set.....	A-1335M-S
Oil Filter Full Flow.....	C-1301	<b>PROFIA FN</b> (TRUCKS) P11C-PT , 11000, 2003-2007		<b>PROFIA FN</b> (TRUCKS) A09C-T LKG-FN1A , FN, 2010	
Oil Filter Full Flow.....	C-1309	Oil Filter By Pass.....	0-1323	Air Filter Primary.....	A-1335M
Oil Filter Full Flow.....	0-1301			Air Filter Set.....	A-1335M-S
<b>PRJ170</b> (BUSES) HINO H07C , 1984-1988		<b>PROFIA FN</b> (TRUCKS) E13C-T , 2003-2006		<b>PROFIA FN</b> (TRUCKS) E13C-T LKG-FN1E , FN, 2010	
Air Filter.....	AS-1303	Oil Filter By Pass.....	0-1323	Air Filter Primary.....	A-1335M
Fuel Filter.....	F-1303			Air Filter Set.....	A-1335M-S
Oil Filter Full Flow.....	C-1301	<b>PROFIA FN</b> (TRUCKS) E13C-T ADG-FN1E , FN, 2006-2007		<b>PROFIA FN</b> (TRUCKS) E13C-T LKG-FN1E , FN, 2010	
Oil Filter Full Flow.....	C-1309	Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
Oil Filter Full Flow.....	0-1301	Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
<b>PROFIA FH</b> (TRUCKS) P11C-PT , 11000, 2000-2007		<b>PROFIA FN</b> (TRUCKS) E13C-T BDG-FN1E , FN, 2007-2010		<b>PROFIA FN</b> (TRUCKS) E13C-T PK-FN1E , FN, 2003-2006	
Oil Filter By Pass.....	0-1323	Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
		Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
<b>PROFIA FH</b> (TRUCKS) A09C-T BDG-FH1A , FH, 2007-2010		<b>PROFIA FN</b> (TRUCKS) A09C-T BKG-FN1A , FN, 2007-2010		<b>PROFIA FN</b> (TRUCKS) P11C-T PK-FN2P , FN, 2003-2007	
Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
<b>PROFIA FH</b> (TRUCKS) K13D KC-FH2K , FH, 1995-2000		<b>PROFIA FN</b> (TRUCKS) K13C-T KC-FN1K , FN, 1994-2000		<b>PROFIA FN</b> (TRUCKS) E13C-T QDG-FN1E , FN, 2012	
Air Filter.....	A-1317	Air Filter.....	A-1317	Air Filter Primary.....	A-1335M
Fuel Filter.....	FC-1305	Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S
Fuel Filter Primary.....	FC-1310	Fuel Filter Primary.....	FC-1310		
<b>PROFIA FH</b> (TRUCKS) P11C-T KL-FH2P , FH, 2000-2003		<b>PROFIA FN</b> (TRUCKS) K13D KC-FN2K , FN, 1995-2000		<b>PROFIA FN</b> (TRUCKS) A09C-T QKG-FN1A , FN, 2012	
Air Filter.....	A-1317	Air Filter.....	A-1317	Air Filter Primary.....	A-1335M
Fuel Filter.....	FC-1305	Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S
Fuel Filter Primary.....	FC-1310	Fuel Filter Primary.....	FC-1310		
<b>PROFIA FH</b> (TRUCKS) P11C-T KS-FH2P , FH, 2003-2007		<b>PROFIA FN</b> (TRUCKS) P11C-T KC-FN2P , FN, 1994-2000		<b>PROFIA FN</b> (TRUCKS) E13C-T QKG-FN1E , FN, 2012	
Air Filter Primary.....	A-1335M	Air Filter.....	A-1317	Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S
		Fuel Filter Primary.....	FC-1310		
<b>PROFIA FH</b> (TRUCKS) P11C-T KS-FH2P , FH, 2003-2007		<b>PROFIA FN</b> (TRUCKS) P11C-T KC-FN2P , FN, 1994-2000		<b>PROFIA FP</b> (TRUCKS) P11C-T KC-FP2P , FP, 1994-2000	
Air Filter Primary.....	A-1335M	Air Filter.....	A-1317	Air Filter.....	A-1317
Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305		
		Fuel Filter Primary.....	FC-1310		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>PROFIA FP</b> (TRUCKS) P11C-T KC-FP2P , FP, 1994-2000	Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	Air Filter Set..... A-1335M-S		<b>PROFIA FR</b> (TRUCKS) E13C-T BKG-FR1E , FR, 2006-2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S
<b>PROFIA FP</b> (TRUCKS) P11C-T KL-FP2P , FP, 2000-2003	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305	<b>PROFIA FQ</b> (TRUCKS) E13C-T LDG-FQ1E , FQ, 2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) F17D KC-FR1F , FR, 1995-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) E13C-T , 2003-2006	Oil Filter By Pass..... O-1323	<b>PROFIA FQ</b> (TRUCKS) A09C-T LKG-FQ1A , FQ, 2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) K13C-T KC-FR1K , FR, 1994-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) P11C , 2003	Oil Filter By Pass..... O-1323	<b>PROFIA FQ</b> (TRUCKS) E13C-T LKG-FQ1E , FQ, 2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) K13D KC-FR2K , FR, 1995-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) E13C-T ADG-FQ1E , FQ, 2006-2007	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FQ</b> (TRUCKS) E13C-T PK-FQ1E , FQ, 2003-2006	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) P11C-T KC-FR2P , FR, 1994-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) E13C-T BDG-FQ1E , FQ, 2007-2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FQ</b> (TRUCKS) A09C-T QDG-FQ1A , FQ, 2012	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) F20C KC-FR3F , FR, 1994-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) K13C-T KC-FQ1K , FQ, 1998-2000	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305	<b>PROFIA FQ</b> (TRUCKS) E13C-T QDG-FQ1E , FQ, 2012	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) F21C KC-FR4F , FR, 1994-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) P11C-T KC-FQ2P , FQ, 1996-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	<b>PROFIA FQ</b> (TRUCKS) A09C-T QKG-FQ1A , FQ, 2012	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) P11C-T KL-FR1K , FR, 2000-2003	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305
<b>PROFIA FQ</b> (TRUCKS) K13C-T KL-FQ1K , FQ, 2000-2003	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305	<b>PROFIA FR</b> (TRUCKS) P11C-PT , 11000, 2003-2007	Oil Filter By Pass..... O-1323	<b>PROFIA FR</b> (TRUCKS) P11C-T KL-FR2P , FR, 2000-2003	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) P11C-T KC-FQ2P , FQ, 1996-2000	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	<b>PROFIA FR</b> (TRUCKS) E13C-T , 2003-2006	Oil Filter By Pass..... O-1323	<b>PROFIA FR</b> (TRUCKS) F21C KL-FR4F , FR, 2000-2003	Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310
<b>PROFIA FQ</b> (TRUCKS) K13C-T KL-FQ1K , FQ, 2000-2003	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305	<b>PROFIA FR</b> (TRUCKS) E13C-T ADG-FR1E , FR, 2006-2006	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) E13C-T KS-FR1E , FR, 2003-2006	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S
<b>PROFIA FQ</b> (TRUCKS) P11C-T KL-FQ2P , FQ, 2000-2003	Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	<b>PROFIA FR</b> (TRUCKS) A09C-T BDG-FR1A , FR, 2007-2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) P11C-T KS-FR2P , FR, 2003-2007	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S
<b>PROFIA FQ</b> (TRUCKS) F21C KL-FQ4F , FQ, 2000-2003	Fuel Filter Primary..... FC-1310 Fuel Filter..... FC-1305	<b>PROFIA FR</b> (TRUCKS) E13C-T BDG-FR1E , FR, 2006-2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S	<b>PROFIA FR</b> (TRUCKS) A09C-T BKG-FR1A , FR, 2007-2010	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S
<b>PROFIA FQ</b> (TRUCKS) P11C-T KL-FQ2P , FQ, 2000-2003	Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	<b>PROFIA FR</b> (TRUCKS) E13C-T KS-FQ1E , FQ, 2003-2006	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S		
<b>PROFIA FQ</b> (TRUCKS) E13C-T KS-FQ1E , FQ, 2003-2006	Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S				
<b>PROFIA FQ</b> (TRUCKS) A09C-T LDG-FQ1A , FQ, 2010	Air Filter Primary..... A-1335M				



# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
PROFIA FW (TRUCKS) E13C-T , 2003-2006 Oil Filter By Pass.....	0-1323	PROFIA FW (TRUCKS) F21C KL-FW4F , FW, 2000-2003 Air Filter.....	A-1317	Fuel Filter.....	FC-1305
PROFIA FW (TRUCKS) E13C-T ADG-FW1E , FW, 2006-2006 Air Filter Primary.....	A-1335M	Fuel Filter.....	FC-1305	Fuel Filter Primary.....	FC-1310
Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310		
PROFIA FW (TRUCKS) A09C-T BDG-FW1A , FW, 2007-2010 Air Filter Primary.....	A-1335M	PROFIA FW (TRUCKS) E13C-T KS-FW1E , FW, 2003-2006 Air Filter Primary.....	A-1335M	PROFIA FY (TRUCKS) F20C KC-FY3FUB , FY, 1998-2001 Fuel Filter.....	FC-1305
Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
PROFIA FW (TRUCKS) E13C-T BDG-FW1E , FW, 2006-2010 Air Filter Primary.....	A-1335M	PROFIA FW (TRUCKS) P11C-T KS-FW2P , FW, 2003-2007 Air Filter Primary.....	A-1335M	Fuel Filter.....	FC-1305
Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
PROFIA FW (TRUCKS) A09C-T BKG-FW1A , FW, 2007-2010 Air Filter Primary.....	A-1335M	PROFIA FW (TRUCKS) A09C-T LDG-FW1A , FW, 2010 Air Filter Primary.....	A-1335M	PROFIA FZ (TRUCKS) F17D KC-FZ1FJC , FZ, 1995-2001 Air Filter.....	A-1317
Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305
PROFIA FW (TRUCKS) E13C-T BKG-FW1E , FW, 2006-2010 Air Filter Primary.....	A-1335M	PROFIA FW (TRUCKS) E13C-T LDG-FW1E , FW, 2010 Air Filter Primary.....	A-1335M	Fuel Filter Primary.....	FC-1310
Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S		
PROFIA FW (TRUCKS) F17D KC-FW1F , FW, 1995-2000 Air Filter.....	A-1317	PROFIA FW (TRUCKS) A09C-T LKG-FW1A , FW, 2010 Air Filter Primary.....	A-1335M	PROFIA GN (TRUCKS) P11C-PT , 11000, 2003 Oil Filter By Pass.....	0-1323
Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S	PROFIA GN (TRUCKS) A09C-T BDG-GN1A , GN, 2007-2010 Air Filter Primary.....	A-1335M
Fuel Filter Primary.....	FC-1310	PROFIA FW (TRUCKS) E13C-T LKG-FW1E , FW, 2010 Air Filter Set.....	A-1335M-S	Air Filter Set.....	A-1335M-S
PROFIA FW (TRUCKS) K13C-T KC-FW1K , FW, 1994-2000 Air Filter.....	A-1317	Air Filter Primary.....	A-1335M	PROFIA GN (TRUCKS) F17D KC-GN1F , GN, 1994-2000 Air Filter.....	A-1317
Fuel Filter.....	FC-1305	PROFIA FW (TRUCKS) E13C-T PK-FW1E , FW, 2003-2006 Air Filter Primary.....	A-1335M	Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310	Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
PROFIA FW (TRUCKS) P11C-T KC-FW2P , FW, 1996-2000 Air Filter.....	A-1317	PROFIA FW (TRUCKS) P11C-T PK-FW2P , FW, 2003-2007 Air Filter Primary.....	A-1335M	PROFIA GN (TRUCKS) K13D KC-GN2K , GN, 1995-2000 Air Filter.....	A-1317
Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310	PROFIA FW (TRUCKS) A09C-T QDG-FW1A , FW, 2012 Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
PROFIA FW (TRUCKS) F20C KC-FW3F , FW, 1994-2000 Air Filter.....	A-1317	Air Filter Primary.....	A-1335M	PROFIA GN (TRUCKS) P11C-T KC-GN2P , GN, 1994-2000 Air Filter.....	A-1317
Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S	Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310	PROFIA FW (TRUCKS) E13C-T QDG-FW1E , FW, 2012 Air Filter Primary.....	A-1335M	Fuel Filter Primary.....	FC-1310
PROFIA FW (TRUCKS) F21C KC-FW4F , FW, 1994-2000 Air Filter.....	A-1317	Air Filter Set.....	A-1335M-S	PROFIA GN (TRUCKS) P11C-T KL-GN2P , GN, 2000-2003 Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1305	PROFIA FW (TRUCKS) A09C-T QKG-FW1A , FW, 2012 Air Filter Set.....	A-1335M-S	Fuel Filter Primary.....	FC-1310
Fuel Filter Primary.....	FC-1310	Air Filter Primary.....	A-1335M	PROFIA GN (TRUCKS) P11C-T KS-GN2P , GN, 2003-2007 Air Filter Primary.....	A-1335M
PROFIA FW (TRUCKS) K13C-T KL-FW1K , FW, 2000-2003 Fuel Filter Primary.....	FC-1310	PROFIA FW (TRUCKS) E13C-T QKG-FW1E , FW, 2012 Air Filter Primary.....	A-1335M	Air Filter Set.....	A-1335M-S
Fuel Filter.....	FC-1305	Air Filter Set.....	A-1335M-S	PROFIA GN (TRUCKS) A09C-T LDG-GN1A , GN, 2010 Air Filter Set.....	A-1335M-S
PROFIA FW (TRUCKS) P11C-T KL-FW2P , FW, 2000-2003 Fuel Filter.....	FC-1305	PROFIA FW (TRUCKS) E13C-T QKG-FW1E , FW, 2012 Air Filter Primary.....	A-1335M	Air Filter Primary.....	A-1335M
Fuel Filter Primary.....	FC-1310	Air Filter Set.....	A-1335M-S	PROFIA GN (TRUCKS) A09C-T LKG-GN1A , GN, 2010 Air Filter Set.....	A-1335M-S
		PROFIA FY (TRUCKS) K13C-T KC-FY1KWE , FY, 2001-2003		Air Filter Primary.....	A-1335M



MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PROFIA GN</b> (TRUCKS) A09C-T LKG-GN1A , GN, 2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA GN</b> (TRUCKS) P11C-T PK-GN2P , GN, 2003-2007	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA GN</b> (TRUCKS) A09C-T QDG-GN1A , GN, 2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA GN</b> (TRUCKS) A09C-T QKG-GN1A , GN, 2012	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA PR</b> (TRUCKS) A09C-T BDG-PR1A , PR, 2007-2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA PR</b> (TRUCKS) F20C KL-PR4FPH , PR, 2002-2003	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
Oil Filter By Pass.....	O-1321
<b>PROFIA PR</b> (TRUCKS) A09C-T LDG-PR1A , PR, 2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA PR</b> (TRUCKS) P11C-T PK-PR2PPW , PR, 2004-2007	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) P11C-PT , 11000, 2003-2007	
Oil Filter By Pass.....	O-1323
<b>PROFIA SH</b> (TRUCKS) E13C-T , 16700, 2003-2006	
Oil Filter By Pass.....	O-1323
<b>PROFIA SH</b> (TRUCKS) E13C-T ADG-SH1E , SH, 2006-2006	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) A09C-T BDG-SH1A , SH, 2007-2010	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) E13C-T BDG-SH1E , SH, 2006-2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) E13C-T BKG-SH1E , SH, 2006-2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) F17D-T KC-SH1F#E , SH, 1998-2000	
Air Filter.....	A-1322
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) K13C-T KC-SH1K , SH, 1996-2001	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) F20C KC-SH3F , SH, 1995-2001	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) V26C KC-SH3V , SH, 1995-2001	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) F21C KC-SH4F , SH, 1995-2001	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) F17D-T KL-SH1F , SH, 2000-2003	
Air Filter.....	A-1322
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) K13C-T KL-SH1K , SH, 2000-2003	
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) F21C KL-SH4F , SH, 2000-2003	
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SH</b> (TRUCKS) E13C-T KS-SH1E , SH, 2004-2006	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) P11C-T KS-SH2P , SH, 2003-2007	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) A09C-T LDG-SH1A , SH, 2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) A09C-T LKG-SH1A , SH, 2010	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PROFIA SH</b> (TRUCKS) E13C-T LKG-SH1E , SH, 2010-2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) E13C-T8 LKG-SH1E , SH, 2010-2012	
Air Filter Set.....	A-1342-S
Air Filter Primary.....	A-1342
<b>PROFIA SH</b> (TRUCKS) E13C-T PK-SH1E , SH, 2004-2006	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) P11C-T PK-SH2P , SH, 2003-2007	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) A09C-T QDG-SH1A , SH, 2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SH</b> (TRUCKS) A09C-T QKG-SH1A , SH, 2012	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SH</b> (TRUCKS) E13C-T QKG-SH1E , SH, 2012	
Air Filter Primary.....	A-1342
Air Filter Set.....	A-1342-S
<b>PROFIA SH</b> (TRUCKS) E13C-T SH1E , 13000, 2003-2010	
Fuel Filter.....	EF-13090
<b>PROFIA SS</b> (TRUCKS) E13C-T , 2012	
Oil Filter By Pass.....	EO-1303
<b>PROFIA SS</b> (TRUCKS) E13C-T , 2003-2006	
Oil Filter By Pass.....	O-1323
<b>PROFIA SS</b> (TRUCKS) E13C-T7 ADG-SS1E , SS, 2006-2007	
Air Filter Set.....	A-1335M-S
Air Filter Primary.....	A-1335M
<b>PROFIA SS</b> (TRUCKS) E13C-T7 BDG-SS1E , SS, 2007-2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>PROFIA SS</b> (TRUCKS) F17D-T KC-SS1FJE , SS, 1998-2001	
Air Filter.....	A-1322
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>PROFIA SS</b> (TRUCKS) V26C KC-SS3V , SS, 1995-2001	
Air Filter.....	A-1317
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E17D KL-SS1FJG , SS, 2000-2003 Air Filter..... A-1322 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310		<b>PRR19</b> <i>(TRUCKS)</i> HINO H06C-T , 1988-1990 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303		<b>PRU174</b> <i>(TRUCKS)</i> HINO H07C , 1986 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T7 KS-SS1E , SS, 2004-2006 Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S		<b>PRR191</b> <i>(TRUCKS)</i> HINO H06C-T , 1988-1990 Air Filter..... A-1310 Oil Filter Combination..... C-1303		<b>PRU192</b> <i>(TRUCKS)</i> HINO H06C-T , 1986-UP Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T LDG-SS1E , SS, 2010-2012 Air Filter Set..... A-1342-S Air Filter Primary..... A-1342		<b>PRR192</b> <i>(TRUCKS)</i> HINO H06C-T , 1986-UP Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303		<b>PRU192</b> <i>(TRUCKS)</i> HINO H06C-T , 1986-1989 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T7 LDG-SS1E , SS, 2010-2012 Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S		<b>PRR192</b> <i>(TRUCKS)</i> HINO H06C-T , 1986 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303		<b>PRU192</b> <i>(TRUCKS)</i> HINO H06C-T , 1986 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T LKG-SS1E , SS, 2010-2012 Air Filter Set..... A-1335M-S Air Filter Primary..... A-1335M		<b>PRT174</b> <i>(TRUCKS)</i> HINO H07C , 1986-UP Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>PRU22</b> <i>(TRUCKS)</i> HINO EM100 , 1984-1989 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T7 PK-SS1E , SS, 2004-2006 Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S		<b>PRT174</b> <i>(TRUCKS)</i> HINO H07C , 1986-1990 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>PRU60</b> <i>(TRUCKS)</i> HINO EF550 , 1984-1990 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1310	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T QDG-SS1E , SS, 2012 Air Filter Set..... A-1342-S Air Filter Set..... A-1335M-S Air Filter Primary..... A-1335M Air Filter Primary..... A-1342		<b>PRT174</b> <i>(TRUCKS)</i> HINO H07CT , 1986 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>PRU63</b> <i>(TRUCKS)</i> HINO EF750 , 1984-1990 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1310 Oil Filter Full Flow..... 0-13081	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T QKG-SS1E , SS, 2012 Air Filter Primary..... A-1335M Air Filter Set..... A-1335M-S		<b>PRT22</b> <i>(TRUCKS)</i> HINO EM100 , 1983-1989 Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-1301 Oil Filter By Pass..... 0-1310		<b>PRY638</b> <i>(TRUCKS)</i> HINO EF750T , 1985-UP Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter Full Flow..... 0-13081 Oil Filter By Pass..... 0-1310	
<b>PROFIA SS</b> <i>(TRUCKS)</i> E13C-T SS1E , 13000, 2004-2010 Fuel Filter..... EF-13090		<b>PRU174</b> <i>(TRUCKS)</i> HINO H07C , 1986-UP Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>PRY638</b> <i>(TRUCKS)</i> HINO EF750T , 1985-1990 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1310 Oil Filter Full Flow..... 0-13081	
<b>PROFIA WP</b> <i>(TRUCKS)</i> F21C KC-WP4FLB , WP, 1998-2001 Air Filter..... A-1317 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310		<b>PRU174</b> <i>(TRUCKS)</i> HINO H07C , 1986-1990 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309		<b>PRY638</b> <i>(TRUCKS)</i> HINO EF750T , 1985 Air Filter Primary..... A-5425 Fuel Filter..... F-1304 Oil Filter By Pass..... 0-1310 Oil Filter Full Flow..... 0-13081	
<b>PRR17</b> <i>(BUSES)</i> HINO H07C , 1983-1990 Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309 Oil Filter Full Flow..... 0-1301		<b>PRU174</b> <i>(TRUCKS)</i> HINO H07C , 1986-1990 Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309			
<b>PRR170</b> <i>(TRUCKS)</i> HINO EH700 , 1986 Air Filter..... AS-1303 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309					

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PRY638</b> (TRUCKS) HINO EF750T , 1985	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PSD171</b> (TRUCKS) HINO H07C , 1983-1986	
Air Filter.....	A-1306
Fuel Filter.....	F-1303
Oil Filter Full Flow.....	O-1301
<b>PSD191</b> (TRUCKS) HINO H06C-T , 1986-1989	
Air Filter Primary.....	A-6006
Air Filter Primary.....	A-60400
Air Filter Set.....	A-6118-S
Oil Filter Combination.....	C-1303
<b>PSH1V</b> (TRUCKS) HINO V22D , 1991-1992	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PSH275</b> (TRUCKS) HINO EK100 , 1984-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PSH2K</b> (TRUCKS) HINO K13D , 1991-1992	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-13081
<b>PSH2V</b> (TRUCKS) HINO F17E , 1992	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PSH2V</b> (TRUCKS) HINO V25C , 1992	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PSH331</b> (TRUCKS) HINO K13CT , 1986-1991	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1311
<b>PSH601</b> (TRUCKS) HINO EF550 , 1983-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PSH631</b> (TRUCKS) HINO EF750T , 1984-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PSH631</b> (TRACTORS) HINO EF750 , 1983-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
<b>PSH661</b> (TRUCKS) HINO F17C , 1987-1991	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PSH691</b> (TRUCKS) HINO V21C , 1987-1991	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1310
<b>PSH691</b> (TRUCKS) HINO F17C , 1986-1991	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>PSH711</b> (TRUCKS) HINO EV700 , 1984-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PSH721</b> (TRUCKS) HINO V22C , 1986-1991	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>PSS631</b> (TRUCKS) HINO EF750 , 1984-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310
<b>PSS631</b> (TRUCKS) HINO EF750T , 1983-1991	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-13081
<b>PSS661</b> (TRUCKS) HINO F17CT , 1987-1991	
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081
Oil Filter By Pass.....	O-1310

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>PSS691</b> (TRUCKS) HINO V21C , 1986-1991	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>PSS711</b> (TRUCKS) HINO EV700 , 1984-1986	
Air Filter Primary.....	A-5425
Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1310
<b>PSS721</b> (TRUCKS) HINO V22C , 1986-1991	
Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1309
<b>RAINBOW</b> (BUSES) 5.8L W06D , 5800, 1983-1989	
Air Filter.....	AS-1301
<b>RAINBOW</b> (BUSES) J07E-T BDG-HR7JPB , HR, 2007-2010	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
Oil Filter Combination.....	C-1319
<b>RAINBOW</b> (BUSES) J08C KC-RJ1J , RJ, 1995-1999	
Air Filter.....	A-1311
Air Filter.....	A-1322
Fuel Filter.....	FC-1301
Oil Filter Combination.....	C-1304
Oil Filter Full Flow.....	C-1325
<b>RAINBOW</b> (BUSES) J08C KC-RR1J , RR, 1995-1999	
Air Filter.....	A-1322
Air Filter.....	A-1311
Fuel Filter.....	FC-1301
Oil Filter Full Flow.....	C-1325
Oil Filter Combination.....	C-1304
<b>RAINBOW</b> (BUSES) J08C KK-HR1J , HR, 2001-2004	
Air Filter.....	A-1311
<b>RAINBOW</b> (BUSES) J08C KK-HR1J , HR, 1999-2001	
Air Filter.....	A-1311
Oil Filter Combination.....	C-1315
<b>RAINBOW</b> (BUSES) J08C KK-RJ1J , RJ, 2001-2004	
Air Filter.....	A-1311
Air Filter.....	A-1322
Fuel Filter.....	FC-1301

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>RAINBOW</b> (BUSES) J08C KK-RJ1J , RJ, 1999-2001		<b>Ranger</b> (TRUCKS) 6.6L J07C , 6600, 1996-2003		Air Filter Primary.....	A-1324M
Air Filter.....	A-1322	Air Filter Secondary.....	A-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08E-T ADG-GK8J , GK, 2005-2006	
Air Filter.....	A-1311	<b>Ranger</b> (TRUCKS) 7.7L J08E-T , 7700, 2004		Air Filter Primary.....	A-1324
Fuel Filter.....	FC-1301	Fuel Filter.....	EF-1306	Air Filter Primary.....	A-1324M
Oil Filter Combination.....	C-1315	<b>Ranger</b> (TRUCKS) J08C FD1J , 1997		Air Filter Set.....	A-1324-S
<b>RAINBOW</b> (BUSES) J08C KL-HR1J , HR, 2001-2004		Fuel/Water Separator.....	SFC-1307	Air Filter Set.....	A-1324M-S
Air Filter.....	A-1311	<b>Ranger</b> (TRUCKS) J08C FD2J , 1998		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T ADG-GX7J , GX, 2005-2006	
<b>RAINBOW</b> (BUSES) J08C KL-HR1J , HR, 1999-2001		Fuel/Water Separator.....	SFC-1307	Air Filter Set.....	A-6118-S
Air Filter.....	A-1311	<b>Ranger</b> (TRUCKS) J08C-TF F61J , 1997-2002		Air Filter Set.....	A-1324-S
Oil Filter Combination.....	C-1315	Fuel/Water Separator.....	SFC-1307	Air Filter Set.....	A-1324M-S
<b>RAINBOW</b> (BUSES) 6HK1-T PA-KR234J1 , KR, 2004-2007		<b>Ranger</b> (TRUCKS) J08C-TG FM1J , 1998-2002		Oil Filter Combination.....	C-1319
Air Filter Primary.....	A-1013	Fuel/Water Separator.....	SFC-1307	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T BDG-GC7J , GC, 2006-2007	
Air Filter Primary.....	A-10134	<b>Ranger</b> (TRUCKS) J08C-F GD1J , 1996-2002		Air Filter Primary.....	A-1324
Air Filter Set.....	A-1841-S	Fuel/Water Separator.....	SFC-1307	Air Filter Primary.....	A-1324M
Fuel Filter.....	FC-1203	<b>Ranger</b> (TRUCKS) J08C-TG GH1J , 1997-2002		Air Filter Set.....	A-1324-S
Oil Filter By Pass.....	O-1524	Fuel/Water Separator.....	SFC-1307	Air Filter Set.....	A-1324M-S
Oil Filter Full Flow.....	O-1313	<b>Ranger</b> (TRUCKS) J08C GT1J , 1998-2002		Oil Filter Combination.....	C-1319
<b>RAINBOW</b> (BUSES) J07E-T PB-HR7JHA , HR, 2004-2007		Fuel/Water Separator.....	SFC-1307	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T BDG-GD7J , GD, 2006-2007	
Air Filter Primary.....	A-1324	<b>Ranger</b> (TRUCKS) J08C-TG GH1J , 1997-2002		Air Filter Set.....	A-1324M-S
Air Filter Primary.....	A-1324M	Fuel/Water Separator.....	SFC-1307	Air Filter Set.....	A-6118-S
Air Filter Set.....	A-1324-S	<b>Ranger</b> (TRUCKS) J08C-TG GH1J , 1997-2002		Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S	Fuel/Water Separator.....	SFC-1307	Air Filter Primary.....	A-1324M
Oil Filter Combination.....	C-1319	<b>Ranger</b> (TRUCKS) J08C-TG GH1J , 1997-2002		Air Filter Primary.....	A-6006
<b>RAINBOW</b> (BUSES) 6HK1-T PDG-KR234J2 , KR, 2007-2012		Fuel/Water Separator.....	SFC-1307	Air Filter Primary.....	A-60400
Air Filter Primary.....	A-1013	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T ADG-GC7J , GC, 2005-2006		Air Filter Primary.....	A-1324
Air Filter Primary.....	A-10134	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1841-S	Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324
Fuel Filter.....	EF-1509	Air Filter Set.....	A-1324-S	Oil Filter Combination.....	C-1319
Oil Filter By Pass.....	O-1524	Air Filter Set.....	A-1324M-S	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08E-T BDG-GD8J , GD, 2007-2011	
Oil Filter Full Flow.....	O-1313	Oil Filter Combination.....	C-1319	Air Filter Primary.....	A-1324
<b>RAINBOW</b> (BUSES) J07E-T PK-HR7JPA , HR, 2004-2007		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08C ADG-GC7J , GC, 2005-2006		Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324M	Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324	Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-1324	Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324M	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08E-T BDG-GK8J , GK, 2006-2010	
Oil Filter Combination.....	C-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T ADG-GD7J , GD, 2005-2006		Air Filter Set.....	A-1324-S
<b>Ranger</b> (TRUCKS) 4.7L J05D-T , 4700, 2004-2011		Air Filter Primary.....	A-1324M	Air Filter Set.....	A-1324M-S
Fuel Filter.....	EF-1306	Air Filter Primary.....	A-6006	Air Filter Primary.....	A-1324
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2004		Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324M
Fuel Filter.....	EF-1306	Air Filter Primary.....	A-60400	Air Filter Primary.....	A-6006
<b>Ranger</b> (TRUCKS) 6.3L J07E-T , 6300, 2004		Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-60400
Fuel Filter.....	EF-1306	Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		Air Filter Set.....	A-6118-S	Air Filter Set.....	A-1324M-S
Fuel Filter.....	EF-1306	Oil Filter Combination.....	C-1319	Oil Filter Combination.....	C-1319
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08C-T ADG-GK8J , GK, 2005-2006		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T BDG-GX7J , GX, 2006-2011	
Fuel Filter.....	EF-1306	Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-1324M
Fuel Filter.....	EF-1306	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-6006
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08C-T ADG-GK8J , GK, 2005-2006		Air Filter Primary.....	A-60400
Fuel Filter.....	EF-1306	Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-6118-S
Fuel Filter.....	EF-1306	Air Filter Primary.....	A-1324	Oil Filter Combination.....	C-1319
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08C-T ADG-GK8J , GK, 2005-2006		<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T BKG-GC7J , GC, 2007-2011	
Fuel Filter.....	EF-1306	Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324M-S
<b>Ranger</b> (TRUCKS) 6.3L J07E , 6300, 2003		Air Filter Set.....	A-1324M-S	Oil Filter Combination.....	C-1319
Fuel Filter.....	EF-1306	Air Filter Primary.....	A-1324	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T BKG-GC7J , GC, 2007-2011	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07E-T BKG-GC7J , GC, 2007-2011		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07C-T KK-GC5J , GC, 2002-2004		Air Filter..... A-1322	
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324	Fuel Filter.....	FC-1301
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324-S	Oil Filter Combination.....	C-1315
Air Filter Primary.....	A-1324	Air Filter Set.....	A-1324M-S	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J{10017-} , GX, 2001-2001	
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324M	Air Filter.....	A-1322
Oil Filter Combination.....	C-1319	Oil Filter Combination.....	C-1319	Fuel Filter.....	FC-1301
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07E-T BKG-GD7J , GD, 2007-2011		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GD1J#E , GD, 2001-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J{-10214} , GX, 1999-2001	
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324M	Air Filter Set.....	A-6118-S
Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-60400
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-6006
Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S	Fuel Filter.....	FC-1301
Oil Filter Combination.....	C-1319	Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1315
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KC-GD1J , GD, 1994-1999		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KK-GD1J#E , GD, 2001-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J{10215-} , GX, 2001-2002	
Air Filter.....	A-1311	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-6006
Air Filter Set.....	A-6118-S	Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-60400
Air Filter Primary.....	A-6006	Air Filter Set.....	A-1324-S	Air Filter Set.....	A-6118-S
Air Filter Primary.....	A-60400	Air Filter Set.....	A-1324M-S	Fuel Filter.....	FC-1301
Fuel Filter.....	FC-1301	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KL-GK1J#E , GK, 2001-2004		Air Filter Primary.....	A-1324M
Oil Filter Combination.....	C-1304	Air Filter.....	A-1322	Air Filter Primary.....	A-1324
Oil Filter Full Flow.....	C-1325	Fuel Filter.....	FC-1301	Air Filter Set.....	A-1324-S
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KC-GD1J , GD, 1994-1999		Air Filter.....	A-1322	Air Filter Set.....	A-1324M-S
Air Filter.....	A-1311	Oil Filter Combination.....	C-1315	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KL-GK1J{-10057} , GK, 1999-2001	
Fuel Filter.....	FC-1301	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GD1J{10138-} , GD, 2001-2001		Air Filter.....	A-1322
Oil Filter Full Flow.....	C-1325	Air Filter.....	A-1322	Oil Filter Combination.....	C-1315
Oil Filter Combination.....	C-1304	Fuel Filter.....	FC-1301	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KL-GK1J{10058-} , GK, 2001-2001	
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KC-GK1J#B , GK, 1995-1999		Fuel Filter.....	FC-1301	Air Filter.....	A-1322
Air Filter.....	A-1311	Oil Filter Combination.....	C-1315	Oil Filter Combination.....	C-1315
Fuel Filter.....	FC-1301	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GD1J{-10274} , GD, 1999-2001		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KL-GK1J{10058-} , GK, 2001-2001	
Oil Filter Combination.....	C-1304	Air Filter Set.....	A-6118-S	Air Filter.....	A-1322
Oil Filter Full Flow.....	C-1325	Air Filter Primary.....	A-60400	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C-T KL-GK1J{10058-} , GK, 2001-2001	
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J , GX, 1997-1999		Air Filter Primary.....	A-6006	Air Filter.....	A-1322
Air Filter.....	A-1311	Air Filter Primary.....	A-60400	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08E-T KS-GK8J , GK, 2004-2005	
Air Filter Primary.....	A-6006	Air Filter Primary.....	A-60400	Air Filter Set.....	A-1324-S
Air Filter Primary.....	A-60400	Air Filter Set.....	A-6118-S	Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-6118-S	Air Filter Set.....	A-6118-S	Air Filter Primary.....	A-1324
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	Air Filter Primary.....	A-1324M
Oil Filter Full Flow.....	C-1325	Oil Filter Combination.....	C-1315	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08E-T LDG-GK8J , GK, 2010	
Oil Filter Combination.....	C-1304	<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GD1J{10275-} , GD, 2001-2002		Air Filter Primary.....	A-1324
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GC1J , GC, 2002-2005		Air Filter Primary.....	A-6006	Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-60400	Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-60400	Air Filter Set.....	A-1324M-S
Air Filter Primary.....	A-1324	Air Filter Set.....	A-6118-S	Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M	Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1319
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GC1J#E , GC, 2001-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J#E , GX, 2002-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07E-T PB-GC7J , GC, 2004-2005	
Air Filter Primary.....	A-1324	Air Filter Set.....	A-6118-S	Air Filter Set.....	A-1324-S
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-6006	Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-60400	Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-6118-S	Air Filter Primary.....	A-1324M
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1319
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GC1J#E , GC, 2001-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J#E , GX, 2001-2004		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07E-T PB-GD7J , GD, 2004-2005	
Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324	Air Filter Set.....	A-1324-S
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324M	Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-1324M
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	Oil Filter Combination.....	C-1319
<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J{-10016} , GX, 1999-2001		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J08C KK-GX1J{-10016} , GX, 1999-2001		<b>RANGER GD-GK-GX-GC (TRUCKS)</b> J07E-T PB-GD7J , GD, 2004-2005	
Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324	Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-1324M	Air Filter Primary.....	A-6006
Air Filter Set.....	A-1324-S	Air Filter Set.....	A-1324-S	Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324M-S	Air Filter Set.....	A-1324M-S	Air Filter Primary.....	A-6006
Fuel Filter.....	FC-1301	Fuel Filter.....	FC-1301	Air Filter Primary.....	A-1324

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T PB-GD7J , GD, 2004-2005	Air Filter Primary..... A-60400 Air Filter Set..... A-1324M-S Air Filter Set..... A-6118-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Oil Filter Combination..... C-1319		Oil Filter Full Flow..... 0-1301	
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T PB-GX7J , GX, 2004-2005	Air Filter Set..... A-1324-S Air Filter Set..... A-6118-S Air Filter Set..... A-1324M-S Air Filter Primary..... A-60400 Air Filter Primary..... A-1324 Air Filter Primary..... A-6006 Air Filter Primary..... A-1324M Oil Filter Combination..... C-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J05E-T SKG-GC9J , GC, 2011-2012	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1304 Oil Filter Full Flow..... C-1325	<b>RANGER P-FD161</b> (TRUCKS) HINO W06E	Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08C-T PK-GK8J , GK, 2004-2005	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T SKG-GD7J , GD, 2011-2012	Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Oil Filter Combination..... C-1319	<b>RANGER P-FD162</b> (TRUCKS) HINO H06C-T	Air Filter Set..... A-6118-S Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Oil Filter Combination..... C-1303
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J08E-T PK-GK8J , GK, 2004-2005	Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Air Filter Primary..... A-1324M Air Filter Primary..... A-1324	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T TKG-GC7J , GC, 2012	Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Oil Filter Combination..... C-1319	<b>RANGER P-FD163</b> (TRUCKS) HINO W06E	Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T SDG-GC7J , GC, 2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J05E-T TKG-GC9J , GC, 2012	Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Oil Filter Combination..... C-1304 Oil Filter Full Flow..... C-1325	<b>RANGER P-FD164</b> (TRUCKS) HINO H06C-T	Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Set..... A-6118-S Oil Filter Combination..... C-1303
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T SDG-GD7J , GD, 2011	Air Filter Set..... A-1324M-S Air Filter Set..... A-6118-S Air Filter Set..... A-1324-S Air Filter Primary..... A-1324M Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Air Filter Primary..... A-1324 Oil Filter Combination..... C-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T TKG-GD7J , GD, 2012	Air Filter Primary..... A-1324M Air Filter Primary..... A-1324 Air Filter Set..... A-1324M-S Air Filter Set..... A-1324-S Oil Filter Combination..... C-1319	<b>RANGER P-FD165</b> (TRUCKS) HINO W06E	Air Filter..... A-1306 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T SDG-GX7J , GX, 2011	Air Filter Primary..... A-1324 Air Filter Primary..... A-1324M Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S Oil Filter Combination..... C-1319	<b>RANGER GD-GK-GX-GC</b> (TRUCKS) 700 SERIES	Cabin Air Filter..... CA-13010	<b>RANGER P-FD166</b> (TRUCKS) HINO H06C-T	Air Filter Set..... A-6118-S Air Filter Primary..... A-6006 Air Filter Primary..... A-60400 Oil Filter Combination..... C-1303
<b>RANGER GD-GK-GX-GC</b> (TRUCKS) J07E-T SKG-GC7J , GC, 2011-2012	Air Filter Set..... A-1324-S Air Filter Set..... A-1324M-S	<b>RANGER K-FD171</b> (TRUCKS) HINO EH700	Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	<b>RANGER P-FD167</b> (TRUCKS) HINO H07C	Air Filter..... A-1306 Fuel Filter..... F-1303 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309 Oil Filter Full Flow..... 0-1301
		<b>RANGER K-FD173</b> (TRUCKS) HINO EH700	Air Filter..... AS-1303 Fuel Filter..... F-1303 Oil Filter Full Flow..... 0-1301	<b>RANGER P-FD171</b> (TRUCKS) HINO H07C	Air Filter..... A-1306 Fuel Filter..... F-1303 Oil Filter Full Flow..... C-1301 Oil Filter Full Flow..... C-1309 Oil Filter Full Flow..... 0-1301
		<b>RANGER K-FF172</b> (TRUCKS) HINO EH700	Air Filter..... AS-1303 Fuel Filter..... F-1303	<b>RB145</b> (TRUCKS) HINO W04CT	Air Filter..... A-1305

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>RB145</b> (TRUCKS) HINO W04CT Oil Filter Full Flow.....	C-1302	<b>RG197</b> (TRUCKS) HINO H06C-TE Fuel Filter.....	F-1303	<b>RV730</b> (TRUCKS) HINO EF100 , 1972-1979 Fuel Filter.....	F-1303
<b>RC</b> (TRUCKS) HINO DK20 Fuel Filter.....	F-1303	<b>RK176</b> (TRUCKS) HINO EH700 Air Filter.....	AS-1303	Oil Filter Full Flow.....	O-1301
<b>RC141</b> (TRUCKS) HINO EB400 , 1977-1984 Air Filter.....	AS-5709	Oil Filter Full Flow.....	O-1301	<b>RV730P</b> (TRUCKS) HINO EH100 Fuel Filter.....	F-1303
Fuel Filter.....	F-1302	<b>RL100</b> (TRUCKS) HINO EC100 , 1970-1975 Air Filter.....	A-1301	Oil Filter Full Flow.....	O-1301
Oil Filter Full Flow.....	O-1303	Fuel Filter.....	F-1301	<b>RV731</b> (TRUCKS) HINO EF300 , 1978-1979 Fuel Filter.....	F-1304
<b>RC300</b> (TRUCKS) HINO DK20 , 1969-1979 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301
Oil Filter Full Flow.....	O-1303	<b>RL300</b> (TRUCKS) HINO EH300 , 1975-1979 Air Filter.....	AS-1303	Oil Filter By Pass.....	O-1305
<b>RC321</b> (TRUCKS) HINO ER200 Air Filter.....	AS-5709	Fuel Filter.....	F-1303	<b>RV761</b> (TRUCKS) HINO EF300 , 1978-1979 Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301	Oil Filter By Pass.....	O-1305
Oil Filter Full Flow.....	O-1301	<b>RS120</b> (TRUCKS) HINO EF300 , 1978-1980 Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	O-1301	Oil Filter By Pass.....	O-1305
<b>RC701P</b> (TRUCKS) HINO EK200 , 1979-UP Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1305	<b>RZU100X</b> (TRUCKS) HINO 15BFP , 1997 Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	O-1301	<b>RS120P</b> (TRUCKS) HINO EF300 , 1978-1980 Fuel Filter.....	F-1304	<b>RZU100X</b> (TRUCKS) TOYOTA 15BFP , 1995 Oil Filter Combination.....	C-1112
Oil Filter Full Flow.....	O-1303	Oil Filter By Pass.....	O-1305	<b>SD171</b> (TRUCKS) HINO EH700 , 1984-UP Oil Filter Full Flow.....	O-1301
<b>RD100</b> (TRUCKS) HINO DS70 , 1975-1976 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-13081	<b>SD191</b> (TRUCKS) HINO H06C-T , 1986-1989 Air Filter Set.....	A-6118-S
<b>RD100</b> (TRUCKS) HINO DS70 , 1970-1976 Fuel Filter.....	F-1302	<b>RS360</b> (TRUCKS) HINO EF500 , 1979-1980 Fuel Filter.....	F-1304	Air Filter Primary.....	A-6006
<b>RD300</b> (TRUCKS) HINO EH300 , 1977-1980 Air Filter.....	AS-1303	Oil Filter Full Flow.....	O-1301	Air Filter Primary.....	A-60400
Fuel Filter.....	F-1303	Oil Filter By Pass.....	O-1305	Oil Filter Combination.....	C-1303
Oil Filter Full Flow.....	O-1301	<b>RS360P</b> (TRUCKS) HINO EF500 , 1978-1980 Fuel Filter.....	F-1304	<b>SD2H</b> (TRUCKS) HINO H07CT , 1989-1994 Oil Filter Combination.....	C-1303
<b>RD300</b> (TRUCKS) HINO EH300 , 1972-1980 Air Filter.....	AS-1303	Oil Filter Full Flow.....	O-1301	<b>SD601</b> (TRUCKS) HINO EF550 , 1983-1991 Air Filter Primary.....	A-5425
Fuel Filter.....	F-1303	Oil Filter By Pass.....	O-1305	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301	Oil Filter By Pass.....	O-1310
<b>RE100</b> (TRUCKS) HINO EB200 , 1967-1977 Fuel Filter.....	F-1302	<b>RV530</b> (TRUCKS) HINO EG100 , 1973-1978 Fuel Filter.....	F-1303	<b>SD.SH.SS TRUCK</b> (TRUCKS) E13C-T KS-SH1E , 2003 Oil Filter Full Flow.....	O-1325
Oil Filter Full Flow.....	O-1303	Oil Filter Full Flow.....	O-1301	<b>SD.SH.SS TRUCK</b> (TRUCKS) E13C-T7 PK-SS1E , 2004 Oil Filter Full Flow.....	O-1325
<b>RE101</b> (TRUCKS) HINO EB200 , 1977-1984 Air Filter.....	AS-5709	<b>RV531</b> (TRUCKS) HINO EF500 , 1979-1982 Fuel Filter.....	F-1304	<b>SELEGA</b> (BUSES) E13C-T ADG-RU1ESA , RU, 2005-2006 Air Filter Primary.....	A-1335M
Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-13081	Air Filter Set.....	A-1335M-S
Oil Filter Full Flow.....	O-1303	<b>RV531</b> (TRUCKS) HINO EF500 , 1978-1979 Fuel Filter.....	F-1304	<b>SELEGA</b> (BUSES) J08E-T ADG-RU8JHA , RU, 2006-2007 Air Filter Primary.....	A-1324
<b>RE141</b> (TRUCKS) HINO EB400 , 1977-UP Air Filter.....	AS-5709	Oil Filter Full Flow.....	O-1301	Air Filter Primary.....	A-1324M
Fuel Filter.....	F-1302	Oil Filter By Pass.....	O-1305		



MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>SELEGA</b> (BUSES) J08E-T ADG-RU8JHA , RU, 2006-2007	
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
<b>SELEGA</b> (BUSES) J08E-T BDG-RU8JHA , RU, 2007-2010	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
<b>SELEGA</b> (BUSES) A09C-T BJG-RU1ASA , RU, 2008-2011	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) P11C-T HM-RU2PPE , RU, 2001-2005	
Air Filter.....	A-1315
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) J08C KC-RU1J#C{-60000} , RU, 1995-1999	
Air Filter.....	A-1311
Fuel Filter.....	FC-1301
Oil Filter Full Flow.....	C-1325
Oil Filter Combination.....	C-1304
<b>SELEGA</b> (BUSES) J08C-T KC-RU1J#C{-60000} , RU, 1995-1999	
Air Filter.....	A-1311
Fuel Filter.....	FC-1301
Oil Filter Combination.....	C-1304
Oil Filter Full Flow.....	C-1325
<b>SELEGA</b> (BUSES) J08C KC-RU1J#C{60001-} , RU, 1999-2000	
Air Filter.....	A-1311
Air Filter.....	A-1322
Fuel Filter.....	FC-1301
Oil Filter Full Flow.....	C-1325
Oil Filter Combination.....	C-1304
<b>SELEGA</b> (BUSES) J08C-T KC-RU1J#C{60001-} , RU, 1999-2000	
Air Filter.....	A-1311
Air Filter.....	A-1322
Oil Filter Combination.....	C-1315
<b>SELEGA</b> (BUSES) P11C KC-RU2PPC , RU, 1997-2001	
Air Filter.....	A-1315
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) F20C KC-RU3F , RU, 1995-2000	
Air Filter.....	A-1315
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) F21C KC-RU4F , RU, 1995-2000	
Air Filter.....	A-1315

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) F17D-T KL-RU1F#E , RU, 2000-2005	
Air Filter.....	A-1315
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) J08C-T KL-RU1JHE{-40094} , RU, 2000-2001	
Air Filter.....	A-1311
Air Filter.....	A-1322
Oil Filter Combination.....	C-1315
<b>SELEGA</b> (BUSES) J08C-T KL-RU1JHE{40095-} , RU, 2001-2005	
Air Filter.....	A-1311
Air Filter.....	A-1322
<b>SELEGA</b> (BUSES) F21C KL-RU4F , RU, 2000-2005	
Air Filter.....	A-1315
Fuel Filter.....	FC-1305
Fuel Filter Primary.....	FC-1310
<b>SELEGA</b> (BUSES) J08E-T LDG-RU8JHB , RU, 2010	
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Set.....	A-1324-S
Air Filter Set.....	A-1324M-S
<b>SELEGA</b> (BUSES) A09C-T LJG-RU1ASB , RU, 2011-2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) E13C-T LKG-RU1ESB , RU, 2010-2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) E13C-T PKG-RU1ESA , RU, 2006-2010	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) A09C-T QQG-RU1A , RU, 2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) A09C-T QRG-RU1A , RU, 2012	
Air Filter Primary.....	A-1335M
Air Filter Set.....	A-1335M-S
<b>SELEGA</b> (BUSES) J08E-T SDG-RU8JHB , RU, 2010	
Air Filter Primary.....	A-1324M
Air Filter Primary.....	A-1324
Air Filter Set.....	A-1324M-S
Air Filter Set.....	A-1324-S
<b>SELEGA</b> (BUSES) P11C-T VM-RU2PPF , RU, 2005-2008	
Air Filter.....	A-1315

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	
<b>SERIES 500/1018</b> (TRUCKS) HINO J05D-TG	
Air Filter Set.....	A-1324M-S
Air Filter Primary.....	A-1324
Air Filter Primary.....	A-1324M
Air Filter Secondary.....	A-1326
Fuel Filter.....	EF-1802
Fuel Filter.....	F-1507
Oil Filter Full Flow.....	C-1314
<b>SF17</b> (TRUCKS) HINO H07C , 1989	
Fuel Filter.....	FC-1312
<b>SF17</b> (TRUCKS) HINO H07C-F , 1984-1991	
Air Filter Secondary.....	A-1307
Air Filter Primary.....	A-1313
Air Filter Set.....	A-5662-S
Coolant Filter.....	WC-5707
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>SG</b> (TRUCKS) HINO EM100	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
<b>SG19</b> (TRUCKS) HINO H06C , 1986-1991	
Air Filter Primary.....	A-1313
Air Filter Secondary.....	A-1307
Air Filter Set.....	A-5662-S
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>SG19</b> (TRUCKS) HINO H06C-T	
Fuel Filter.....	FC-1312
<b>SG1H</b> (TRUCKS) HINO H06C , 1993-1997	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519
<b>SG1HD</b> (TRUCKS) HINO H06C , 1993-1997	
Air Filter.....	A-1334
Fuel Filter.....	FC-1305
Fuel Filter.....	FC-1312
Fuel Filter Primary.....	FC-1310
Oil Filter Full Flow.....	C-5519



MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>SG1J</b> (TRUCKS) HINO J08C , 2004 Air Filter..... A-1334 Fuel/Water Separator Secondary.. SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Full Flow..... C-1314 Oil Filter Transmission..... H-8537-S		<b>SG2J</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter..... A-1334 Fuel Filter..... FC-1312 Oil Filter Full Flow..... C-1314 Oil Filter Full Flow..... C-5519		<b>SG3323</b> (TRUCKS) HINO J08C-TE Air Filter..... A-1334 <b>SG3325</b> (TRUCKS) HINO J08C , 2004 Air Filter..... A-1334 Fuel/Water Separator Secondary.. SFC-7912-10 Fuel/Water Separator Secondary.. SFC-7912-10B Oil Filter Full Flow..... C-1314 Oil Filter Transmission..... H-8537-S	
<b>SG1J</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter..... A-1334 Fuel Filter..... FC-1312 Oil Filter Full Flow..... C-1314 Oil Filter Full Flow..... C-5519		<b>SG3320</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter..... A-1334 Fuel Filter..... FC-1312 Oil Filter Full Flow..... C-1314 Oil Filter Full Flow..... C-5519		<b>SG3325</b> (TRUCKS) HINO J08C , 1998-2003 Air Filter..... A-1334 Fuel Filter..... FC-1312 Oil Filter Full Flow..... C-1314 Oil Filter Full Flow..... C-5519	
<b>SG20</b> (TRUCKS) HINO H06C , 1992-1992 Fuel Filter..... FC-1312		<b>SG3320</b> (TRUCKS) HINO H06C-TN , 1997-UP Air Filter..... A-1334 Air Filter Primary..... A-5639 Air Filter Set..... A-5654-S Coolant Filter..... WC-5714 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310		<b>SG3325</b> (TRUCKS) HINO J08C-TD Fuel Filter..... FC-1312	
<b>SG20</b> (TRUCKS) HINO H06C , 1992 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519		<b>SG3320</b> (TRUCKS) HINO H06C-TN , 1997 Fuel Filter..... FC-1312		<b>SG4H</b> (TRUCKS) HINO H06C , 1993-1997 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519	
<b>SG20</b> (TRUCKS) HINO H06C-TI Fuel Filter..... FC-1312		<b>SG3320</b> (TRUCKS) HINO H06C , 1993-1997 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519		<b>SG5523</b> (TRUCKS) HINO H06C-TM , TO-1996 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310	
<b>SG22</b> (TRUCKS) HINO EM100 , 1986-1986 Fuel Filter..... FC-1312		<b>SG3320</b> (TRUCKS) HINO H08C-TD Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519		<b>SG5523</b> (TRUCKS) HINO H06C-TM , 1996 Fuel Filter..... FC-1312	
<b>SG22</b> (TRUCKS) HINO EM100 , 1986 Air Filter Primary..... A-1313 Air Filter Secondary..... A-1307 Air Filter Set..... A-5662-S Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519 Oil Filter By Pass..... C-1306 Oil Filter By Pass..... C-1327		<b>SG3320</b> (TRUCKS) HINO H08C-TD Air Filter..... A-1334 Coolant Filter..... WC-5705 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-1314		<b>SG5523</b> (TRUCKS) HINO H06C , 1993-1997 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519	
<b>SG22</b> (TRUCKS) HINO EM100E , 1984-1986 Fuel Filter..... FC-1312		<b>SG3323</b> (TRUCKS) HINO H06C , 1993-1997 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519		<b>SH1F</b> (TRUCKS) HINO F17D , 1995 Oil Filter Full Flow..... O-13081	
<b>SG22</b> (TRUCKS) EM100E Oil Filter By Pass..... C-1306		<b>SG3323</b> (TRUCKS) HINO H06C-TM Air Filter..... A-1334 Air Filter Primary..... A-5639 Air Filter Set..... A-5654-S Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310		<b>SH1F</b> (TRUCKS) HINO F17DT , 1995 Oil Filter Full Flow..... O-13081	
<b>SG23</b> (TRUCKS) HINO H06C , 1992-1992 Fuel Filter..... FC-1312		<b>SG3323</b> (TRUCKS) HINO H06C-TM Air Filter..... A-1334 Air Filter Primary..... A-5639 Air Filter Set..... A-5654-S Fuel Filter..... FC-1305 Fuel Filter..... FC-1312 Fuel Filter Primary..... FC-1310		<b>SH1F</b> (TRUCKS) HINO F17D , 1992 Fuel Filter..... F-1304 Oil Filter Full Flow..... O-13081 Oil Filter By Pass..... O-1310	
<b>SG23</b> (TRUCKS) HINO H06C-TH , 1992-1992 Fuel Filter..... FC-1312		<b>SG3323</b> (TRUCKS) HINO J08C-TE Fuel Filter..... FC-1312		<b>SH1FB</b> (TRUCKS) HINO F17D , 1992-1995 Fuel Filter..... F-1304 Oil Filter Full Flow..... O-13081	
<b>SG23</b> (TRUCKS) HINO H06C , 1992 Air Filter..... A-1334 Fuel Filter..... FC-1305 Fuel Filter Primary..... FC-1310 Oil Filter Full Flow..... C-5519					

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
SH1FDB (TRUCKS) HINO F17DT , 1993		Oil Filter By Pass.....	0-1310	SH721 (TRUCKS) HINO V22C , 1986-1991	
Fuel Filter.....	F-1304	SH2VB (TRUCKS) HINO V25C , 1992-1995		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
SH1K (TRUCKS) HINO K13C , 1996		Oil Filter By Pass.....	0-1310	SHRIKE 1400 (TRUCKS) HINO M10C	
Oil Filter Full Flow.....	0-13081	SH 2045 (TRUCKS) HINO E13C		Air Filter Primary.....	A-6006
SH1V (TRUCKS) HINO V22D , 1992		Air Filter Secondary.....	A-1336M	Air Filter Primary.....	A-60400
Fuel Filter.....	F-1304	SH331 (TRUCKS) HINO K13CT , 1986-1991		Air Filter Set.....	A-6118-S
Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1309	Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	C-1314
Oil Filter By Pass.....	0-1310	SH350T (TRUCKS) HINO K13C , 1989-UP		SS1F (TRUCKS) HINO F17DT , 1995	
SH1VA (TRUCKS) HINO V22D , 1991-1992		Fuel Filter.....	F-1303	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	SH3FA (TRUCKS) HINO F20C , 1991-1992		SS1F (TRUCKS) HINO F17DT , 1993-1995	
Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
SH1VB (TRUCKS) HINO V22D , 1992-1995		Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	SH3V (TRUCKS) HINO V26C , 1995		SS1V (TRUCKS) HINO V22D , 1990-1992	
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
SH215 (TRUCKS) HINO EK100 , 1984-UP		SH4F (TRUCKS) HINO F21C , 1995		Oil Filter By Pass.....	0-1310
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1310	SS2V (TRUCKS) HINO F20C , 1991-1992	
SH273 (TRUCKS) HINO EK100 , 1986-UP		SH601 (TRUCKS) HINO EF550 , 1981-1983		Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1310
SH275 (TRUCKS) HINO EK100E , 1982-1983		SH631 (TRUCKS) HINO EF750 , 1981-1983		Oil Filter Full Flow.....	C-1301
Air Filter Primary.....	A-5425	Air Filter Primary.....	A-5425	Oil Filter Full Flow.....	C-1309
SH280 (TRUCKS) HINO EP100 , 1987-UP		SH631 (TRUCKS) HINO EF750T , 1981-1983		SS2VA (TRUCKS) HINO V25C , 1990-1992	
Air Filter Primary.....	A-5425	Air Filter Primary.....	A-5425	Fuel Filter.....	F-1304
SH2F (TRUCKS) HINO F17E , 1991-1992		SH633 (TRUCKS) HINO EF750 V8 , 1987-UP		Oil Filter By Pass.....	0-1310
Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425	SS2VB (TRUCKS) HINO V25C , 1992-1995	
Oil Filter By Pass.....	0-1310	SH661 (TRUCKS) HINO F17C , 1987-1991		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
Oil Filter Full Flow.....	C-1309	Oil Filter By Pass.....	0-1310	SS3F (TRUCKS) HINO V25C , 1991-1992	
SH2FA (TRUCKS) HINO F17E , 1991-1992		SH691 (TRUCKS) HINO F17C , 1986-1991		Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	C-1301
SH2K (TRUCKS) HINO K13D , 1991-1992		SH711 (TRUCKS) HINO EV700 , 1986-UP		Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1304	Air Filter Primary.....	A-5425	SS631 (TRUCKS) HINO EF750T , 1983-1991	
Oil Filter Full Flow.....	0-13081	SH711 (TRUCKS) HINO EV700 , 1984-1986		Air Filter Primary.....	A-5425
SH2V (TRUCKS) HINO V25C , 1991-1992		Air Filter Primary.....	A-5425	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310	SS661 (TRUCKS) HINO F17C , 1987-1991	
Oil Filter By Pass.....	0-1310	SH711 (TRUCKS) HINO EV700 , 1984-1986		Fuel Filter.....	F-1304
SH2VA (TRUCKS) HINO V25C , 1991-1992		Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1310
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	SS691 (TRUCKS) HINO V21C , 1986-1991	
		Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
				Oil Filter By Pass.....	0-1310

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>SUPER EAGLE</b> (TRUCKS) HINO H07D (S/N: 195HP-UP) , 1991-1997		<b>TC582</b> (TRUCKS) HINO EF500 , 1978-1979		<b>UCH3H</b> (TRUCKS) HINO H07C , 1989	
Air Filter Primary.....	A-6006	Fuel Filter.....	F-1304	Air Filter.....	A-1310
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	O-1301	Oil Filter Combination.....	C-1303
Air Filter Secondary.....	A-6007	Oil Filter By Pass.....	O-1305		
Air Filter Set.....	A-6118-S			<b>UFB2W</b> (TRUCKS) HINO W04D , 1990	
Oil Filter Combination.....	C-1303			Air Filter.....	A-1308
		<b>TC585</b> (TRACTORS) HINO EF500 , 1980-1981		Fuel Filter.....	FC-1302
<b>SUPER EAGLE 1000</b> (TRUCKS) HINO H06C-T		Fuel Filter.....	F-1304		
Air Filter Set.....	A-6118-S			<b>U-FB2WC</b> (TRUCKS) HINO W04D , 1990-1995	
Air Filter Secondary.....	A-6007	<b>TC781</b> (TRUCKS) HINO EF100 , 1972-1975		Air Filter.....	A-1308
Air Filter Primary.....	A-6006	Fuel Filter.....	F-1303	Fuel Filter.....	FC-1302
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1302
Fuel Filter.....	F-1304				
Oil Filter Full Flow.....	C-1314	<b>TC782</b> (TRUCKS) HINO EF100 , 1975-1981		<b>U-FB2WE</b> (TRUCKS) HINO W04D , 1990-1995	
		Fuel Filter.....	F-1304	Air Filter.....	A-1308
<b>SUPER EAGLE 1000</b> (TRUCKS) HINO 6.5L INTERCOOLED		Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1302
Air Filter Primary.....	A-6006			Oil Filter Full Flow.....	C-1302
Air Filter Primary.....	A-60400	<b>TC782</b> (TRUCKS) HINO EF300 , 1975-1981			
Air Filter Secondary.....	A-6007	Fuel Filter.....	F-1304	<b>U-FB2WGAB</b> (TRUCKS) HINO W04D , 1990-1995	
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	O-1301	Fuel Filter.....	FC-1302
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	C-1302
Oil Filter Full Flow.....	C-1314				
		<b>TC782</b> (TRUCKS) HINO EK100 , 1975-1979		<b>UFC2J</b> (TRUCKS) HINO J08C , 1995	
<b>SUPER EAGLE 900</b> (TRUCKS) HINO H07D 7.4L		Fuel Filter.....	F-1303	Air Filter Primary.....	A-1156
Air Filter Set.....	A-6118-S	Oil Filter By Pass.....	O-1305	Air Filter Set.....	A-1156-S
Air Filter Secondary.....	A-6007	Oil Filter Full Flow.....	O-1301	Oil Filter Combination.....	C-1303
Air Filter Primary.....	A-6006				
Air Filter Primary.....	A-60400	<b>TC921</b> (TRUCKS) HINO ED100 , 1972-1975		<b>U-FC300</b> (TRUCKS) HINO W06E (S/N: 163HP-UP) , 1990-1995	
Fuel Filter.....	F-1304	Fuel Filter.....	F-1302	Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	C-1314	Oil Filter Full Flow.....	O-1303	Oil Filter Full Flow.....	C-1309
<b>TC303</b> (TRUCKS) HINO EK100 , 1975		<b>TE100</b> (TRUCKS) HINO DS70 , 1970-1977		<b>UFC3H</b> (TRUCKS) HINO H07D , 1990-1995	
Fuel Filter.....	F-1303	Fuel Filter.....	F-1302	Air Filter.....	A-1310
Oil Filter Full Flow.....	O-1301			Oil Filter Combination.....	C-1303
Oil Filter By Pass.....	O-1305	<b>UAB2W</b> (TRUCKS) HINO W04D , 1989-UP			
		Air Filter.....	A-1308	<b>UFC3W</b> (TRUCKS) HINO W06E , 1990-1995	
<b>TC323</b> (TRUCKS) HINO EK100 , 1975-1979		Fuel Filter.....	FC-1302	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-1302	Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1305				
Oil Filter Full Flow.....	O-1301	<b>UAB2W</b> (BUSES) HINO W04D , 1989-1995		<b>UFC3W</b> (TRUCKS) HINO W06D , 1990	
		Air Filter.....	A-1308	Air Filter.....	A-1310
<b>TC541</b> (TRACTORS) HINO EG100 , 1971-1977		Fuel Filter.....	FC-1302	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1303	Oil Filter Full Flow.....	C-1302	Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	O-1301				
<b>TC562</b> (TRUCKS) HINO EF700 , 1977-1981		<b>U-AB2W</b> (TRUCKS) HINO W04D-T (S/N: 114HP-UP)		<b>UFD1H</b> (TRUCKS) HINO H06C-T , 1989-1994	
Fuel Filter.....	F-1304	Fuel Filter.....	FC-1302	Oil Filter Combination.....	C-1303
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1302		
Oil Filter Full Flow.....	O-13081			<b>UFD1H</b> (TRUCKS) HINO JH06CT , 1989	
Oil Filter By Pass.....	O-1305	<b>UCH3H</b> (TRUCKS) HINO H07D , 1989-UP		Air Filter.....	A-1310
		Air Filter.....	A-1310	Oil Filter Combination.....	C-1303
<b>TC562</b> (TRACTORS) HINO EF700 , 1977-1979		Oil Filter Combination.....	C-1303		
Fuel Filter.....	F-1304			<b>UFD1J</b> (TRUCKS) HINO J08C , 1991-1994	
Oil Filter By Pass.....	O-1305	<b>UCH3H</b> (TRUCKS) HINO H07D , 1989-1995		Air Filter.....	A-1310
Oil Filter Full Flow.....	O-1301	Air Filter.....	A-1310	Oil Filter Combination.....	C-1303
		Oil Filter Combination.....	C-1303		

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>U-FD1W</b> (TRUCKS) HINO W06E , 1989		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Air Filter.....	A-1306	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	C-1301	Oil Filter By Pass.....	0-1310		
Oil Filter Full Flow.....	C-1309			<b>UFP1F</b> (TRUCKS) HINO F17D , 1989-1992	
<b>U-FD300</b> (TRUCKS) HINO W06E (S/N: 163HP-UP) , 1989-1994		<b>UFN1F</b> (TRUCKS) HINO F17DT , 1991-1992		Fuel Filter.....	F-1304
Air Filter Set.....	A-6118-S	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
Air Filter Primary.....	A-6006	Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1310
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-13081		
Oil Filter Full Flow.....	C-1301			<b>UFP1F</b> (TRUCKS) HINO F17D , 1989	
Oil Filter Full Flow.....	C-1309	<b>UFN1F</b> (TRUCKS) HINO F17E , 1991-1992		Fuel Filter.....	F-1304
<b>UFD3H</b> (TRUCKS) HINO H07D , 1989-1994		Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
Air Filter.....	A-1310	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311
Air Filter Primary.....	A-6006	Oil Filter By Pass.....	0-1310		
Air Filter Primary.....	A-60400	Oil Filter Full Flow.....	0-13081	<b>UFP1K</b> (TRUCKS) HINO K13CT , 1992-1995	
Air Filter Set.....	A-6118-S			Fuel Filter.....	F-1304
Oil Filter Combination.....	C-1303	<b>UFN1FA</b> (TRUCKS) HINO F17DT , 1989-1992		Oil Filter Full Flow.....	0-13081
<b>UFD3W</b> (TRUCKS) HINO W06E , 1989-1994		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Air Filter.....	A-1306	Oil Filter By Pass.....	0-1310		
Air Filter Set.....	A-6118-S	Oil Filter Full Flow.....	0-13081	<b>UFP1P</b> (TRUCKS) HINO P09CT , 1989-UP	
Air Filter Primary.....	A-6006			Fuel Filter.....	F-1304
Air Filter Primary.....	A-60400	<b>UFN1FB</b> (TRUCKS) HINO F17DT , 1992-1995		Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	C-1301	Fuel Filter.....	F-1304		
Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	0-13081	<b>UFP1P</b> (TRUCKS) HINO P09CT , 1989-1992	
<b>UFD3W</b> (TRUCKS) HINO W08E , 1989-1994		Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	C-1301			Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	C-1309	<b>UFN1K</b> (TRUCKS) HINO K13CT , 1992		Oil Filter By Pass.....	0-1311
<b>UFG1H</b> (TRUCKS) HINO H06C-TI , 1989-1994		Fuel Filter.....	F-1304		
Oil Filter Combination.....	C-1303	Oil Filter By Pass.....	0-1311	<b>UFP2F</b> (TRUCKS) HINO F17E , 1992-1995	
<b>UFH2K</b> (TRUCKS) HINO K13D , 1989-1992		Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Oil Filter By Pass.....	0-1311	Oil Filter By Pass.....	0-1310
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1311				
Oil Filter Full Flow.....	0-13081	<b>UFN1P</b> (TRUCKS) HINO P09CT , 1989-1992		<b>UFP2K</b> (TRUCKS) HINO K13D , 1992	
<b>UFH2KA</b> (TRUCKS) HINO K13D , 1990-1992		Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311	Oil Filter By Pass.....	0-1311
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1311				
<b>U-FK2K</b> (TRUCKS) HINO K130D , 1989-UP		<b>UFN1KA</b> (TRUCKS) HINO K13CT , 1989-1992		<b>UFP2K</b> (TRUCKS) HINO K13D , 1989-UP	
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311		
<b>UFN1F</b> (TRUCKS) HINO F17D , 1992		<b>UFN2F</b> (TRUCKS) HINO F17E , 1989-1992		<b>UFP2K</b> (TRUCKS) HINO K13D , 1989-1992	
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
<b>UFN1F</b> (TRUCKS) HINO F17D , 1991-1992		Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311		
Oil Filter Full Flow.....	0-13081			<b>UFP2P</b> (TRUCKS) HINO P11CT , 1992-1995	
<b>UFN1F</b> (TRUCKS) HINO F17D , 1991-1992		<b>UFN2P</b> (TRUCKS) HINO P11CT , 1992-1995		Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
<b>UFN1F</b> (TRUCKS) HINO F17D , 1991-1992					
Fuel Filter.....	F-1304			<b>UFQ1F</b> (TRUCKS) HINO F17D , 1992	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>UFQ1F</b> (TRUCKS) HINO F17D , 1992		Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-13081	<b>U-FR2F SRS</b> (TRUCKS) 1989-UP		<b>U-FS1K</b> (TRUCKS) HINO K13C , 1989-1991	
Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
<b>UFQ1F</b> (TRUCKS) HINO F17DT , 1989		<b>UFR2K</b> (TRUCKS) HINO K13D , 1989-1992		Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1311	<b>U-FS1KA</b> (TRUCKS) HINO K13CT , 1990-1992	
Oil Filter Full Flow.....	0-13081	<b>UFR2P</b> (TRUCKS) HINO P11CT , 1992-1995		Fuel Filter.....	F-1304
<b>U-FQ1F SRS</b> (TRUCKS) HINO F17DT , 1989-UP		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	<b>U-FS1KB</b> (TRUCKS) HINO K13CT , 1992-1995	
<b>UFQ2F</b> (TRUCKS) HINO F17E , 1992		<b>UFR2P</b> (TRUCKS) HINO P11C , 1990-UP		Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1311
Oil Filter By Pass.....	0-1310	<b>UFR2P</b> (TRUCKS) HINO P11C , 1990		<b>U-FS1VA</b> (TRUCKS) HINO V22D , 1991-1992	
<b>U-FQ2FA</b> (TRUCKS) HINO F17E , 1990-1992		Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	C-1301
Oil Filter Full Flow.....	0-13081	<b>UFR3F</b> (TRUCKS) HINO F20C , 1992		Oil Filter Full Flow.....	C-1309
<b>UFR1F</b> (TRUCKS) HINO F17D , 1992		Fuel Filter.....	F-1304	<b>U-FS1VB</b> (TRUCKS) HINO V22D , 1992-1995	
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	C-1301
Oil Filter By Pass.....	0-1310	<b>UFR3F</b> (TRUCKS) HINO F20C , 1989-1992		Oil Filter Full Flow.....	C-1309
<b>UFR1F</b> (TRUCKS) HINO F17D , 1989-1992		Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	C-1301
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	C-1309
Oil Filter Full Flow.....	0-13081	<b>U-FR3FA</b> (TRUCKS) HINO F20C , 1989-1992		<b>U-FS1VKA</b> (TRUCKS) HINO V22D , 1991-1992	
<b>U-FR1FB</b> (TRUCKS) HINO F17DT , 1992-1995		Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310
Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1310	Oil Filter Full Flow.....	C-1301
<b>UFR1K</b> (TRUCKS) HINO K13CT , 1992		Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1304	<b>UFR3F</b> (TRUCKS) HINO F20C , 1989-1992		<b>U-FS2F</b> (TRUCKS) HINO F17E , 1989-1992	
Oil Filter By Pass.....	0-1311	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
<b>UFR1K</b> (TRUCKS) HINO K13C , 1989-1992		Oil Filter By Pass.....	0-1311	Oil Filter By Pass.....	0-1310
Fuel Filter.....	F-1304	<b>UFRK</b> (TRUCKS) HINO K13D , 1992		Oil Filter Full Flow.....	0-13081
Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304	<b>U-FS2K</b> (TRUCKS) HINO F13D , 1989-1992	
Oil Filter By Pass.....	0-1311	Oil Filter Full Flow.....	0-13081	Fuel Filter.....	F-1304
<b>UFR1P</b> (TRUCKS) HINO P09CT , 1989-1992		Oil Filter By Pass.....	0-1311	Oil Filter By Pass.....	0-1311
Fuel Filter.....	F-1304	<b>UFS1F</b> (TRUCKS) HINO F17D , 1992		Oil Filter Full Flow.....	0-13081
Oil Filter By Pass.....	0-1311	Fuel Filter.....	F-1304	<b>U-FS2KA</b> (TRUCKS) HINO K13D , 1989-1992	
Oil Filter Full Flow.....	0-13081	Oil Filter By Pass.....	0-1310	Fuel Filter.....	F-1304
<b>UFR2F</b> (TRUCKS) HINO F17E , 1989-1992		Oil Filter Full Flow.....	0-13081	Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Oil Filter By Pass.....	0-1310	Oil Filter By Pass.....	0-1311
<b>UFR2F</b> (TRUCKS) HINO F17E , 1989-1992		<b>U-FS1K</b> (TRUCKS) HINO K13CT , 1992		Oil Filter Full Flow.....	0-13081
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	<b>U-FS2S</b> (TRUCKS) HINO F17E	

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
<b>U-FS3F</b> (TRUCKS) HINO F20C , 1989-1992		Oil Filter Full Flow.....	C-1309	<b>U-GN2K</b> (TRUCKS) HINO F13D , 1992	
Fuel Filter.....	F-1304	<b>U-FZ1FA</b> (TRUCKS) HINO F17D , 1990-1992		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1311
Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081
<b>U-FS3F</b> (TRUCKS) HINO F20C		Oil Filter By Pass.....	O-1310	<b>U-GN2KB</b> (TRUCKS) HINO F13D , 1992-1995	
Fuel Filter.....	F-1304	<b>U-FZ1FB</b> (TRUCKS) HINO F17D , 1993		Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1311
<b>U-FT3H</b> (TRUCKS) HINO H07D , 1989-1994		Oil Filter Full Flow.....	O-13081	<b>U-GN2P</b> (TRUCKS) HINO P11CT , 1992-1995	
Air Filter.....	A-1310	<b>UGD2H</b> (TRUCKS) HINO H07CT , 1989-1994		Fuel Filter.....	F-1304
Air Filter Primary.....	A-6006	Air Filter.....	A-1310	Oil Filter By Pass.....	O-1311
Air Filter Primary.....	A-60400	Oil Filter Combination.....	C-1303	Oil Filter Full Flow.....	O-13081
Air Filter Set.....	A-6118-S	<b>U-GK1H</b> (TRUCKS) HINO H06C-TI , 1989-1994		<b>U-GNF</b> (TRUCKS) HINO K13C , 1990-1992	
Oil Filter Combination.....	C-1303	Oil Filter Combination.....	C-1303	Fuel Filter.....	F-1304
<b>U-FU3F</b> (TRUCKS) HINO F20C , 1993		<b>U-GK1H</b> (TRUCKS) HINO H06C-T , 1989		Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1304	Air Filter.....	A-1310	Oil Filter By Pass.....	O-1311
Oil Filter By Pass.....	O-1310	Oil Filter Combination.....	C-1303	<b>UHT2M</b> (TRUCKS) HINO M10U , 1990-1995	
Oil Filter Full Flow.....	O-13081	<b>U-GN1F</b> (TRUCKS) HINO F17D , 1989-1992		Air Filter Set.....	A-6118-S
<b>U-FW1F</b> (TRUCKS) HINO F17D , 1989-1992		Fuel Filter.....	F-1304	Air Filter Primary.....	A-6006
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Air Filter Primary.....	A-60400
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1310	<b>U-GN1F SRS</b> (TRUCKS) HINO F120C , 1990-UP		Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1311	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
<b>U-FW1K</b> (TRUCKS) HINO K13CT , 1992		Oil Filter Full Flow.....	O-13081	<b>UHT2M</b> (TRUCKS) HINO M10U , 1989	
Fuel Filter.....	F-1304	<b>U-GN1FA</b> (TRUCKS) HINO F17D , 1989-1992		Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1311	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-1301
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
<b>U-FW1K</b> (TRUCKS) HINO K13C , 1989-1992		Oil Filter By Pass.....	O-1310	<b>UHT3K</b> (TRUCKS) HINO K13U , 1990-1995	
Fuel Filter.....	F-1304	<b>U-GN1FB</b> (TRUCKS) HINO F17D , 1992-1995		Fuel Filter.....	F-1304
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1311	Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	O-1301
<b>U-FW2FA</b> (TRUCKS) HINO F17E , 1989-1992		Oil Filter Full Flow.....	O-13081	<b>UHT3K</b> (TRUCKS) HINO K13U , 1989	
Fuel Filter.....	F-1304	<b>U-GN1P</b> (TRUCKS) HINO P09CT , 1989-1992		Air Filter Primary.....	A-6006
Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304	Air Filter Primary.....	A-60400
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	O-13081	Air Filter Set.....	A-6118-S
<b>U-FW2K</b> (TRUCKS) HINO K13D , 1989-1992		Oil Filter By Pass.....	O-1310	Fuel Filter.....	F-1304
Fuel Filter.....	F-1304	<b>U-GN2F</b> (TRUCKS) HINO F120C , 1990-1992		Oil Filter Full Flow.....	O-1301
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1311	Oil Filter By Pass.....	O-1310	<b>UHU2M</b> (TRUCKS) HINO M10U , 1990-1995	
<b>U-FW3F</b> (TRUCKS) HINO F20C , 1992-1995		Oil Filter Full Flow.....	O-13081	Air Filter Set.....	A-6118-S
Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310	Air Filter Primary.....	A-6006
Oil Filter By Pass.....	O-1310	<b>U-GN2F</b> (TRUCKS) HINO K13D , 1989-1992		Air Filter Primary.....	A-60400
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
<b>U-FX3H</b> (TRUCKS) HINO H07D , 1992-1994		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	C-1301	Oil Filter By Pass.....	O-1311	Oil Filter Full Flow.....	O-1301
				<b>UHU2M</b> (TRUCKS) HINO M10U , 1989	
				Fuel Filter.....	F-1304





MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
U-SD2H (TRUCKS) HINO H07CT , 1989-1994		Oil Filter Full Flow.....	O-13081	WSS1F (TRUCKS) HINO F17DT , 1993-1995	
Air Filter.....	A-1310	WSH1FB (TRUCKS) HINO F17D , 1992-1995		Fuel Filter.....	F-1304
Oil Filter Combination.....	C-1303	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081
VICTOR 500 (TRUCKS) J08E-WH		Oil Filter Full Flow.....	O-13081	Oil Filter By Pass.....	O-1310
Fuel Filter.....	EF-13110	Oil Filter By Pass.....	O-1310	WSS1V (TRUCKS) HINO V22D , 1990-1992	
VICTOR 500 (TRUCKS) J08E-WJ		WSH1FDB (TRUCKS) HINO F17DT , 1993		Fuel Filter.....	F-1304
Fuel Filter.....	EF-13110	Fuel Filter.....	F-1304	Oil Filter By Pass.....	O-1310
WB310 (TRUCKS) HINO EC100 , 1975-1978		Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	C-1301
Air Filter.....	A-1301	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1301	WSH1VA (TRUCKS) HINO V22D , 1991-1992		WSS1VJA (TRUCKS) HINO V22D , 1991-1992	
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
WB311 (TRUCKS) HINO EH100 , 1978-1979		Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	C-1301
Air Filter.....	AS-1303	Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1301	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-1301	WSH1VB (TRUCKS) HINO V22D , 1992-1995		WSS2V (TRUCKS) HINO V25C , 1992	
WD300 (TRUCKS) HINO EK100 , 1977-1980		Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Fuel Filter.....	F-1303	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310
Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	C-1301	Oil Filter Full Flow.....	O-13081
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	C-1309	WSS2VA (TRUCKS) HINO V25C , 1990-1992	
WD300D 4X4 (TRUCKS) HINO EK100 , 1981-UP		WSH2FA (TRUCKS) HINO F17E , 1991-1992		Fuel Filter.....	F-1304
Air Filter Primary.....	A-5425	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1304	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1311	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310
WD300D 4X4 (TRUCKS) HINO EK100 , 1977-1981		WSH2FB (TRUCKS) HINO F17E , 1992-1995		WSS2VJA (TRUCKS) HINO V25C , 1991-1992	
Fuel Filter.....	F-1303	Fuel Filter.....	F-1304	Fuel Filter.....	F-1304
Oil Filter By Pass.....	O-1305	Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1311
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1301
WG300 (TRACTORS) HINO EG100 , 1973-1977		WSH2K (TRUCKS) HINO K13D , 1991-1992		Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1303	Fuel Filter.....	F-1304	WSS3F (TRUCKS) HINO F20C , 1991-1992	
Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304
WP325 (TRUCKS) HINO EK500 , 1974-1978		Oil Filter By Pass.....	O-1311	Oil Filter Full Flow.....	O-13081
Fuel Filter.....	F-1303	WSH2VA (TRUCKS) HINO V25C , 1991-1992		Oil Filter By Pass.....	O-1310
Oil Filter Full Flow.....	O-1301	Fuel Filter.....	F-1304	XZU130X (TRUCKS) HINO J05C , 1995	
Oil Filter By Pass.....	O-1305	Oil Filter By Pass.....	O-1310	Air Filter.....	A-1112
WP4F (TRUCKS) HINO F21C , 1998		Oil Filter Full Flow.....	C-1301	Fuel Filter.....	FC-1302
Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1309	Oil Filter Full Flow.....	C-1301
WSFJA (TRUCKS) HINO F20C , 1991-1992		Oil Filter By Pass.....	O-1310	Oil Filter Full Flow.....	C-1309
Fuel Filter.....	F-1304	WSH3FB (TRUCKS) HINO F20C , 1992-1995		XZU140M (TRUCKS) HINO J05C , 1997	
Oil Filter Full Flow.....	O-13081	Fuel Filter.....	F-1304	Air Filter.....	A-1112
Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310	Fuel Filter.....	FC-1302
WSH1FA (TRUCKS) HINO F17D , 1991-1992		Oil Filter Full Flow.....	O-13081	Oil Filter Full Flow.....	C-1301
Fuel Filter.....	F-1304	Fuel Filter.....	F-1304	Oil Filter Full Flow.....	C-1309
Oil Filter By Pass.....	O-1310	Oil Filter By Pass.....	O-1310	XZU300E (TRUCKS) HINO J05C , 1999	
		Oil Filter Full Flow.....	O-13081	Fuel Filter.....	FC-1206
				XZU301 (TRUCKS) HINO S05D , 1999	

# Sakura Filter

# ENGINE APPLICATION

MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO	MODEL/APPLICATION	SAKURA NO
<b>HINO</b>		<b>HINO</b>		<b>HINO</b>	
XZU301 (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	XZU424R (300 SERIES) (TRUCKS) HINO S05C-TI Oil Filter Combination.....	C-1303	ZM302 (TRUCKS) HINO EK100 , 1975-UP Fuel Filter.....	F-1303
XZU301E (TRUCKS) TOYOTA 15BLPG , 2000 Oil Filter Combination.....	C-1112	XZU434R (300 SERIES) (TRUCKS) HINO S05C-TI Oil Filter Combination.....	C-1303	Oil Filter By Pass.....	O-1305
XZU301E (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	ZC100 (TRUCKS) HINO ED100 , 1975-1979 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
XZU301X (TRUCKS) HINO 15BLPG , 2000 Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	O-1303	ZM312 (TRUCKS) HINO EK100 , 1979-UP Fuel Filter.....	F-1303
XZU302 (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	ZG150 (TRUCKS) HINO ED100 , 1978-UP Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
XZU302E (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	O-1303	ZM500 (TRUCKS) HINO EF500 , 1977-1979 Fuel Filter.....	F-1304
XZU320 (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1707	ZH100 (TRUCKS) HINO ED100 , 1979-UP Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
XZU382M (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	O-1303	ZM702 (TRUCKS) HINO EF100 , 1972-1975 Fuel Filter.....	F-1303
XZU400X (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1206	ZH100 (TRUCKS) HINO ED100 , 1975-1979 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
XZU401M (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	O-1303	ZM704 (TRUCKS) HINO EF300 , 1975-1977 Fuel Filter.....	F-1303
XZU410M (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	ZH100D (TRUCKS) HINO EB300 , 1972-1977 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
XZU411M (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	O-1303	ZM705 (TRUCKS) HINO EF300 , 1979 Oil Filter Full Flow.....	O-1301
XZU412 (TRUCKS) HINO 15BCNG , 2000 Oil Filter Combination.....	C-1112	ZH100D (TRUCKS) HINO ED100 , 1972-1977 Fuel Filter.....	F-1302	ZR101 (CRANES) HINO EB300 , 1972-1976 Fuel Filter.....	F-1302
XZU412 (TRUCKS) TOYOTA 15BCNG , 2000 Oil Filter Combination.....	C-1112	Oil Filter Full Flow.....	O-1303	Oil Filter Full Flow.....	O-1303
XZU414R (300 SERIES) (TRUCKS) HINO S05C-TI Oil Filter Combination.....	C-1303	ZH110D (TRUCKS) HINO ED100 , 1975-1977 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1303
XZU420M (TRUCKS) HINO J05C , 1999 Fuel Filter.....	FC-1206	Oil Filter Full Flow.....	O-1303	ZR250 (CRANES) HINO EB300 , 1975-1977 Fuel Filter.....	F-1302
XZU421M (TRUCKS) HINO S05C , 1999 Fuel Filter.....	FC-1707	ZL110 (CRANES) HINO EB300 , 1977-1979 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1303
XZU421M (TRUCKS) HINO S05D , 1999 Fuel Filter.....	FC-1707	Oil Filter Full Flow.....	O-1303	Oil Filter By Pass.....	O-1305
		ZM102D (TRUCKS) HINO ED100 , 1973-1976 Fuel Filter.....	F-1302	ZR255 (CRANES) HINO EK100 , 1976-UP Fuel Filter.....	F-1303
		Oil Filter Full Flow.....	O-1303	Oil Filter Full Flow.....	O-1301
		Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301
		ZM103D (TRUCKS) HINO EM100 , 1976-1979 Fuel Filter.....	F-1303	ZR255 (CRANES) HINO EK100 , 1975-1981 Fuel Filter.....	F-1303
		Oil Filter Full Flow.....	O-1301	Oil Filter Full Flow.....	O-1301
		ZM300 (TRUCKS) HINO ED100 , 1971-1979 Fuel Filter.....	F-1302	Oil Filter Full Flow.....	O-1301
		Oil Filter Full Flow.....	O-1303	ZR300 (CRANES) HINO ED100 , 1973-1979 Fuel Filter.....	F-1302
		ZM302 (TRUCKS) HINO EM100 , 1975-UP Fuel Filter.....	F-1303	Oil Filter Full Flow.....	O-1303
		Oil Filter Full Flow.....	O-1301	ZT300 (CRANES) HINO EB300 , 1979-1981 Fuel Filter.....	F-1302
		Oil Filter By Pass.....	O-1305	Oil Filter Full Flow.....	O-1303
				ZT300 (CRANES) HINO EB300 , 1972-1979 Fuel Filter.....	F-1302
				Oil Filter Full Flow.....	O-1303

MODEL/APPLICATION	SAKURA NO
<b>HINO</b>	

ZT300  
(CRANES)  
HINO ED100

Fuel Filter..... F-1302  
Oil Filter Full Flow..... O-1303




# Technical Specification

**B**

# Sakura Filter

# Technical Specification

**A-1013** Air Filter Primary Metal End Cap Element



ISUZU 1-14214126-0  
ISUZU 1-14215-181-0  
ISUZU 1-86750-309-0  
NISSAN 16546-96071  
NISSAN 16546-99218  
Secondary Filter uses A-5631  
Set Filter uses A-1841-S  
H 1 : 394.7 (mm)  
H 2 : 382 (mm)  
OD 1 : 276 (mm)  
OD 2 : 275 (mm)  
ID 1 : 165 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.046

Note : Is a Primary Air Filter for A-5631,A-7607

**A-1156** Air Filter Primary Soft PU end cap Element



HINO 17801-3000  
HINO 17902-1110  
ISUZU 5-86500664-0  
ISUZU 5-86509144-0  
NISSAN AY120-TY073  
Secondary Filter uses A-1319  
Set Filter uses A-1156-S  
H 1 : 348 (mm)  
H 2 : 335 (mm)  
OD 1 : 237 (mm)  
OD 2 : 237 (mm)  
ID 1 : 132 (mm)

CONT : 1  
VOL : 0.024

**A-1304** Air Filter Metal End Cap Element




HINO 17801-1020

H 1 : 317.75 (mm)  
H 2 : 305 (mm)  
OD 1 : 280 (mm)  
OD 2 : 280 (mm)  
ID 1 : 170 (mm)  
ID 2 : 12 (mm)

CONT : 1  
VOL : 0.029

Note : with fins version uses AS-1304

**A-1108** Air Filter Plastic Element




TOYOTA 17801-44010  
TOYOTA 17801-48010  
TOYOTA 17801-48011

H 1 : 145 (mm)  
OD 1 : 195 (mm)  
OD 2 : 195 (mm)  
ID 1 : 85 (mm)  
ID 2 : 85 (mm)

CONT : 18  
VOL : 0.121

**A-1156-S** Air Filter Set Soft PU end cap Element



HINO 17801-3000+17801-3030A

Primary Filter uses A-1156  
Secondary Filter uses A-1319  
H 1 : 348 (mm)  
H 2 : 335 (mm)  
OD 1 : 237 (mm)  
OD 2 : 237 (mm)  
ID 1 : 132 (mm)

CONT : 1  
VOL : 0.024

**A-1305** Air Filter Metal End Cap Element




ISUZU 1-14215150-0  
HINO 17801-2440  
TOYOTA 17801-58020

H 1 : 288.75 (mm)  
H 2 : 279 (mm)  
OD 1 : 190 (mm)  
OD 2 : 190 (mm)  
ID 1 : 105 (mm)  
ID 2 : 23 (mm)

CONT : 12  
VOL : 0.158

**A-1112** Air Filter Hard PU end cap Element




TOYOTA 17801-60040  
TOYOTA 17801-61030  
TOYOTA 17801-66020  
TOYOTA 17801-66030  
TOYOTA 17801-67010

H 1 : 146 (mm)  
H 2 : 143 (mm)  
OD 1 : 218 (mm)  
OD 2 : 218 (mm)  
ID 1 : 109 (mm)  
ID 2 : 109 (mm)

CONT : 8  
VOL : 0.072

**A-1177** Air Filter Primary Soft PU end cap Element



TOYOTA 17801-78020  
TOYOTA 17801-78030  
TOYOTA SUJ17T0101

Secondary Filter uses A-59060  
Set Filter uses A-1177-S  
H 1 : 263 (mm)  
H 2 : 250 (mm)  
OD 1 : 237 (mm)  
OD 2 : 237 (mm)  
ID 1 : 132 (mm)

CONT : 4  
VOL : 0.074

**A-1306** Air Filter Metal End Cap Element




HINO 17220-4090  
HINO 17220-4090B  
HINO 17801-2200

H 1 : 326.7 (mm)  
H 2 : 314 (mm)  
OD 1 : 216 (mm)  
OD 2 : 216 (mm)  
ID 1 : 137 (mm)  
ID 2 : 23 (mm)

CONT : 4  
VOL : 0.078

Note : with hotmelt

**A-1119** Air Filter Metal End Cap Element




TOYOTA 17801-44070  
DAIHATSU 17801-44070-000  
HINO 1780B-56020

H 1 : 145 (mm)  
OD 1 : 195 (mm)  
OD 2 : 195 (mm)  
ID 1 : 85 (mm)  
ID 2 : 85 (mm)

CONT : 18  
VOL : 0.117

**A-1301** Air Filter Metal End Cap Element




HINO 17801-1960  
HINO 6302-2000-80  
HINO 6302-2200-80

H 1 : 251 (mm)  
H 2 : 240 (mm)  
OD 1 : 201 (mm)  
OD 2 : 201 (mm)  
ID 1 : 97 (mm)  
ID 2 : 14 (mm)

CONT : 6  
VOL : 0.083

**A-1307** Air Filter Secondary Metal End Cap Element



ISUZU 1-14215085-0  
HINO 17801-2460  
CATERPILLAR 3I-0179

Primary Filter uses A-1313  
Set Filter uses A-5662-S  
H 1 : 444.7 (mm)  
H 2 : 432 (mm)  
OD 1 : 145 (mm)  
OD 2 : 145 (mm)  
ID 1 : 116.5 (mm)  
ID 2 : 23 (mm)

CONT : 9  
VOL : 0.106

**A-1135** Air Filter Plastic Element




TOYOTA 17801-61030  
TOYOTA 17801-68020  
HINO BHL10-01131

H 1 : 144 (mm)  
OD 1 : 220 (mm)  
OD 2 : 220 (mm)  
ID 1 : 108 (mm)  
ID 2 : 108 (mm)

CONT : 8  
VOL : 0.075

**A-1303** Air Filter Metal End Cap Element



HINO 17801-1720  
HINO 6302-2200-20  
HINO 6302-2210-20

H 1 : 301 (mm)  
H 2 : 290 (mm)  
OD 1 : 201 (mm)  
OD 2 : 201 (mm)  
ID 1 : 97 (mm)  
ID 2 : 14 (mm)

CONT : 12  
VOL : 0.184

**A-1308** Air Filter Metal End Cap Element



HINO 17801-2410

H 1 : 244.7 (mm)  
H 2 : 235 (mm)  
OD 1 : 190 (mm)  
OD 2 : 190 (mm)  
ID 1 : 105 (mm)  
ID 2 : 23 (mm)

CONT : 12  
VOL : 0.159

# Sakura Filter

# Technical Specification

**A-1309** Air Filter Primary Metal End Cap Element

HINO 17801-2490



Secondary Filter uses A-6011  
Set Filter uses A-1309-S  
H 1 : 493 (mm)  
H 2 : 480 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.052

**A-1313** Air Filter Primary Metal End Cap Element

CATERPILLAR 099-5801  
ISUZU 1-14215084-0  
HINO 17720-3640  
HINO 17801-2530



Secondary Filter uses A-1307  
Set Filter uses A-5662-S  
H 1 : 469.75 (mm)  
H 2 : 457 (mm)  
OD 1 : 232 (mm)  
OD 2 : 232 (mm)  
ID 1 : 147 (mm)  
ID 2 : 23 (mm)

CONT : 4  
VOL : 0.123

**A-1318** Air Filter Secondary Metal End Cap Element

HINO 17801-2900



H 1 : 314.7 (mm)  
H 2 : 302 (mm)  
OD 1 : 162.5 (mm)  
OD 2 : 162.5 (mm)  
ID 1 : 134 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.098

**A-1309-S** Air Filter Set Metal End Cap Element

HINO 17801-2490+17801-2320



Primary Filter uses A-1309  
Secondary Filter uses A-6011  
H 1 : 493 (mm)  
H 2 : 480 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.052

**A-1314** Air Filter Primary Metal End Cap Element

HINO 17801-2890A




Secondary Filter uses A-1318  
Set Filter uses A-1314-S  
H 1 : 371.7 (mm)  
H 2 : 359 (mm)  
OD 1 : 276 (mm)  
OD 2 : 275 (mm)  
ID 1 : 165 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.033

**A-1319** Air Filter Secondary Soft PU end cap Element

HINO 17801-3030A



Primary Filter uses A-1156  
Set Filter uses A-1156-S  
H 1 : 334 (mm)  
H 2 : 328 (mm)  
OD 1 : 132.4 (mm)  
OD 2 : 125 (mm)  
ID 1 : 110.8 (mm)

CONT : 25  
VOL : 0.192

**A-13092-S** Air Filter Set Metal End Cap Element

HINO 17801-2490+17801-3050



Primary Filter uses A-1309  
Secondary Filter uses A-13550  
H 1 : 493 (mm)  
H 2 : 480 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.054

**A-1314-S** Air Filter Set Metal End Cap Element

HINO 17801-2890A+17801-2900




Primary Filter uses A-1314  
Secondary Filter uses A-1318  
H 1 : 371.7 (mm)  
H 2 : 359 (mm)  
OD 1 : 276 (mm)  
OD 2 : 275 (mm)  
ID 1 : 165 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.036

**A-1320** Air Filter Secondary Metal End Cap Element

HINO 17801-3190




Primary Filter uses A-1338  
Set Filter uses A-1338-S  
H 1 : 339.7 (mm)  
H 2 : 327 (mm)  
OD 1 : 187.5 (mm)  
OD 2 : 187.5 (mm)  
ID 1 : 157 (mm)  
ID 2 : 22 (mm)

CONT : 4  
VOL : 0.073

Note : for HINO-JO8C

**A-1310** Air Filter Metal End Cap Element

HINO 17801-2730  
HINO 17801-2820




H 1 : 342.7 (mm)  
H 2 : 330 (mm)  
OD 1 : 230 (mm)  
OD 2 : 230 (mm)  
ID 1 : 121 (mm)  
ID 2 : 22.5 (mm)

CONT : 4  
VOL : 0.093

**A-1315** Air Filter Metal End Cap Element

HINO 17801-2590



H 1 : 451 (mm)  
OD 1 : 290 (mm)  
OD 2 : 290 (mm)  
ID 1 : 180 (mm)  
ID 2 : 22.5 (mm)

CONT : 1  
VOL : 0.047

**A-1322** Air Filter Soft PU+Metal Element

HINO 17801-1070  
HINO 17801-2980



H 1 : 341 (mm)  
H 2 : 326 (mm)  
OD 1 : 237 (mm)  
OD 2 : 228 (mm)  
ID 1 : 125 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.022

**A-1311** Air Filter Metal End Cap Element

HINO 17801-2850



H 1 : 342.7 (mm)  
H 2 : 330 (mm)  
OD 1 : 230 (mm)  
OD 2 : 230 (mm)  
ID 1 : 121 (mm)  
ID 2 : 22.5 (mm)

CONT : 4  
VOL : 0.091

**A-1317** Air Filter Soft PU+Metal Element

HINO 17801-2960  
NISSAN AY120-HD501




H 1 : 370 (mm)  
H 2 : 360 (mm)  
OD 1 : 274 (mm)  
OD 2 : 273 (mm)  
ID 1 : 153 (mm)  
ID 2 : 14 (mm)

CONT : 1  
VOL : 0.032

**A-1323** Air Filter Metal End Cap Element

HINO 17801-2830



H 1 : 364.7 (mm)  
H 2 : 352 (mm)  
OD 1 : 273 (mm)  
OD 2 : 273 (mm)  
ID 1 : 163 (mm)  
ID 2 : 22.5 (mm)

CONT : 1  
VOL : 0.032

**A-1324** Air Filter Primary Soft PU end cap Element



HINO 17801-3360  
TOYOTA 17801-E0010  
HINO 17902-1140  
HINO 17902-3360  
ISUZU 5-86511-352-0

Secondary Filter uses A-1326  
Set Filter uses A-1324-S

H 1 : 343 (mm)  
H 2 : 320 (mm)  
OD 1 : 215 (mm)  
OD 2 : 215 (mm)  
ID 1 : 117 (mm)

CONT : 6  
VOL : 0.117

31

**A-1326** Air Filter Secondary Soft PU end cap Element



HINO 17801-3370

Primary Filter uses A-1324  
Set Filter uses A-1324-S

H 1 : 334.5 (mm)  
H 2 : 327 (mm)  
OD 1 : 112 (mm)  
OD 2 : 106 (mm)  
ID 1 : 81 (mm)

CONT : 9  
VOL : 0.062

36

**A-1331-S** Air Filter Set Soft PU end cap Element



HINO 17801-3380+17801-3390

Primary Filter uses A-1325  
Secondary Filter uses A-1330

H 1 : 438 (mm)  
H 2 : 413 (mm)  
OD 1 : 228 (mm)  
OD 2 : 228 (mm)  
ID 1 : 115 (mm)

CONT : 1  
VOL : 0.027

41

**A-1324-S** Air Filter Set Soft PU end cap Element



HINO 17801-3360+17801-3370

Primary Filter uses A-1324  
Secondary Filter uses A-1326


H 1 : 343 (mm)  
H 2 : 320 (mm)  
OD 1 : 215 (mm)  
OD 2 : 215 (mm)  
ID 1 : 117 (mm)

CONT : 4  
VOL : 0.077

Note : with metal reinforcement version uses A-1324M-S

32

**A-1327** Air Filter Primary Soft PU end cap Element



HINO 17801-2990

Secondary Filter uses A-1328  
Set Filter uses A-1329-S

H 1 : 347 (mm)  
H 2 : 335 (mm)  
OD 1 : 208 (mm)  
OD 2 : 208 (mm)  
ID 1 : 124.4 (mm)

CONT : 1  
VOL : 0.020

37

**A-1334** Air Filter Metal End Cap Element



HINO 17801-2810

H 1 : 471.75 (mm)  
H 2 : 459 (mm)  
OD 1 : 234 (mm)  
OD 2 : 234 (mm)  
ID 1 : 123 (mm)  
ID 2 : 17 (mm)

CONT : 4  
VOL : 0.123

42

**A-1324M** Air Filter Primary Soft PU+Metal Element with metal reinforcement



HINO 17801-3360

Secondary Filter uses A-1326  
Set Filter uses A-1324M-S

H 1 : 343 (mm)  
H 2 : 320 (mm)  
OD 1 : 215 (mm)  
OD 2 : 215 (mm)  
ID 1 : 117 (mm)

CONT : 6  
VOL : 0.117

33

**A-1328** Air Filter Secondary Soft PU end cap Element



HINO 17801-3020


Primary Filter uses A-1327  
Set Filter uses A-1329-S

H 1 : 330 (mm)  
H 2 : 324 (mm)  
OD 1 : 124 (mm)  
OD 2 : 117 (mm)  
ID 1 : 104 (mm)

CONT : 9  
VOL : 0.066

38

**A-1335M** Air Filter Primary Soft PU+Metal Element



HINO 17801-3450  
HINO 17902-1150  
ISUZU 5-86511-808-0  
ISUZU 5-86521-602-0  
HINO S1790-21150

Secondary Filter uses A-1336M  
Set Filter uses A-1335M-S

H 1 : 374 (mm)  
H 2 : 361 (mm)  
OD 1 : 277 (mm)  
OD 2 : 277 (mm)  
ID 1 : 174 (mm)

CONT : 1  
VOL : 0.034

43

**A-1324M-S** Air Filter Set Soft PU+Metal Element with metal reinforcement



HINO 17801-3360+17801-3370

Primary Filter uses A-1324M  
Secondary Filter uses A-1326

H 1 : 343 (mm)  
H 2 : 320 (mm)  
OD 1 : 215 (mm)  
OD 2 : 215 (mm)  
ID 1 : 117 (mm)

CONT : 6  
VOL : 0.120

34

**A-1329-S** Air Filter Set Soft PU end cap Element



HINO 17801-2990+17801-3020

Primary Filter uses A-1327  
Secondary Filter uses A-1328

H 1 : 347 (mm)  
H 2 : 335 (mm)  
OD 1 : 208 (mm)  
OD 2 : 208 (mm)  
ID 1 : 124.4 (mm)

CONT : 1  
VOL : 0.020

39

**A-1335M-S** Air Filter Set Soft PU+Metal Element



HINO 17801-3450+17801-3460

Primary Filter uses A-1335M  
Secondary Filter uses A-1336M

H 1 : 374 (mm)  
H 2 : 361 (mm)  
OD 1 : 277 (mm)  
OD 2 : 277 (mm)  
ID 1 : 174 (mm)

CONT : 1  
VOL : 0.034

44

**A-1325** Air Filter Primary Soft PU end cap Element



HINO 17801-3380

Secondary Filter uses A-1330  
Set Filter uses A-1331-S

H 1 : 438 (mm)  
H 2 : 413 (mm)  
OD 1 : 228 (mm)  
OD 2 : 228 (mm)  
ID 1 : 115 (mm)

CONT : 1  
VOL : 0.028

35

**A-1330** Air Filter Secondary Soft PU end cap Element



HINO 17801-3390

Primary Filter uses A-1325  
Set Filter uses A-1331-S

H 1 : 427.5 (mm)  
H 2 : 420 (mm)  
OD 1 : 110 (mm)  
OD 2 : 102 (mm)  
ID 1 : 81 (mm)

CONT : 9  
VOL : 0.066

40

**A-1336M** Air Filter Secondary Soft PU+Metal Element



HINO 17801-3460

Primary Filter uses A-1335M  
Set Filter uses A-1335M-S

H 1 : 357.5 (mm)  
H 2 : 355 (mm)  
OD 1 : 173 (mm)  
OD 2 : 166.5 (mm)  
ID 1 : 128 (mm)

CONT : 1  
VOL : 0.014

45



**A-1337** Air Filter Metal End Cap Element

HINO 17801-0W030  
HINO 17801-1131  
TOYOTA 17801-0W030



H 1 : 145 (mm)  
OD 1 : 220 (mm)  
OD 2 : 220 (mm)  
ID 1 : 108.5 (mm)  
ID 2 : 108.5 (mm)

CONT : 1  
VOL : 0.009

46

**A-1341** Air Filter Secondary Metal End Cap Element

HINO 17801-3480



Primary Filter uses A-1342  
Set Filter uses A-1342-S

H 1 : 369.7 (mm)  
H 2 : 357 (mm)  
OD 1 : 185 (mm)  
OD 2 : 185 (mm)  
ID 1 : 157.5 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.146

51

**A-13510-S** Air Filter Set Metal End Cap Element

HINO 17801-3150P+17801-3160P



Primary Filter uses A-13490  
Secondary Filter uses A-13500

H 1 : 470.75 (mm)  
H 2 : 461 (mm)  
OD 1 : 273 (mm)  
OD 2 : 273 (mm)  
ID 1 : 157 (mm)  
ID 2 : 22 (mm)

CONT : 4  
VOL : 0.179

56

**A-1338** Air Filter Primary Metal End Cap Element

HINO 17801-3180A



Secondary Filter uses A-1320  
Set Filter uses A-1338-S

H 1 : 373.7 (mm)  
H 2 : 361 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.045

Note : HINO-JO8C

47

**A-1342** Air Filter Primary Metal End Cap Element

HINO 17801-3470  
TOYOTA 17801-E0060  
HINO 17801-LDE70  
HINO S1780-13470



Secondary Filter uses A-1341  
Set Filter uses A-1342-S

H 1 : 412.7 (mm)  
H 2 : 400 (mm)  
OD 1 : 329 (mm)  
OD 2 : 329 (mm)  
ID 1 : 218 (mm)  
ID 2 : 17.5 (mm)

CONT : 1  
VOL : 0.055

52

**A-13520** Air Filter Secondary Metal End Cap Element

HINO 17801-3170P



H 1 : 439.75 (mm)  
H 2 : 427 (mm)  
OD 1 : 145 (mm)  
OD 2 : 145 (mm)  
ID 1 : 116.5 (mm)  
ID 2 : 23 (mm)

CONT : 9  
VOL : 0.112

57

**A-1338-S** Air Filter Set Metal End Cap Element

HINO 17801-3180+17801-3190



Primary Filter uses A-1338  
Secondary Filter uses A-1320

H 1 : 373.7 (mm)  
H 2 : 361 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)


CONT : 1  
VOL : 0.045

Note : for HINO-JO8C

48

**A-1342-S** Air Filter Set Metal End Cap Element

HINO 17801-3470+17801-3480



Primary Filter uses A-1342  
Secondary Filter uses A-1341


H 1 : 412.7 (mm)  
H 2 : 400 (mm)  
OD 1 : 329 (mm)  
OD 2 : 329 (mm)  
ID 1 : 218 (mm)  
ID 2 : 17.5 (mm)

CONT : 1  
VOL : 0.055

53

**A-13550** Air Filter Secondary Metal End Cap Element

HINO 17801-3050P



Primary Filter uses A-1309  
Set Filter uses A-13092-S

H 1 : 469.75 (mm)  
H 2 : 457 (mm)  
OD 1 : 185 (mm)  
OD 2 : 185 (mm)  
ID 1 : 157.5 (mm)  
ID 2 : 23 (mm)

CONT : 9  
VOL : 0.181

Note : for Hino K13D

58

**A-1339** Air Filter Metal End Cap Element

HINO 17801-3270A



H 1 : 382 (mm)  
H 2 : 369 (mm)  
OD 1 : 308 (mm)  
OD 2 : 308 (mm)  
ID 1 : 196 (mm)  
ID 2 : 22.7 (mm)

CONT : 1  
VOL : 0.045

49

**A-13490** Air Filter Primary Metal End Cap Element

HINO 17801-3150P



Secondary Filter uses A-13500  
Set Filter uses A-13510-S

H 1 : 470.75 (mm)  
H 2 : 461 (mm)  
OD 1 : 273 (mm)  
OD 2 : 273 (mm)  
ID 1 : 190 (mm)  
ID 2 : 22 (mm)

CONT : 4  
VOL : 0.181

54

**A-13560** Air Filter Metal End Cap Element

HINO 17801-2200



H 1 : 326.7 (mm)  
H 2 : 314 (mm)  
OD 1 : 216 (mm)  
OD 2 : 216 (mm)  
ID 1 : 137 (mm)  
ID 2 : 23 (mm)


CONT : 4  
VOL : 0.078

Note : Flame Retardant version of A-1306

59

**A-1340** Air Filter Metal End Cap Element

HINO 17801-3280A




H 1 : 356.7 (mm)  
H 2 : 344 (mm)  
OD 1 : 185 (mm)  
OD 2 : 185 (mm)  
ID 1 : 157.5 (mm)  
ID 2 : 17 (mm)

CONT : 1  
VOL : 0.015

50

**A-13500** Air Filter Secondary Metal End Cap Element

HINO 17801-3160P



H 1 : 435.75 (mm)  
H 2 : 423 (mm)  
OD 1 : 187.5 (mm)  
OD 2 : 187.5 (mm)  
ID 1 : 157 (mm)  
ID 2 : 22 (mm)

CONT : 4  
VOL : 0.085

55

**A-13570** Air Filter Soft PU end cap Element

HINO 17801-78110



H 1 : 216 (mm)  
H 2 : 203 (mm)  
OD 1 : 237 (mm)  
OD 2 : 237 (mm)  
ID 1 : 132 (mm)

CONT : 4  
VOL : 0.064

Note : Hino 300 series Euro 4

60

# Sakura Filter

# Technical Specification

**A-13580** Air Filter Primary Soft PU end cap Element

HINO 17801-EW030  
HINO 17801-JAA30



Secondary Filter uses A-13590  
Set Filter uses A-13580-S  
H 1 : 363 (mm)  
OD 1 : 281.6 (mm)  
OD 2 : 281.6 (mm)  
ID 1 : 148 (mm)

CONT : 1  
VOL : 0.040

**A-13630** Air Filter Secondary Soft PU end cap Element

HINO 17801-E0140  
HINO 17801-JAB40



Primary Filter uses A-13620  
Set Filter uses A-13620-S  
H 1 : 400 (mm)  
OD 1 : 180.5 (mm)  
OD 2 : 180.5 (mm)  
ID 1 : 138.8 (mm)

CONT : 1  
VOL : 0.016

**A-5618** Air Filter Primary Metal End Cap Element

NISSAN 16546-97004  
HINO 17801-2550  
HITACHI 4177213




Secondary Filter uses A-5610  
Set Filter uses A-5658-S  
H 1 : 469.7 (mm)  
H 2 : 457 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 17 (mm)

CONT : 1  
VOL : 0.055

**A-13580-S** Air Filter Set Soft PU end cap Element

HINO 17801-EW030+17801-EW040  
HINO 17801-JAA30+17801-JAA40



Primary Filter uses A-13580  
Secondary Filter uses A-13590  
H 1 : 363 (mm)  
OD 1 : 281.6 (mm)  
OD 2 : 281.6 (mm)  
ID 1 : 148 (mm)

CONT : 1  
VOL : 0.034

**A-1828** Air Filter Primary Metal End Cap Element

ISUZU 1-14215058-0  
NISSAN 16546-96064  
HINO 17801-2150




Secondary Filter uses A-7967  
Set Filter uses A-1840-S  
H 1 : 520.7 (mm)  
H 2 : 508 (mm)  
OD 1 : 275.8 (mm)  
OD 2 : 271 (mm)  
ID 1 : 165 (mm)  
ID 2 : 22.7 (mm)

CONT : 1  
VOL : 0.050

**A-5631** Air Filter Secondary Metal End Cap Element

ISUZU 1-14215087-0  
NISSAN 16546-96072  
HITACHI 4288964




Primary Filter uses A-1013  
Set Filter uses A-1841-S  
H 1 : 361.75 (mm)  
H 2 : 349 (mm)  
OD 1 : 162.5 (mm)  
OD 2 : 163 (mm)  
ID 1 : 134 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.110

**A-13590** Air Filter Secondary Metal End Cap Element

HINO 17801-EW040  
HINO 17801-JAA40




Primary Filter uses A-13580  
Set Filter uses A-13580-S  
H 1 : 356 (mm)  
OD 1 : 151 (mm)  
OD 2 : 151 (mm)  
ID 1 : 109.6 (mm)

CONT : 9  
VOL : 0.099

**A-5020** Air Filter Primary Soft PU end cap Element

GENERAL MOTORS 15619013  
HINO 17801-3430A  
FORD F3HZ-9601A  
FORD F3HZ-9601B



Secondary Filter uses A-5021  
Set Filter uses A-5022-S  
H 1 : 325 (mm)  
H 2 : 312 (mm)  
OD 1 : 237 (mm)  
OD 2 : 237 (mm)  
ID 1 : 132 (mm)

CONT : 1  
VOL : 0.023

**A-5653-S** Air Filter Set Metal End Cap Element

NISSAN 16546-96125  
NISSAN 16546-99226  
KOMATSU 600-181-3800




Primary Filter uses A-6113  
Secondary Filter uses A-5408  
H 1 : 418.7 (mm)  
H 2 : 406 (mm)  
OD 1 : 282 (mm)  
OD 2 : 282 (mm)  
ID 1 : 171 (mm)  
ID 2 : 17 (mm)

CONT : 1  
VOL : 0.042

**A-13620** Air Filter Primary Soft PU end cap Element

HINO 17801-E0130  
HINO 17801-JAB30




Secondary Filter uses A-13630  
Set Filter uses A-13620-S  
H 1 : 405 (mm)  
OD 1 : 313.4 (mm)  
OD 2 : 313.4 (mm)  
ID 1 : 177.6 (mm)

CONT : 1  
VOL : 0.046

**A-5408** Air Filter Secondary Metal End Cap Element

ISUZU 1-14215034-0  
ISUZU 1-14215036-0  
NISSAN 16546-96014




Primary Filter uses A-6113  
Set Filter uses A-5653-S  
H 1 : 406 (mm)  
OD 1 : 192.3 (mm)  
OD 2 : 162.5 (mm)  
ID 1 : 134.2 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.167

Note : Is a Secondary Air filter for A-6113,A-54490

**A-6006** Air Filter Primary Metal End Cap Element

ISUZU 1-14214108-0  
ISUZU 1-14214153-0  
ISUZU 1-14215060-0  
NISSAN 16546-Z9010  
TOYOTA 17801-2560




Secondary Filter uses A-6007  
Set Filter uses A-6118-S  
H 1 : 342.7 (mm)  
H 2 : 330 (mm)  
OD 1 : 232 (mm)  
OD 2 : 232 (mm)  
ID 1 : 147 (mm)  
ID 2 : 23 (mm)

CONT : 4  
VOL : 0.093

Note : For Flame Retardant version use A-60400

**A-13620-S** Air Filter Set Soft PU end cap Element

HINO 17801-E0130+17801-E0140  
HINO 17801-JAB30+17801-JAB40



Primary Filter uses A-13620  
Secondary Filter uses A-13630  
H 1 : 405 (mm)  
H 2 : 400 (mm)  
OD 1 : 313.4 (mm)  
OD 2 : 180.5 (mm)  
ID 1 : 177.6 (mm)  
ID 2 : 138.8 (mm)

CONT : 1  
VOL : 0.046

**A-5425** Air Filter Primary Metal End Cap Element

HINO 17801-2020  
HINO 17801-2270  
HINO 17801-2290




Secondary Filter uses A-5417  
Set Filter uses A-5425-S  
H 1 : 418.7 (mm)  
H 2 : 406 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 22.7 (mm)

CONT : 1  
VOL : 0.050

**A-6007** Air Filter Secondary Metal End Cap Element

ISUZU 1-14215061-0  
ISUZU 1-14215078-0  
ISUZU 1-14215078-1



Primary Filter uses A-6006  
Set Filter uses A-6118-S  
H 1 : 317.7 (mm)  
H 2 : 305 (mm)  
OD 1 : 145 (mm)  
OD 2 : 145 (mm)  
ID 1 : 116.5 (mm)  
ID 2 : 23 (mm)

CONT : 9  
VOL : 0.078

Note : ID=17 MM uses A-6031

# Sakura Filter

# Technical Specification

**A-6010** Air Filter Primary Metal End Cap Element



ISUZU 1-14215116-0  
ISUZU 1-14215117-0  
ISUZU 1-14215128-0

Secondary Filter uses A-6011  
Set Filter uses A-6010-S

H 1 : 495.7 (mm)  
H 2 : 483 (mm)  
OD 1 : 307 (mm)  
OD 2 : 307 (mm)  
ID 1 : 196 (mm)  
ID 2 : 23 (mm)

CONT : 1  
VOL : 0.058

**AS-1301** Air Filter Metal End Cap Element With Sleeve



HINO 17801-1010

H 1 : 251 (mm)  
H 2 : 240 (mm)  
OD 1 : 257 (mm)  
OD 2 : 201 (mm)  
ID 1 : 97 (mm)  
ID 2 : 14 (mm)

CONT : 1  
VOL : 0.019

**AS-1316** Air Filter Metal End Cap Element With Sleeve



HINO 17801-1721

H 1 : 301 (mm)  
H 2 : 290 (mm)  
OD 1 : 257 (mm)  
OD 2 : 201.6 (mm)  
ID 1 : 97 (mm)  
ID 2 : 13.7 (mm)

CONT : 12  
VOL : 0.197

**A-6011** Air Filter Secondary Metal End Cap Element



ISUZU 1-14215118-0  
ISUZU 1-14215127-0  
ISUZU 14215-127

Primary Filter uses A-6010  
Set Filter uses A-6010-S

H 1 : 469.7 (mm)  
H 2 : 457 (mm)  
OD 1 : 185 (mm)  
OD 2 : 185 (mm)  
ID 1 : 157.5 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.190

**AS-1302** Air Filter Metal End Cap Element With Sleeve




HINO 17801-1560  
HINO 6072-2214-00

H 1 : 193.7 (mm)  
H 2 : 181 (mm)  
OD 1 : 336.5 (mm)  
OD 2 : 282 (mm)  
ID 1 : 171 (mm)  
ID 2 : 12 (mm)

CONT : 1  
VOL : 0.028

**AS-5709** Air Filter Metal End Cap Element With Sleeve



ISUZU 1-14215-044-0  
ISUZU 1-14215-044-1  
ISUZU 1-14215-062-1  
ISUZU 1-14215041-0  
HINO 17801-1150

H 1 : 266.75 (mm)  
H 2 : 254 (mm)  
OD 1 : 296 (mm)  
OD 2 : 234 (mm)  
ID 1 : 123 (mm)  
ID 2 : 14 (mm)

CONT : 1  
VOL : 0.027

Note : Sleeve on E/C "A" type uses AS-5708

**A-60400** Air Filter Primary Metal End Cap Element



ISUZU 1-14215108-1  
HINO 17801-2280  
HITACHI 4147010

H 1 : 342.7 (mm)  
H 2 : 330 (mm)  
OD 1 : 232 (mm)  
OD 2 : 232 (mm)  
ID 1 : 147 (mm)  
ID 2 : 23 (mm)

CONT : 4  
VOL : 0.094

Note : Flame Retardant version of A-6006

**AS-1303** Air Filter Metal End Cap Element With Sleeve



HINO 17801-1580  
HINO 17801-1720  
HINO 17801-1720(BL)

H 1 : 301 (mm)  
H 2 : 290 (mm)  
OD 1 : 245 (mm)  
OD 2 : 201 (mm)  
ID 1 : 97 (mm)  
ID 2 : 14 (mm)

CONT : 1  
VOL : 0.021

**C-1011** Oil Filter Full Flow Spin-On



NISSAN 15208-HC400  
HINO 15607-1920  
MAZDA JEYO-14-302

H 1 : 85 (mm)  
OD 1 : 68 (mm)  
Thread Size : M20X1.5-6H  
BPV (kg/cm<sup>2</sup>) : 1.0  
ADBV : YES  
Gasket Type : Round

CONT : 50  
VOL : 0.026

Note : Square version uses C-1030

**A-6113** Air Filter Primary Metal End Cap Element




FIAT 01901779  
ISUZU 1-14215046-0  
NISSAN 16546-96017

Secondary Filter uses A-5408  
Set Filter uses A-5653-S

H 1 : 418.7 (mm)  
H 2 : 406 (mm)  
OD 1 : 282 (mm)  
OD 2 : 282 (mm)  
ID 1 : 171 (mm)  
ID 2 : 17 (mm)

CONT : 1  
VOL : 0.038

**AS-13031** Air Filter Metal End Cap Element With Sleeve



HINO 17801-1080

H 1 : 297.5 (mm)  
H 2 : 285 (mm)  
OD 1 : 245 (mm)  
OD 2 : 201.6 (mm)  
ID 1 : 116 (mm)  
ID 2 : 13.5 (mm)

CONT : 1  
VOL : 0.022

Note : AS-1303(difference in height)

**C-1011XPL** Oil Filter Full Flow Spin-On High Efficiency



ISUZU 8-93156750-0  
MAZDA FEY0-14-302  
MITSUBISHI MD 135735  
MITSUBISHI MD 135737

H 1 : 85 (mm)  
OD 1 : 68 (mm)  
Thread Size : M20X1.5-6H  
BPV (kg/cm<sup>2</sup>) : 1.0  
ADBV : YES  
Gasket Type : Round

CONT : 50  
VOL : 0.026

**AS-1201** Air Filter Metal End Cap Element With Sleeve



DAIHATSU 17801-87303  
DAIHATSU 17801-87303-000  
DAIHATSU 17801-87304

H 1 : 206 (mm)  
H 2 : 197 (mm)  
OD 1 : 200 (mm)  
OD 2 : 155 (mm)  
ID 1 : 88 (mm)  
ID 2 : 13 (mm)

CONT : 18  
VOL : 0.190

**AS-1304** Air Filter Metal End Cap Element With Sleeve



ISUZU 1-14215009-0  
ISUZU 1-14215043-0  
ISUZU 1-14215043-1

H 1 : 317.75 (mm)  
H 2 : 305 (mm)  
OD 1 : 352 (mm)  
OD 2 : 280 (mm)  
ID 1 : 170 (mm)  
ID 2 : 12 (mm)

CONT : 1  
VOL : 0.046

Note : without fins version uses A-1304

**C-1112** Oil Filter Combination Spin-On



TOYOTA 90915-03006  
TOYOTA 90915-30002  
HINO 9091F-30002

H 1 : 120 (mm)  
OD 1 : 100 (mm)  
Thread Size : M24X1.5-6H  
BPV (kg/cm<sup>2</sup>) : 1.0  
ADBV : YES  
Gasket Type : Round

CONT : 25  
VOL : 0.042

# Sakura Filter

# Technical Specification

**C-1208** Oil Filter Full Flow Spin-On

DAIHATSU 15601-87305-000  
HINO 1560B-87305




H 1 : 125 (mm)  
OD 1 : 90 (mm)  
Thread Size : M20X1.5-6H  
BPV (kg/cm<sup>2</sup>) : 1.0  
Gasket Type : Round

CONT : 25  
VOL : 0.035

91

**C-1305** Oil Filter Full Flow Spin-On

ISUZU 1-13240046-1  
ISUZU 1-13240061-0  
ISUZU 1-13240075-0



H 1 : 199 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-12 UNF-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.036

Note : Without Nut

96

**C-1312** Oil Filter Full Flow Spin-On

ISUZU 1-13200768-1  
ISUZU 1-13240105-0  
HINO 15607-1420



H 1 : 248 (mm)  
OD 1 : 121 (mm)  
Thread Size : 1 3/8-16 UNF-2B  
Gasket Type : Square


CONT : 6  
VOL : 0.031

Note : With Drain Nut

101

**C-1301** Oil Filter Full Flow Spin-On

HINO 15601-89102  
HINO 15607-1590  
HINO 15607-1670



H 1 : 162 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-12 UNF-2B


CONT : 20  
VOL : 0.055

Note : Without Drain Nut

92

**C-1306** Oil Filter By Pass Spin-On

ISUZU 1-13240067-0  
ISUZU 1-13240209-0  
HINO 15607-1440



H 1 : 249 (mm)  
OD 1 : 120 (mm)  
Thread Size : 1 3/8-16 UNF-2B  
Gasket Type : Square

CONT : 6  
VOL : 0.029

Note : Without Drain Nut

97

**C-1313** Oil Filter Full Flow Spin-On

HINO 15607-1640




H 1 : 125 (mm)  
OD 1 : 102 (mm)  
Thread Size : M16X1.5-6H  
Gasket Type : Round

CONT : 20  
VOL : 0.037

102

**C-1302** Oil Filter Full Flow Spin-On

HINO 15607-1330  
HINO 15607-1331  
HINO 15607-1480




H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : M26X1.5-6H  
BPV (kg/cm<sup>2</sup>) : 1.0  
Gasket Type : Round

CONT : 12  
VOL : 0.027

93

**C-1308** Oil Filter Full Flow Spin-On

HINO 15607-1630




H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-16 UNF-2B  
BPV (kg/cm<sup>2</sup>) : 1.0  
Gasket Type : Round

CONT : 25  
VOL : 0.054

98

**C-1314** Oil Filter Full Flow Spin-On

HINO 15607-2050  
HINO 15607-2051




H 1 : 199 (mm)  
OD 1 : 118 (mm)  
Thread Size : 1 1/2-16 UN-2B

CONT : 6  
VOL : 0.024

103

**C-1303** Oil Filter Combination Spin-On

HINO 15607-1600  
HINO 15607-1830



H 1 : 199 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-16 UN-2B


CONT : 6  
VOL : 0.018

Note : single element version uses C-1325

94

**C-1309** Oil Filter Full Flow Spin-On

HINO 15607-1671  
HINO 15607-1780



H 1 : 162 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-12 UNF-2B  
Thread Nut Size : M8X1.25  
Gasket Type : Square

CONT : 12  
VOL : 0.033

Note : Drain Nut

99

**C-1315** Oil Filter Combination Spin-On

HINO 15607-2070  
HINO 15607-2071  
HINO 15607-2073



H 1 : 210 (mm)  
OD 1 : 120 (mm)  
Thread Size : 1 1/2-12 UNF-2B  
BPV (kg/cm<sup>2</sup>) : 1.0  
Gasket Type : Square


CONT : 6  
VOL : 0.027

Note : Upgrade With High Gasket Seal

104

**C-1304** Oil Filter Combination Spin-On

HINO 15607-1731  
HINO 15607-1732  
HINO 15607-1733



H 1 : 199 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-16 UN-2B  
Thread Nut Size : M8X1.25

CONT : 10  
VOL : 0.033

Note : Drain nut

95

**C-1310** Oil Filter By Pass Spin-On

HINO 15607-1890



H 1 : 151.6 (mm)  
OD 1 : 102 (mm)  
Thread Size : 5/8-18 UNF-2B  
Gasket Type : Round

CONT : 12  
VOL : 0.031

100

**C-1316** Oil Filter Combination Spin-On

NISSAN 15209-Z5001  
HINO 15607-2190  
TOYOTA S1560-72190



H 1 : 210 (mm)  
OD 1 : 120 (mm)  
Thread Size : 1 1/2-16 UN-2B  
Thread Nut Size : M8X1.25  
Gasket Type : Square

CONT : 10  
VOL : 0.042

Note : Upgrade With Gasket Seal

105

# Sakura Filter

# Technical Specification

**C-1317** Oil Filter Combination Spin-On

HINO 15607-1221  
HINO 15607-2210  
HINO 15613-89105




H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-16 UNF-2B  
BPV (kg/cm2) : 1.0  
Gasket Type : Square

CONT : 12  
VOL : 0.026

106

**C-1328** Oil Filter Full Flow Spin-On With Nut

HINO 15613-E0080  
HINO S1560-72320  
HINO S1560-72390




H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-12 UNF-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.028

111

**CA-13010** Cabin Air Filter Paper framed Element

SUBARU 72880AE020  
HINO S8722-01010




H 1 : 17 (mm)  
Length 1 : 202.5 (mm)  
Width 1 : 199.5 (mm)

CONT : 20  
VOL : 0.031

116

**C-1318** Oil Filter Full Flow Spin-On

HINO 15607-2250  
HINO 15607-2320  
HINO 15607-2390



H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-12 UNF-2B  
ADBV : YES  
Gasket Type : Square

CONT : 12  
VOL : 0.026

Note : Without Nut

107

**C-13320** Oil Filter Full Flow Spin-On

HINO 15607-2060L



H 1 : 85 (mm)  
OD 1 : 68 (mm)  
Thread Size : M20X1.5-6H  
Gasket Type : Round

CONT : 40  
VOL : 0.023

Note : for 078 FM2P

112

**EF-1112** Fuel Filter Eco Element High Efficiency

HINO 23390-78220  
TOYOTA 23390-78220  
HINO 23390-78221  
TOYOTA 23390-78221

H 1 : 91.1 (mm)  
H 2 : 69 (mm)  
OD 1 : 84 (mm)  
OD 2 : 78 (mm)  
ID 1 : 20.5 (mm)  
ID 2 : 12 (mm)


CONT : 12  
VOL : 0.011

Note : to upgrade use EF-11110

117

**C-1319** Oil Filter Combination Spin-On With Nut

NISSAN 15209-Z5002  
NISSAN 15209-Z5003  
NISSAN 15209-Z500C  
HINO 15607-2200  
ISUZU 5-86506950-0




H 1 : 150 (mm)  
OD 1 : 120 (mm)  
Thread Size : 1 1/2-16 UN-2B  
ADBV : YES  
Gasket Type : Square

CONT : 6  
VOL : 0.020

108

**C-1809** Oil Filter Full Flow Spin-On

NISSAN 15208-AA080  
NISSAN 15208-HC010  
NISSAN 15208-HC430



H 1 : 65 (mm)  
OD 1 : 68 (mm)  
Thread Size : M20X1.5-6H  
BPV (kg/cm2) : 1.0  
ADBV : YES  
Gasket Type : Round

CONT : 50  
VOL : 0.021

113

**EF-1301** Fuel Filter Main Eco Element High Efficiency

HINO 23401-1690  
HINO S23401-1690


H 1 : 136.5 (mm)  
H 2 : 130.5 (mm)  
OD 1 : 91 (mm)  
OD 2 : 91 (mm)  
ID 1 : 19 (mm)  
ID 2 : 19 (mm)

CONT : 12  
VOL : 0.019

118

**C-1320** Oil Filter Combination Spin-On

HINO 15607-2210



H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-16 UNF-2B  
Gasket Type : Square


CONT : 12  
VOL : 0.026

Note : With by pass valve version used C-1317

109

**C-5718** Oil Filter By Pass Spin-On

ISUZU 1-87310093-0  
CATERPILLAR 1W-8845  
J.C.BAMFORD 32/919502  
HITACHI 4285964



H 1 : 246 (mm)  
OD 1 : 115.5 (mm)  
Thread Size : 1 3/8-16 UNF-2B

CONT : 6  
VOL : 0.029

114

**EF-13020** Fuel Filter Eco Element High Efficiency

HINO 23304-EV041

H 1 : 71 (mm)  
H 2 : 65 (mm)  
OD 1 : 80.5 (mm)  
OD 2 : 80.5 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)


CONT : 50  
VOL : 0.032

Note : media 7 micron

119

**C-1321** Oil Filter Combination Spin-On

HINO 15607-2120  
HINO 15607-2121  
HINO 15607-2180




H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-12 UNF-2B  
Gasket Type : Square

CONT : 15  
VOL : 0.033

110

**C-60030** Oil Filter By Pass Spin-On

ISUZU 1-13240089-0  
ISUZU 1-13240089-2  
ISUZU 2-90654820-0



H 1 : 143 (mm)  
OD 1 : 108 (mm)  
Thread Size : 5/8-18 UNF-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.020

115

**EF-13021** Fuel Filter Eco Element High Efficiency

HINO 23304-EV360

H 1 : 71 (mm)  
H 2 : 65 (mm)  
OD 1 : 80.5 (mm)  
OD 2 : 80.5 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 50  
VOL : 0.032

Note : media 2 micron

120




**EF-1306** Fuel Filter Eco Element High Efficiency  
HINO 23401-1681

H 1 : 116 (mm)  
H 2 : 110 (mm)  
OD 1 : 80 (mm)  
OD 2 : 80 (mm)  
ID 1 : 19 (mm)  
ID 2 : 19 (mm)

CONT : 50  
VOL : 0.051

121

**EF-1509** Fuel Filter Eco Element High Efficiency  
ISUZU 8-98037011-0



H 1 : 115 (mm)  
H 2 : 96 (mm)  
OD 1 : 100 (mm)  
OD 2 : 90 (mm)  
ID 1 : 11.75 (mm)

CONT : 50  
VOL : 0.083

Note : Media 4 micron

126


**EO-1302** Oil Filter Full Flow Eco Element  
HINO 15607-LCD70  
HINO S1560-72370

H 1 : 186.5 (mm)  
H 2 : 178.5 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 47.5 (mm)

CONT : 50  
VOL : 0.136

131

**EF-13070** Fuel Filter Eco Element with adhesive  
HINO 23304-78090  
HINO 23304-78091  
SF-FILTER AG SK 48605



H 1 : 146 (mm)  
H 2 : 112 (mm)  
OD 1 : 84 (mm)  
OD 2 : 78 (mm)  
ID 1 : 12 (mm)

CONT : 50  
VOL : 0.068

Note : for Hino 300 series Euro 5

122

**EF-1802** Fuel Filter Eco Element High Efficiency  
NISSAN 16444-Z500C  
HINO S23401-1682

H 1 : 116 (mm)  
H 2 : 110 (mm)  
OD 1 : 90 (mm)  
OD 2 : 90 (mm)  
ID 1 : 19 (mm)  
ID 2 : 19 (mm)

CONT : 25  
VOL : 0.033

Note : 7 micron

127


**EO-1303** Oil Filter By Pass Eco Element  
HINO 15607-LCD80  
HINO S1560-72380

H 1 : 225.5 (mm)  
H 2 : 197.5 (mm)  
OD 1 : 139.5 (mm)  
OD 2 : 139.5 (mm)  
ID 1 : 16.8 (mm)  
ID 2 : 16.8 (mm)

CONT : 12  
VOL : 0.072

132

**EF-13090** Fuel Filter Eco Element  
HINO 23304-EV310  
HINO 23304-EV350  
ISUZU 5-86543-509-0  
ISUZU 8-98341-540-0



H 1 : 136 (mm)  
H 2 : 130.5 (mm)  
OD 1 : 91 (mm)  
OD 2 : 91 (mm)  
ID 1 : 19 (mm)

CONT : 50  
VOL : 0.073

123


**EFG-1001** Blow-by Gas Filter Eco Element  
NISSAN 11811-NY025  
ISUZU 8-97385919-0  
MITSUBISHI ME 354459  
HINO S1222-EV040

H 1 : 101 (mm)  
H 2 : 97 (mm)  
OD 1 : 71 (mm)  
OD 2 : 71 (mm)  
ID 1 : 26 (mm)  
ID 2 : 26 (mm)

CONT : 50  
VOL : 0.033

128

**EO-13040** Oil Filter By Pass Eco Element  
HINO 15601-E0070  
HINO S1560-72360



H 1 : 225.5 (mm)  
H 2 : 197.5 (mm)  
OD 1 : 139.5 (mm)  
OD 2 : 139.5 (mm)  
ID 1 : 16.8 (mm)  
ID 2 : 16.8 (mm)

CONT : 16  
VOL : 0.090

133

**EF-13100** Fuel Filter Eco Element High Efficiency  
HINO 23304-EV330  
HINO 23304-EV370  
ISUZU 5-86543-510-0

H 1 : 116 (mm)  
H 2 : 110 (mm)  
OD 1 : 90 (mm)  
OD 2 : 90 (mm)  
ID 1 : 19 (mm)  
ID 2 : 19 (mm)

CONT : 50  
VOL : 0.064

Note : 2 micron

124

**EFG-1002** Blow-by Gas Filter Eco Element  
ISUZU 8-97606318-0  
MITSUBISHI ME 302763

H 1 : 75.5 (mm)  
H 2 : 72.5 (mm)  
OD 1 : 71 (mm)  
OD 2 : 71 (mm)  
ID 1 : 26 (mm)  
ID 2 : 26 (mm)

CONT : 50  
VOL : 0.030

129

**EO-13050** Oil Filter Full Flow Eco Element  
HINO S1560-72340  
NISSAN S1560-72340  
KOBELCO VHS156072340


H 1 : 186.5 (mm)  
H 2 : 178.5 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 47.5 (mm)

CONT : 16  
VOL : 0.045

Note : EO-1302 (packing set difference)

134

**EF-13110** Fuel Filter Eco Element  
HINO 23304-EV290  
HINO 23304-EV290P



H 1 : 79.8 (mm)  
H 2 : 75.7 (mm)  
OD 1 : 79.5 (mm)  
OD 2 : 79.5 (mm)  
ID 1 : 17 (mm)

CONT : 50  
VOL : 0.036

Note : Hino 500 Victor Engine : J08E-WJ / J08E-WH

125


**EO-13010-S** Oil Filter Combination Eco Element  
HINO S1560-72370+S1560-72380

H 1 : 225.5 (mm)  
H 2 : 186.5 (mm)  
OD 1 : 104 (mm)  
OD 2 : 139.5 (mm)  
ID 1 : 15 (mm)  
ID 2 : 16.8 (mm)

CONT : 8  
VOL : 0.079

130

**EO-13060** Oil Filter Full Flow Eco Element  
HINO 15601-EV030



H 1 : 167 (mm)  
H 2 : 165 (mm)  
OD 1 : 90 (mm)  
OD 2 : 90 (mm)  
ID 1 : 32 (mm)


CONT : 25  
VOL : 0.050

Note : HINO RB145 BUS, MITSUBISHI FUSO KK-FG72E

135

**F-1110** Fuel Filter Plastic Element

TOYOTA 23304-78110  
HINO 23401-7811L



H 1 : 110.5 (mm)  
H 2 : 103 (mm)  
OD 1 : 104.5 (mm)  
OD 2 : 92.5 (mm)  
ID 1 : 29 (mm)  
ID 2 : 29 (mm)

CONT : 25  
VOL : 0.041

136

**F-1306** Fuel Filter Metal End Cap Element High Efficiency

HINO 23355-78020



H 1 : 99 (mm)  
H 2 : 94.5 (mm)  
OD 1 : 95 (mm)  
OD 2 : 95 (mm)  
ID 1 : 27.3 (mm)


CONT : 50  
VOL : 0.061

Note : Euro 3 engine N04C,J05E

141

**FC-1103** Fuel Filter Spin-On

TOYOTA 23303-56022  
TOYOTA 23303-56031  
DAIHATSU 23303-56031-000




H 1 : 87 (mm)  
OD 1 : 80 (mm)  
Thread Size : 3/4-16 UNF-2B  
Gasket Type : Round

CONT : 50  
VOL : 0.039

146

**F-1301** Fuel Filter Metal End Cap Element

TOYOTA 04234-76005-71  
HINO 23401-1060  
HINO 23401-1061




H 1 : 64.6 (mm)  
H 2 : 60 (mm)  
OD 1 : 62 (mm)  
OD 2 : 62 (mm)  
ID 1 : 11 (mm)  
ID 2 : 11 (mm)

CONT : 75  
VOL : 0.030

137

**F-13080** Fuel Filter Metal End Cap Element

HINO 15924-0004




H 1 : 242.2 (mm)  
H 2 : 237.8 (mm)  
OD 1 : 95 (mm)  
OD 2 : 95 (mm)  
ID 1 : 27.3 (mm)

CONT : 25  
VOL : 0.070

142

**FC-1107** Fuel Filter Spin-On

TOYOTA 23300-78020  
TOYOTA 23303-78020  
TOYOTA 23304-78020




H 1 : 100 (mm)  
OD 1 : 80 (mm)  
Thread Size : M20X1.5-6H  
Gasket Type : Round

CONT : 50  
VOL : 0.043

147

**F-1302** Fuel Filter Metal End Cap Element

HINO 23401-1040  
HINO 23401-1050  
HINO 6052-2008-00



H 1 : 102 (mm)  
H 2 : 100 (mm)  
OD 1 : 71 (mm)  
OD 2 : 71 (mm)  
ID 1 : 15 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.035

138

**F-13090** Fuel Filter Plastic Element High Efficiency

HINO 23300-E0531



H 1 : 65 (mm)  
OD 1 : 79 (mm)  
OD 2 : 79 (mm)  
ID 1 : 17 (mm)

CONT : 12  
VOL : 0.010

143

**FC-1203** Fuel Filter Spin-On

MAZDA 1456-13-850A  
MAZDA 1456-23-570  
MAZDA 1456-23-570A  
DAIHATSU 23303-87308-000  
ISUZU 8-94369299-3



H 1 : 140 (mm)  
OD 1 : 95 (mm)  
Thread Size : M20X1.5-6H  
Thread Nut Size : M36X1.5-6H  
Gasket Type : Round


CONT : 25  
VOL : 0.043

Note : not for common rail engine

148

**F-1303** Fuel Filter Metal End Cap Element

ISUZU 13240-029  
NISSAN 16403-90026  
NISSAN 16444-90000  
HINO 23401-1030




H 1 : 105 (mm)  
OD 1 : 74 (mm)  
OD 2 : 74 (mm)  
ID 1 : 16 (mm)  
ID 2 : 16 (mm)

CONT : 50  
VOL : 0.040

139

**F-1507** Fuel Filter Metal End Cap Element

ISUZU 1-13240194-0  
MITSUBISHI ME300361  
HINO S23401-1740 L



H 1 : 99 (mm)  
H 2 : 94.5 (mm)  
OD 1 : 95 (mm)  
OD 2 : 95 (mm)  
ID 1 : 27.3 (mm)


CONT : 50  
VOL : 0.058

Note : High performance grade uses F-1306

144

**FC-1301** Fuel Filter Spin-On

HINO 23401-1330  
HINO 23401-1331  
HINO 23401-1332



H 1 : 100 (mm)  
OD 1 : 80 (mm)  
Thread Size : 3/4-16 UNF-2B  
Gasket Type : Round

CONT : 50  
VOL : 0.043

149

**F-1304** Fuel Filter Metal End Cap Element

HINO 23401-1020  
HINO 23401-1021  
HINO 23401-1080




H 1 : 109 (mm)  
H 2 : 104 (mm)  
OD 1 : 103 (mm)  
OD 2 : 104 (mm)  
ID 1 : 49 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.080

140

**F-1803** Fuel Filter Metal End Cap Element

NISSAN 16444-90027  
NISSAN 16444-99127  
NISSAN 16444-99128




H 1 : 141 (mm)  
H 2 : 134 (mm)  
OD 1 : 91.5 (mm)  
OD 2 : 91.5 (mm)  
ID 1 : 14.5 (mm)  
ID 2 : 14.5 (mm)

CONT : 50  
VOL : 0.073

145

**FC-1302** Fuel Filter Spin-On

TCM 20801-02112



H 1 : 75 (mm)  
OD 1 : 80 (mm)  
Thread Size : M20X1.5-6H  
Gasket Type : Round

CONT : 50  
VOL : 0.034

150



**FC-1303** Fuel Filter Spin-On



HINO 23401-1190  
HINO 23401-1371  
HINO 23401-1400

H 1 : 125 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Round

CONT : 12  
VOL : 0.022

Note : Seat Zinc Coating

151

**FC-13190** Fuel Filter Spin-On



HINO 23304-EV021

H 1 : 80 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Round

CONT : 24  
VOL : 0.029

156

**FC-55240** Fuel Filter Spin-On High Efficiency



DONGFENG D638-002-802A  
SDE ENGINE D638-002-802A  
YUCHAI G5800-1105140  
WEICHAI VG1540080110

H 1 : 210 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 12  
VOL : 0.042

161

**FC-1305** Fuel Filter Spin-On High Efficiency



HINO 23401-1221  
HINO 23401-1640  
HINO S2340-11222  
HINO S2340-11640

H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Round

CONT : 25  
VOL : 0.054

152

**FC-13200** Fuel Filter Spin-On



HINO 23310-EV250  
HINO 23310-JAC50

H 1 : 199 (mm)  
OD 1 : 110 (mm)  
Thread Size : 1 1/2-12 UNF-2B

CONT : 12  
VOL : 0.042

157

**FC-5701** Fuel Filter Spin-On




HINO 23401-1281

H 1 : 174 (mm)  
OD 1 : 93 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.030

162

**FC-1310** Fuel Filter Primary Spin-On



HINO 23401-1284  
HINO 23401-1580


H 1 : 150 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Round

CONT : 25  
VOL : 0.054

Note : FC-1305 (Media difference)

153

**FC-13210** Fuel Filter Spin-On With Nut



TOYOTA 23304-78420  
HINO 23304-EV021  
HINO 23304-EV280

H 1 : 89.6 (mm)  
H 2 : 80 (mm)  
OD 1 : 91.5 (mm)  
Top Thread Size : 1-14 UNS-2B

CONT : 12  
VOL : 0.015

158

**H-1301** Hydraulic Oil Filter Metal End Cap Element



HINO 44308-1210

H 1 : 91.6 (mm)  
H 2 : 90 (mm)  
OD 1 : 64.6 (mm)  
OD 2 : 64.6 (mm)  
ID 1 : 36.4 (mm)

CONT : 25  
VOL : 0.015

163

**FC-1311** Fuel Filter Spin-On High Efficiency




HINO 23401-1650

H 1 : 125 (mm)  
OD 1 : 102 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Round

CONT : 12  
VOL : 0.023

154

**FC-1810** Fuel Filter Spin-On with head body



NISSAN 16403-99013  
NISSAN 16403-NY001

H 1 : 145 (mm)  
OD 1 : 93 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.024

159

**K-13210** Filter Kit Combination Metal End Cap Element



HINO 15607-2150+15607-1560

CONT : 6  
VOL : 0.035

Note : O-1321+O-1308

164

**FC-1312** Fuel Filter Spin-On




HINO 23401-1402

H 1 : 136 (mm)  
OD 1 : 93 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.022

155

**FC-2701** Fuel Filter Spin-On High Efficiency




ISUZU 1-13240068-0  
ISUZU 1-13240069-1  
ISUZU 1-13240079-1  
HITACHI 4206080

H 1 : 125 (mm)  
OD 1 : 90 (mm)  
Thread Size : 3/4-16 UNF-2B  
Gasket Type : Round

CONT : 25  
VOL : 0.035

160

**K-13220** Filter Kit Element



HINO S1560-72360+S1560-72340

CONT : 12  
VOL : 0.114

Note : EO-13040+EO-13050

165

**K-13260** Filter Kit

HINO  
S1560-72390+23390-78220+23304-7  
8090+23304-EV021




CONT : 1  
VOL : 0.000

Note : C-1328+EF-1112+EF-13070+FC-13190

166

**O-1304** Oil Filter Full Flow Metal End Cap Element

HINO 04015-6013  
TOYOTA 04152-66010  
HINO 15607-1120




H 1 : 136 (mm)  
H 2 : 129 (mm)  
OD 1 : 85 (mm)  
OD 2 : 85 (mm)  
ID 1 : 15 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.063

171

**O-1310** Oil Filter By Pass Metal End Cap Element

HINO 15607-1350  
HINO 15607-1351  
HINO 15607-1530




H 1 : 218 (mm)  
OD 1 : 122 (mm)  
OD 2 : 122 (mm)  
ID 1 : 17.5 (mm)  
ID 2 : 17.5 (mm)

CONT : 16  
VOL : 0.074

176

**K-13270** Filter Kit

HINO  
23304-78090+23304-EV041+15607-2  
050




CONT : 1  
VOL : 0.000

Note : C-1314+EF-13070+EF-13020

167

**O-1305** Oil Filter By Pass Can-type Depth

HINO 15607-1010  
HINO 15607-1010A  
HINO 15607-1011




H 1 : 225 (mm)  
OD 1 : 120 (mm)  
OD 2 : 120 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.040

172

**O-1311** Oil Filter By Pass Metal End Cap Element

HINO 15607-1340  
HINO 15607-1341  
HINO 15607-1580




H 1 : 249 (mm)  
OD 1 : 122 (mm)  
OD 2 : 122 (mm)  
ID 1 : 17.5 (mm)  
ID 2 : 17.5 (mm)

CONT : 16  
VOL : 0.082

177

**O-1301** Oil Filter Full Flow Metal End Cap Element

ISUZU 1-13240109-1  
NISSAN 15208-61501  
NISSAN 15208-61525  
NISSAN 15208-Z5000  
NISSAN 15208-Z9025




H 1 : 165 (mm)  
H 2 : 160 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 49 (mm)

CONT : 50  
VOL : 0.102

168

**O-1306** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1290




H 1 : 105 (mm)  
H 2 : 102 (mm)  
OD 1 : 92 (mm)  
OD 2 : 92 (mm)  
ID 1 : 42 (mm)  
ID 2 : 14.5 (mm)

CONT : 50  
VOL : 0.054

173

**O-1312** Oil Filter By Pass Can-type Depth

HINO 15607-1080  
HINO 15607-1081




H 1 : 204 (mm)  
OD 1 : 122 (mm)  
OD 2 : 122 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 9  
VOL : 0.040

178

**O-1302** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1150  
HINO 6052-2130-00  
HINO 6052-2330-00




H 1 : 152 (mm)  
H 2 : 145 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.100

169

**O-1307** Oil Filter By Pass Can-type Depth

HINO 15607-1210  
HINO 15607-1211




H 1 : 255 (mm)  
OD 1 : 120 (mm)  
OD 2 : 120 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 12  
VOL : 0.064

174

**O-1313** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1360  
HINO 15607-1490




H 1 : 109 (mm)  
H 2 : 103 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 49 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.072

179

**O-1303** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1030  
HINO 15607-1130  
HINO 6071-2104-00




H 1 : 172 (mm)  
H 2 : 161 (mm)  
OD 1 : 104.5 (mm)  
OD 2 : 104 (mm)  
ID 1 : 49 (mm)  
ID 2 : 23 (mm)

CONT : 50  
VOL : 0.121

170

**O-13081** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1070  
HINO 15607-1100  
HINO 15607-1101  
HINO 15607-1560  
HINO 15607-1561




H 1 : 185 (mm)  
H 2 : 180 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 49 (mm)

CONT : 25  
VOL : 0.065

175

**O-1314** Oil Filter Full Flow Metal End Cap Element

HINO 15607-1390



H 1 : 126 (mm)  
H 2 : 121 (mm)  
OD 1 : 94 (mm)  
OD 2 : 94 (mm)  
ID 1 : 39 (mm)  
ID 2 : 15 (mm)


CONT : 20  
VOL : 0.031

180

# Sakura Filter

# Technical Specification

**O-1318** Oil Filter By Pass Can-type Depth  
HINO 15607-1270




H 1 : 143.5 (mm)  
OD 1 : 100.5 (mm)  
OD 2 : 100.5 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 25  
VOL : 0.050

181

**O-1325** Oil Filter Full Flow Metal End Cap Element  
HINO 15607-2261



H 1 : 186 (mm)  
H 2 : 181 (mm)  
OD 1 : 104 (mm)  
OD 2 : 103 (mm)  
ID 1 : 15 (mm)  
ID 2 : 49 (mm)

CONT : 25  
VOL : 0.071

Note : O-1322 (Outer packing B difference)

186

**PO-13010** Oil Filter Power steering Plastic Element  
HINO 44308-1380  
HINO 44308-1385




H 1 : 143.5 (mm)  
H 2 : 103.5 (mm)  
OD 1 : 90 (mm)  
OD 2 : 90 (mm)  
ID 1 : 16 (mm)  
ID 2 : 13 (mm)

CONT : 50  
VOL : 0.077

191

**O-1319** Oil Filter By Pass Metal End Cap Element  
HINO 15607-1320




H 1 : 166 (mm)  
H 2 : 103 (mm)  
OD 1 : 105 (mm)  
OD 2 : 105 (mm)  
ID 1 : 48 (mm)  
ID 2 : 15 (mm)

CONT : 20  
VOL : 0.050

Note : Multilayer

182

**O-13254** Oil Filter Full Flow Metal End Cap Element  
HINO S1560-72430




H 1 : 186 (mm)  
H 2 : 181 (mm)  
OD 1 : 104 (mm)  
OD 2 : 103 (mm)  
ID 1 : 15 (mm)  
ID 2 : 49 (mm)

CONT : 25  
VOL : 0.071

187

**PO-1302** Oil Filter Power steering Metal End Cap Element  
HINO 44308-1270




H 1 : 67.7 (mm)  
H 2 : 53 (mm)  
OD 1 : 115 (mm)  
OD 2 : 115 (mm)  
ID 1 : 15 (mm)  
ID 2 : 15 (mm)

CONT : 50  
VOL : 0.057

192

**O-1321** Oil Filter By Pass Metal End Cap Element  
HINO 15607-2150




H 1 : 226 (mm)  
H 2 : 207 (mm)  
OD 1 : 140 (mm)  
OD 2 : 140 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 10  
VOL : 0.059

183

**O-13255** Oil Filter Full Flow Metal End Cap Element  
HINO 15613-EV071




H 1 : 185 (mm)  
H 2 : 182 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 47 (mm)  
ID 2 : 15 (mm)

CONT : 25  
VOL : 0.071

188

**SF-1307** Fuel/Water Separator Metal End Cap Element  
NISSAN 16403-Z900J  
HINO S2340-11730




H 1 : 193.4 (mm)  
H 2 : 189 (mm)  
OD 1 : 95 (mm)  
OD 2 : 95 (mm)  
ID 1 : 27.3 (mm)

CONT : 25  
VOL : 0.061

193

**O-1322** Oil Filter Full Flow Metal End Cap Element  
HINO 15607-2260




H 1 : 186 (mm)  
H 2 : 181 (mm)  
OD 1 : 103 (mm)  
OD 2 : 104 (mm)  
ID 1 : 49 (mm)  
ID 2 : 15 (mm)

CONT : 25  
VOL : 0.072

184

**O-13270** Oil Filter Full Flow Metal End Cap Element  
HINO 15607-2270  
HINO 15607-2271  
HINO S1560-72270




H 1 : 186 (mm)  
H 2 : 181 (mm)  
OD 1 : 104 (mm)  
OD 2 : 104 (mm)  
ID 1 : 15 (mm)  
ID 2 : 49 (mm)

CONT : 25  
VOL : 0.071

189

**SF-27010** Fuel/Water Separator Metal End Cap Element  
DETROIT DIESEL 23533816  
MACK 301-SD-19B  
ALLIANCE ABP/N10G-FS19624  
HITACHI E12981308




H 1 : 181.5 (mm)  
H 2 : 173.5 (mm)  
OD 1 : 101 (mm)  
OD 2 : 99.5 (mm)  
ID 1 : 16.8 (mm)

CONT : 25  
VOL : 0.064

Note : 7 micron

194

**O-1323** Oil Filter By Pass Metal End Cap Element  
HINO 15607-2280  
TOYOTA 15607-2280  
HINO 15607-2281  
TOYOTA 15607-2281  
HINO S1560-72281




H 1 : 226 (mm)  
H 2 : 207 (mm)  
OD 1 : 140 (mm)  
OD 2 : 140 (mm)  
ID 1 : 17 (mm)  
ID 2 : 17 (mm)

CONT : 10  
VOL : 0.059

185

**O-2702** Oil Filter By Pass Metal End Cap Element  
HINO 15607-1660  
HITACHI 4208241  
HITACHI 4208241-1




H 1 : 192.5 (mm)  
H 2 : 155.5 (mm)  
OD 1 : 165 (mm)  
OD 2 : 165 (mm)  
Thread Size : M16X1.0-6H

CONT : 16  
VOL : 0.116

190

**SF-28010** Fuel/Water Separator Metal End Cap Element  
TOYOTA 23390-78450  
HINO 23390-LIE50  
KORINDO MOTOR 31921-KM000



H 1 : 143 (mm)  
H 2 : 140 (mm)  
OD 1 : 91 (mm)  
OD 2 : 91 (mm)  
ID 1 : 14.5 (mm)  
ID 2 : 14.5 (mm)

CONT : 50  
VOL : 0.073

195

**SFC-1306-30** Fuel/Water Separator Primary Spin-On 30 Micron



HINO 23401-1440  
HINO 23401-1441  
HINO 23401-1630  
MERCEDES-BENZ A 376 092 7001  
KZ  
FORD F1HZ9365A

H 1 : 117 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 10  
VOL : 0.023

Note : Bowl not included

196

**SFC-5510-02** Fuel/Water Separator Final Spin-On 2 Micron



HINO 23414-E0020  
NEW HOLLAND (CNH)  
VH23414-E0020


H 1 : 217 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.045

Note : bowl not included

201

**SFC-1306-30B** Fuel/Water Separator Primary Spin-On With Bowl 30 Micron



HINO 23401-1440  
HINO 23401-1441  
FORD F1HZ9365A

H 1 : 120 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 10  
VOL : 0.035

Note : SFC-1306-30 and bowl assembly

197

**SFC-7912-10** Fuel/Water Separator Secondary Spin-On 10 Micron



HINO 23401-1700  
ATLAS COPCO 2914-8071-00


Primary Filter uses SFC-7912-30  
Final Filter uses SFC-7912-02  
H 1 : 155 (mm)  
H 2 : 143 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.030

Note : for 300RC series,400 series,600 series,700 series

202

**SFC-1307** Fuel/Water Separator Spin-On With Drain Plug



HINO 23401-1442L


H 1 : 174 (mm)  
H 2 : 147 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 6  
VOL : 0.016

Note : SFC-1307(Media difference)

198

**SFC-7912-10B** Fuel/Water Separator Secondary Spin-On With Bowl 10 Micron



HINO 23390-E0010  
HINO 23401-1700  
ATLAS COPCO 2914-8071-00

Primary Filter uses SFC-7912-30B  
Final Filter uses SFC-7912-02B  
H 1 : 216.5 (mm)  
H 2 : 143 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.043

Note : for 300RC series,400 series,600 series,700 series

203

**SFC-13071** Fuel/Water Separator Spin-On With Drain Plug



HINO 23401-1700A


H 1 : 174 (mm)  
H 2 : 147 (mm)  
OD 1 : 108 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 12  
VOL : 0.034

Note : SFC-1307(Media difference)

199

**WC-5707** Coolant Filter Spin-On



INGERSOLL RAND 35357276  
KOMATSU 600-411-1180  
KOMATSU 6134-61-8110  
KOMATSU 6710-61-8110

H 1 : 135 (mm)  
OD 1 : 93 (mm)  
Thread Size : 11/16-16 UNF-2B  
Gasket Type : Square

CONT : 12  
VOL : 0.022

Note : Coolants = 8 units

204

**SFC-50021-10** Fuel/Water Separator Spin-On 10 Micron



HINO FS1994290

H 1 : 79 (mm)  
OD 1 : 93 (mm)  
Thread Size : 1-14 UNS-2B

CONT : 12  
VOL : 0.016

Note : bowl not included

200